



FZS6W FZS6WC

SERVICE MANUAL

EAS20050

**FZS6W/FZS6WC
SERVICE MANUAL
©2006 by Yamaha Motor
Corporation, U.S.A.
First edition, October 2006
All rights reserved. Any reproduction
or unauthorized use without the written
permission of Yamaha Motor Corporation,
U.S.A. is expressly prohibited.
Printed in U.S.A.
P/N LIT-11616-20-60**

NOTICE

This manual was produced by the Yamaha Motor Company, Ltd. primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha vehicles should have a basic understanding of mechanics and the techniques to repair these types of vehicles. Repair and maintenance work attempted by anyone without this knowledge is likely to render the vehicle unsafe and unfit for use.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the vehicle will operate as designed. If there is any question about a service procedure, it is imperative that you contact a Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his vehicle and to conform to federal environmental quality objectives.

Yamaha Motor Company, Ltd. is continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

NOTE:

- This Service Manual contains information regarding periodic maintenance to the emission control system. Please read this material carefully.
- Designs and specifications are subject to change without notice.

IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the vehicle operator, a bystander or a person checking or repairing the vehicle.

CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the vehicle.

NOTE:

A NOTE provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and check procedures are laid out with the individual steps in sequential order.

- The manual is divided into chapters and each chapter is divided into sections. The current section title is shown at the top of each page “1”.
- Sub-section titles appear in smaller print than the section title “2”.
- To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section “3”.
- Numbers are given in the order of the jobs in the exploded diagram. A number indicates a disassembly step “4”.
- Symbols indicate parts to be lubricated or replaced “5”.
- Refer to “SYMBOLS”.
- A job instruction chart accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc “6”.
- Jobs requiring more information (such as special tools and technical data) are described sequentially “7”.

1
↓
CLUTCH

2 SECTION
CLUTCH

3 Removing the clutch cover

4 **5** **6**

Order	Job/Parts to remove	Q'ty	Remarks
	Engine oil		Drain Refer to "CHANGING THE ENGINE OIL" on page 3-12.
	Coolant		Drain Refer to "CHANGING THE COOLANT" on page 3-18.
1	Coolant hose	1	
2	Clutch cable	1	
3	Clutch cable holder	1	
4	Clutch cover	1	
5	Clutch cover gasket	1	
6	Dowel pin	2	For installation, reverse the removal procedure.

* Yamaha bond No.1215 (Three Bond No.1215®)

5-46

CLUTCH

7

Clutch spring free length
55.00 mm (2.17 in)
Minimum length
54.00 mm (2.13 in)
Limit
52.3 mm (2.06 in)

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

296

297

298

299

300

301

302

303

304

305

306

307

308

309

310

311

312

313

314

315

316

317

318

319

320

321

322

323

324

325

326

327

328

329

330

331

332

333

334

335

336

337

338

339

340

341

342

343

344

345

346

347

348

349

350

351

352

353

354

355

356

357

358

359

360

361

362

363

364

365

366

367

368

369

370

371

372

373

374

375

376

377

378

379

380

381

382

383

384

385

386

387

388

389

390

391

392

393

394

395

396

397

398

399

400

401

402

403

404

405

406

407

408

409

410

411

412

413

414

415

416

417

418

419

420

421

422

423

424

425

426

427

428

429

430

431

432

433

434

435

436

437

438

439

440

441

442

443

444

445

446

447

448

449

450

451

452

453

454

455

456

457

458

459

460

461

462

463

464

465

466

467

468

469

470

471

472

473

474

475

476

477

478

479

480

481

482

483

484

485

486

487

488

489

490

491

492

493

494

495

496

497

498

499

500

501

502

503

504

505

506

507

508

509

510

511

512

513

514

515

516

517

518

519

520

521

522

523

524

525

526

527

528

529

530

531

532

533

534

535

536

537

538

539

540

541

542

543

544

545

546

547

548

549

550

551

552

553

554

555

556

557

558

559

560

561

562

563

564

565

566

567

568

569

570

571

572

573

574

575

576

577

578

579

580

581

582

583

584

585

586

587

588

589

590

591

592

593

594

595

596

597

598

599

600

601

602

603

604

605

606

607

608

609

610

611

612

613

614

615

616

617

618

619

620

621

622

623

624

625

626

627

628

629

630

631

632

633

634

635

636

637

638

639

640

641

642

643

644

645

646

647

648

649

650

651

652

653

654

655

656

657

658

659

660

661

662

663

664

665

666

667

668

669

670

671

672

673

674

675

676

677

678

679

680

681

682

683

684

685

686

687

688

689

690

691

692

693

694

695

696

697

698

699

700

701

702

703

704

705

706

707

708

709

710

711

712

713

714

715

716

717

718

719

720

721

722

723

724

725

726

727

728

729

730

731

732

733

734

735

736

737

738

739

740

741

742

743

744

745

746

747

748

749

750

751

752

753

754

755

756

757

758

759

760

761

762

763

764

765

766

767

768

769

770

771

772

773

774

775

776

777

778

779

780

781

782

783

784

785

786

787

788

789

790

791

792

793

794

795

796

797

798

799

800

801

802

803

804

805

806

807

808

809

810

811

812

813

814

815

816

817

818

819

820

821

822

823

824

825

826

827

828

829

830

831

832

833

834

835

836

837

838

839

840

841

842

843

844

845

846

847

848

849

850

851

852

853

854

855

856

857

858

859

860

861

862

863

864

865

866

867

868

869


870

SYMBOLS

The following symbols are used in this manual for easier understanding.

NOTE:

The following symbols are not relevant to every vehicle.



1. Serviceable with engine mounted
2. Filling fluid
3. Lubricant
4. Special tool
5. Tightening torque
6. Wear limit, clearance
7. Engine speed
8. Electrical data
9. Engine oil
10. Gear oil
11. Molybdenum-disulfide oil
12. Wheel-bearing grease
13. Lithium-soap-based grease
14. Molybdenum-disulfide grease
15. Apply locking agent (LOCTITE®)



TABLE OF CONTENTS

GENERAL INFORMATION	1
SPECIFICATIONS	2
PERIODIC CHECKS AND ADJUSTMENTS	3
CHASSIS	4
ENGINE	5
COOLING SYSTEM	6
FUEL SYSTEM	7
ELECTRICAL SYSTEM	8
TROUBLESHOOTING	9



GENERAL INFORMATION

IDENTIFICATION	1-1
VEHICLE IDENTIFICATION NUMBER.....	1-1
MODEL LABEL	1-1
FEATURES	1-2
OUTLINE OF FI SYSTEM	1-2
FI SYSTEM.....	1-3
INSTRUMENT FUNCTIONS	1-4
IMPORTANT INFORMATION	1-7
PREPARATION FOR REMOVAL AND DISASSEMBLY	1-7
REPLACEMENT PARTS.....	1-7
GASKETS, OIL SEALS AND O-RINGS.....	1-7
LOCK WASHERS/PLATES AND COTTER PINS	1-7
BEARINGS AND OIL SEALS	1-8
CIRCLIPS	1-8
CHECKING THE CONNECTIONS	1-9
SPECIAL TOOLS	1-10


EAS20130

IDENTIFICATION

EAS20140

VEHICLE IDENTIFICATION NUMBER


The vehicle identification number "1" is stamped into the right side of the steering head pipe.



EAS20150

MODEL LABEL

The model label "1" is affixed to the frame. This information will be needed to order spare parts.



EAS20170

FEATURES

EAS4S81003


OUTLINE OF FI SYSTEM

The main function of a fuel supply system is to provide fuel to the combustion chamber at the optimum air-fuel ratio in accordance with the engine operating conditions and the atmospheric temperature.

In the conventional carburetor system, the air-fuel ratio of the mixture that is supplied to the combustion chamber is created by the volume of the intake air and the fuel that is metered by the jet used in the respective carburetor.

Despite the same volume of intake air, the fuel volume requirement varies by the engine operating conditions, such as acceleration, deceleration, or operating under a heavy load. Carburetors that meter the fuel through the use of jets have been provided with various auxiliary devices, so that an optimum air-fuel ratio can be achieved to accommodate the constant changes in the operating conditions of the engine.

As the requirements for the engine to deliver more performance and cleaner exhaust gases increase, it becomes necessary to control the air-fuel ratio in a more precise and finely tuned manner. To accommodate this need, this model has adopted an electronically controlled fuel injection (FI) system, in place of the conventional carburetor system. This system can achieve an optimum air-fuel ratio required by the engine at all times by using a microprocessor that regulates the fuel injection volume according to the engine operating conditions detected by various sensors. The adoption of the FI system has resulted in a highly precise fuel supply, improved engine response, better fuel economy, and reduced exhaust emissions. Furthermore, the air induction system (AI system) has been placed under computer control together with the FI system in order to realize cleaner exhaust gases.




- | | |
|----------------------------------|----------------------------------|
| 1. Ignition coil | 12. Coolant temperature sensor |
| 2. Air filter case | 13. Spark plug |
| 3. Intake air temperature sensor | 14. Pressure regulator |
| 4. Fuel delivery hose | 15. Battery |
| 5. Fuel tank | 16. ECU |
| 6. Fuel pump | 17. Fuel injection system relay |
| 7. Intake air pressure sensor | 18. Engine trouble warning light |
| 8. Throttle position sensor | 19. Lean angle sensor |
| 9. Fuel injector | 20. O ₂ sensor |
| 10. Catalytic converter | |
| 11. Crankshaft position sensor | |

EAS4S81004

FI SYSTEM

The fuel pump delivers fuel to the injector via the fuel filter. The pressure regulator maintains the fuel pressure that is applied to the injector at only 250 kPa (2.5 kg/cm²). Accordingly, when the energizing signal from the ECU energizes the injector, the fuel passage opens, causing the fuel to be injected into the intake manifold only during the time the passage remains open. Therefore, the longer the length of time the injector is energized (injection duration), the greater the volume of fuel that is supplied. Conversely, the shorter the length of time the injector is energized (injection duration), the lesser the volume of fuel that is supplied.


The injection duration and the injection timing are controlled by the ECU. Signals that are input from the throttle position sensor, crankshaft position sensor, intake air pressure sensor, intake temperature sensor, coolant temperature sensor and O₂ sensor enable the ECU to determine the injection duration. The injection timing is determined through the signals from the crankshaft position sensor. As a result, the volume of fuel that is required by the engine can be supplied at all times in accordance with the driving conditions.



1. Fuel pump
 2. Pressure regulator
 3. Fuel injector
 4. Throttle body
 5. Intake air temperature sensor
 6. Throttle position sensor
 7. Intake air pressure sensor
 8. ECU
 9. Coolant temperature sensor
 10. Crankshaft position sensor
 11. O₂ sensor
- A. Fuel system
B. Control system

EAS4S81005

INSTRUMENT FUNCTIONS



1. Coolant temperature display/air intake temperature display
2. Speedometer
3. Tachometer
4. Odometer/tripmeter/fuel reserve tripmeter
5. "SELECT" button
6. "RESET" button
7. Clock
8. Fuel meter

EWA4S81002



WARNING

Be sure to stop the vehicle before making any setting changes to the multi-function meter unit.


The multi-function meter unit is equipped with the following:

- a speedometer (which shows the riding speed)
- a tachometer (which shows engine speed)
- an odometer (which shows the total distance traveled)
- two tripmeters (which show the distance traveled since they were last set to zero)
- a fuel reserve tripmeter (which shows the distance traveled since the left segment of the fuel meter started flashing)
- a clock
- a fuel meter
- a coolant temperature display
- an air intake temperature display a self-diagnosis device
- an LCD and tachometer brightness control mode

NOTE:

- Be sure to turn the key to "ON" before using the "SELECT" and "RESET" buttons.
- To switch the speedometer and odometer/tripmeter displays between kilometers and miles, press the "SELECT" button for at least one second.

Tachometer



1. Tachometer
 2. Tachometer red zone.
- The electric tachometer allows the rider to monitor the engine speed and keep it within the ideal power range.
- When the key is turned to "ON", the tachometer needle will sweep once across the r/min range and then return to zero r/min in order to test the electrical circuit.


ECA4S81004

CAUTION:

Do not operate the engine in the tachometer red zone.


Red zone: 14000 r/min and above

Clock mode



1. Clock
 2. Speedometer
- The clock is displayed when the key is turned to "ON". In addition, the clock can be displayed for 10 seconds by pushing the "SELECT" button when the main switch is in the "OFF" or "LOCK" position.
- To set the clock
- 1 Turn the key to "ON".
 2. Push the "SELECT" button and "RESET" button together for at least two seconds.
 3. When the hour digits start flashing, push the "RESET" button to set the hours.
 4. Push the "SELECT" button, and the minute digits will start flashing.
 5. Push the "RESET" button to set the minutes.
 6. Push the "SELECT" button and then release it to start the clock.

Odometer and tripmeter modes



1. Odometer/tripmeter/fuel reserve tripmeter
Push the “SELECT” button to switch the display between the odometer mode “ODO” and the tripmeter modes “TRIP A” and “TRIP B” in the following order:


“TRIP A” → “TRIP B” → “ODO” → “TRIP A”

When the fuel amount in the fuel tank decreases to 3.4 L (0.90 US gal) (0.75 Imp.gal), the left segment of the fuel meter will start flashing, and the odometer display will automatically change to the fuel reserve tripmeter mode “F TRIP” and start counting the distance traveled from that point. In that case, push the “SELECT” button to switch the display between the various tripmeter and odometer modes in the following order:

“F-TRIP” → “TRIP A” → “TRIP B” → “ODO” → “F-TRIP”

To reset a tripmeter, select it by pushing the “SELECT” button, and then push the “RESET” button for at least one second. If you do not reset the fuel reserve tripmeter manually, it will reset itself automatically and the display will return to the prior mode after refueling and traveling 5 km (3 mi).

Fuel meter




1. Fuel meter
The fuel meter indicates the amount of fuel in the fuel tank. The display segments of the fuel meter disappear towards “E” (Empty) as the fuel level decreases. When only one segment is left near “E”, refuel as soon as possible.

NOTE:

This fuel meter is equipped with a self-diagnosis system. If the electrical circuit is defective, the following cycle will be repeated until the malfunction is corrected: “E” (Empty), “F” (Full) and symbol “” will flash eight times, then go off for approximately 3 seconds. If this occurs, have a Yamaha dealer check the electrical circuit.

Coolant temperature mode



1. Coolant temperature display
The coolant temperature display indicates the temperature of the coolant. Push the “RESET” button to switch the coolant temperature display to the air intake temperature display.

NOTE:


When the coolant temperature display is selected, “C” is displayed for one second, and then the coolant temperature is displayed.

ECA4S81009

CAUTION:

Do not operate the engine if it is overheated.

Air intake temperature mode




1. Air intake temperature display
The air intake temperature display indicates the temperature of the air drawn into the air filter case. Push the “RESET” button to switch the coolant temperature display to the air intake temperature display.

NOTE:

- Even if the air intake temperature is set to be displayed, the coolant temperature warning light comes on when the engine overheats.
- When the key is turned to “ON”, the coolant temperature is automatically displayed, even if the air intake temperature was displayed prior to turning the key to “OFF”.
- When the air intake temperature display is selected, “A” is displayed for one second, and then the air intake temperature is displayed.

4. Push the “RESET” button to select the desired brightness level.
5. Push the “SELECT” button to confirm the selected brightness level. The display will return to the odometer or tripmeter mode.


Self-diagnosis device



1. Error code display

This model is equipped with a self-diagnosis device for various electrical circuits. If any of those circuits are defective, the engine trouble warning light will come on, and then the display will indicate a two-digit error code (e.g., 11, 12, 13).

LCD and tachometer brightness control mode



1. Tachometer panel
2. Tachometer needle
3. LCD
4. Brightness level

This function allows you to adjust the brightness of the LCD and the tachometer panel and needle to suit the outside lighting conditions.

To set the brightness

1. Turn the key to “OFF”.
2. Push and hold the “SELECT” button.
3. Turn the key to “ON”, and then release the “SELECT” button after five seconds.

EAS20180

IMPORTANT INFORMATION

EAS20190

PREPARATION FOR REMOVAL AND DISASSEMBLY

1. Before removal and disassembly, remove all dirt, mud, dust and foreign material.



2. Use only the proper tools and cleaning equipment. Refer to "SPECIAL TOOLS" on page 1-10.
3. When disassembling, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.




4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.

EAS20200

REPLACEMENT PARTS


Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.



EAS20210

GASKETS, OIL SEALS AND O-RINGS

1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. During reassembly, properly oil all mating parts and bearings and lubricate the oil seal lips with grease.




1. Oil
2. Lip
3. Spring
4. Grease

EAS20220

LOCK WASHERS/PLATES AND COTTER PINS



After removal, replace all lock washers/plates "1" and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.



EAS20230

BEARINGS AND OIL SEALS


Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals "1", lubricate the oil seal lips with a light coat of lithium-soap-based grease. Oil bearings liberally when installing, if appropriate.



ECA13300

CAUTION:

Do not spin the bearing with compressed air because this will damage the bearing surfaces.



EAS20240

CIRCLIPS

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip "1", make sure the sharp-edged corner "2" is positioned opposite the thrust "3" that the circlip receives.

CHECKING THE CONNECTIONS

EAS20250

CHECKING THE CONNECTIONS

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

1. Disconnect:


- Lead
- Coupler
- Connector

2. Check:

- Lead
- Coupler
- Connector

Moisture → Dry with an air blower.

Rust/stains → Connect and disconnect several times.




3. Check:

- All connections

Loose connection → Connect properly.

NOTE:

If the pin "1" on the terminal is flattened, bend it up.



4. Connect:

- Lead
- Coupler
- Connector

NOTE:

Make sure all connections are tight.

5. Check:

- Continuity
(with the pocket tester)



Pocket tester



90890-03112

Analog pocket tester

YU-03112-C

NOTE:

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (3).
- As a quick remedy, use a contact revitalizer available at most part stores.



EAS20260







SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools as this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools, part numbers or both may differ depending on the country.









When placing an order, refer to the list provided below to avoid any mistakes.

NOTE:








- For U.S.A. and Canada, use part number starting with “YM-”, “YU-”, or “ACC-”.
- For others, use part number starting with “90890-”.

Tool name/Tool No.	Illustration	Reference pages
Flywheel puller 90890-01362 Heavy duty puller YU-33270-B		5-30
Flywheel puller attachment 90890-04089 Crankshaft protector YM-33282	90890-04089 	5-30
Sheave holder 90890-01701 Primary clutch holder YS-01880-A		5-30, 5-31, 5-32, 5-34
Piston pin puller set 90890-01304 Piston pin puller YU-01304	90890-01304 	5-62
Radiator cap tester 90890-01325 Radiator pressure tester YU-24460-01	90890-01325 	6-3
Radiator cap tester adapter 90890-01352 Radiator pressure tester adapter YU-33984	90890-01352 	6-3









SPECIAL TOOLS

Tool name/Tool No.	Illustration	Reference pages
Steering nut wrench 90890-01403 Spanner wrench YU-33975		3-26, 4-53
Damper rod holder 90890-01294 Damping rod holder set YM-01300		4-45, 4-47
T-handle 90890-01326 YM-01326		4-45, 4-47
Oil filter wrench 90890-01426 YU-38411		3-13
Fork seal driver weight 90890-01367 Replacement hammer YM-A9409-7		4-47, 4-48
Fork seal driver attachment (ø43) 90890-01374 Replacement 43 mm YM-A5142-3		4-47
Vacuum gauge 90890-03094 Carburetor synchronizer YU-44456		3-7
Compression gauge 90890-03081 Engine compression tester YU-33223		3-11

SPECIAL TOOLS

Tool name/Tool No.	Illustration	Reference pages
Pocket tester 90890-03112 Analog pocket tester YU-03112-C		1-9, 5-38, 8-65, 8-66, 8-67, 8-71, 8-72, 8-73, 8-74, 8-75, 8-76, 8-77, 8-78, 8-79, 8-80, 8-81, 8-82
Pressure gauge 90890-03153 YU-03153		3-14, 7-6
Oil pressure adapter H 90890-03139		3-14
Fuel pressure adapter 90890-03176 YM-03176		7-6
Valve spring compressor 90890-04019 YM-04019		5-21, 5-27
Valve spring compressor attachment 90890-04108 Valve spring compressor adapter 22 mm YM-04108		5-21, 5-27
Middle driven shaft bearing driver 90890-04058 Bearing driver 40 mm YM-04058		6-12
Mechanical seal installer 90890-04078 Water pump seal installer YM-33221-A		6-12

SPECIAL TOOLS

Tool name/Tool No.	Illustration	Reference pages
Universal clutch holder 90890-04086 YM-91042		5-49, 5-51
Valve lapper 90890-04101 Valve lapping tool YM-A8998		3-5
Valve guide remover (ø4) 90890-04111 Valve guide remover (4.0 mm) YM-04111		5-23
Valve guide installer (ø4) 90890-04112 Valve guide installer (4.0 mm) YM-04112		5-23
Valve guide reamer (ø4) 90890-04113 Valve guide reamer (4.0 mm) YM-04113		5-23
Ignition checker 90890-06754 Opama pet-4000 spark checker YM-34487		8-74
Yamaha bond No. 1215 (Three bond No.1215®) 90890-85505		5-32, 5-35, 5-58, 6-12
Digital circuit tester 90890-03174 Model 88 Multimeter with tachometer YU-A1927		7-7

SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
ENGINE SPECIFICATIONS	2-2
CHASSIS SPECIFICATIONS	2-9
ELECTRICAL SPECIFICATIONS	2-12
TIGHTENING TORQUES	2-15
GENERAL TIGHTENING TORQUE SPECIFICATIONS	2-15
ENGINE TIGHTENING TORQUES	2-16
CHASSIS TIGHTENING TORQUES	2-20
LUBRICATION POINTS AND LUBRICANT TYPES	2-22
ENGINE	2-22
CHASSIS	2-23
LUBRICATION SYSTEM CHART AND DIAGRAMS	2-25
ENGINE OIL LUBRICATION CHART	2-25
LUBRICATION DIAGRAMS	2-27
COOLING SYSTEM DIAGRAMS	2-39
CABLE ROUTING	2-47

GENERAL SPECIFICATIONS

EAS20280

GENERAL SPECIFICATIONS

Model

Model	4S82 (U.S.A.) 4S83 (California)
-------	------------------------------------

Dimensions

Overall length	2095 mm (82.5 in)
Overall width	750 mm (29.5 in)
Overall height	1210 mm (47.6 in)
Seat height	795 mm (31.3 in)
Wheelbase	1440 mm (56.7 in)
Ground clearance	145 mm (5.71 in)
Minimum turning radius	2800 mm (110.2 in)

Weight

With oil and fuel	207.0 kg (456 lb) (FZS6W) 208.0 kg (459 lb) (FZS6WC)
Maximum load	189 kg (417 lb) (FZS6WC) 190 kg (419 lb) (FZS6W)

ENGINE SPECIFICATIONS

EAS20290

ENGINE SPECIFICATIONS

Engine

Engine type	Liquid cooled 4-stroke, DOHC
Displacement	600.0 cm ³
Cylinder arrangement	Forward-inclined parallel 4-cylinder
Bore × stroke	65.5 × 44.5 mm (2.58 × 1.75 in)
Compression ratio	12.20 :1
Standard compression pressure (at sea level)	1550 kPa/400 r/min (220.5 psi/400 r/min) (15.5 kgf/cm ² /400 r/min)
Minimum–maximum	1300–1650 kPa (184.9–234.7 psi) (13.0–16.5 kgf/cm ²)
Starting system	Electric starter

Fuel

Recommended fuel	Unleaded gasoline only
Fuel tank capacity	19.4 L (5.13 US gal) (4.27 Imp.gal)
Fuel reserve amount	3.6 L (0.95 US gal) (0.79 Imp.gal)

Engine oil

Lubrication system	Wet sump
Type	YAMALUBE 4, SAE10W30 or SAE 20W40
Recommended engine oil grade	API service SG type or higher, JASO standard MA

Engine oil quantity

Total amount	3.40 L (3.59 US qt) (2.99 Imp.qt)
Without oil filter cartridge replacement	2.50 L (2.64 US qt) (2.20 Imp.qt)
With oil filter cartridge replacement	2.80 L (2.96 US qt) (2.46 Imp.qt)
Oil pressure	240 kPa at 6,600 r/min (2.4 kg/cm ² at 6,600 r/min) (2.4 bar at 6,600 r/min) (34.1 psi at 6,600 r/min)

Oil filter

Oil filter type	Formed
-----------------	--------

Oil pump

Oil pump type	Trochoid
Inner-rotor-to-outer-rotor-tip clearance	0.030–0.090 mm (0.0012–0.0035 in)
Limit	0.15 mm (0.0059 in)
Outer-rotor-to-oil-pump-housing clearance	0.030–0.080 mm (0.0012–0.0032 in)
Limit	0.150 mm (0.0059 in)
Bypass valve opening pressure	80.0–120.0 kPa (11.6–17.4 psi) (0.80–1.20 kgf/cm ²)
Relief valve operating pressure	450.0–550.0 kPa (65.3–79.8 psi) (4.50–5.50 kgf/cm ²)
Pressure check location	Main gallery

Cooling system

Radiator capacity (including all routes)	2.00 L (2.11 US qt) (1.76 Imp.qt)
Radiator capacity	0.60 L (0.63 US qt) (0.53 Imp.qt)
Coolant reservoir capacity (up to the maximum level mark)	0.25 L (0.26 US qt) (0.22 Imp.qt)
Radiator cap opening pressure	93–123 kPa (13.2–17.5 psi) (0.93–1.23 kgf/cm ²)

Radiator core

Width	300.0 mm (11.81 in)
Height	188.0 mm (7.40 in)
Depth	24.0 mm (0.94 in)

ENGINE SPECIFICATIONS

Water pump


Water pump type	Single suction centrifugal pump
Reduction ratio	86/44 × 31/31 (1.955)
Max. impeller shaft tilt	0.15 mm (0.006 in)

Spark plug (s)

Manufacturer/model	NGK/CR9EK
Spark plug gap	0.6–0.7 mm (0.024–0.028 in)

Cylinder head

Volume	10.33–10.93 cm ³ (0.63–0.67 cu.in)
Warpage limit	0.05 mm (0.0020 in)




Camshaft

Drive system	Chain drive (right)
Camshaft cap inside diameter	23.008–23.029 mm (0.9058–0.9067 in)
Camshaft journal diameter	22.967–22.980 mm (0.9042–0.9047 in)
Camshaft-journal-to-camshaft-cap clearance	0.028–0.062 mm (0.0011–0.0024 in)
Limit	0.080 mm (0.0032 in)


Camshaft lobe dimensions

Intake A	32.450–32.550 mm (1.2776–1.2815 in)
Limit	32.400 mm (1.2756 in)
Intake B	24.950–25.050 mm (0.9823–0.9862 in)
Limit	24.900 mm (0.9803 in)
Exhaust A	32.450–32.550 mm (1.2776–1.2815 in)
Limit	32.400 mm (1.2756 in)
Exhaust B	24.950–25.050 mm (0.9823–0.9862 in)
Limit	24.900 mm (0.9803 in)



Camshaft runout limit

0.060 mm (0.0024 in)



Timing chain


Model/number of links	92RH2015/120
Tensioning system	Automatic

Valve clearance (cold)


Intake	0.13–0.20 mm (0.0051–0.0079 in)
Exhaust	0.23–0.30 mm (0.0091–0.0118 in)

Valve dimensions


Valve head diameter A (intake)	24.90–25.10 mm (0.9803–0.9882 in)
Valve head diameter A (exhaust)	21.90–22.10 mm (0.8622–0.8701 in)




Valve face width B (intake)	1.140–1.980 mm (0.0449–0.0780 in)
Valve face width B (exhaust)	1.140–1.980 mm (0.0449–0.0780 in)




Valve seat width C (intake)	0.90–1.10 mm (0.0354–0.0433 in)
Limit	1.6 mm (0.06 in)
Valve seat width C (exhaust)	0.90–1.10 mm (0.0354–0.0433 in)
Limit	1.6 mm (0.06 in)



Valve margin thickness D (intake)	0.60–0.80 mm (0.0236–0.0315 in)
Limit	0.5 mm (0.02 in)
Valve margin thickness D (exhaust)	0.60–0.80 mm (0.0236–0.0315 in)
Limit	0.5 mm (0.02 in)



Valve stem diameter (intake)	3.975–3.990 mm (0.1565–0.1571 in)
Limit	3.950 mm (0.1555 in)
Valve stem diameter (exhaust)	3.960–3.975 mm (0.1559–0.1565 in)
Limit	3.935 mm (0.1549 in)
Valve guide inside diameter (intake)	4.000–4.012 mm (0.1575–0.1580 in)
Limit	4.042 mm (0.1591 in)
Valve guide inside diameter (exhaust)	4.000–4.012 mm (0.1575–0.1580 in)
Limit	4.042 mm (0.1591 in)
Valve-stem-to-valve-guide clearance (intake)	0.010–0.037 mm (0.0004–0.0015 in)
Limit	0.080 mm (0.0032 in)
Valve-stem-to-valve-guide clearance (exhaust)	0.025–0.052 mm (0.0010–0.0020 in)
Limit	0.100 mm (0.0039 in)
Valve stem runout	0.040 mm (0.0016 in)




Cylinder head valve seat width (intake)	0.90–1.10 mm (0.0354–0.0433 in)
Limit	1.6 mm (0.06 in)
Cylinder head valve seat width (exhaust)	0.90–1.10 mm (0.0354–0.0433 in)

ENGINE SPECIFICATIONS

Limit	1.6 mm (0.06 in)
-------	------------------

Valve spring

Inner spring	
Free length (intake)	37.04 mm (1.46 in)
Limit	35.20 mm (1.39 in)
Free length (exhaust)	41.79 mm (1.65 in)
Limit	39.70 mm (1.56 in)
Installed length (intake)	30.02 mm (1.18 in)
Installed length (exhaust)	36.12 mm (1.42 in)
Spring rate K1 (intake)	10.50 N/mm (59.96 lb/in) (1.07 kgf/mm)
Spring rate K2 (intake)	17.00 N/mm (97.07 lb/in) (1.73 kgf/mm)
Spring rate K1 (exhaust)	30.26 N/mm (172.78 lb/in) (3.09 kgf/mm)
Spring rate K2 (exhaust)	49.53 N/mm (282.82 lb/in) (5.05 kgf/mm)
Installed compression spring force (intake)	69–79 N (15.51–17.76 lbf) (7.04–8.06 kgf)
Installed compression spring force (exhaust)	160–184 N (35.97–41.36 lbf) (16.32–18.76 kgf)
Spring tilt (intake)	2.5 °/1.6 mm (0.06 in)
Spring tilt (exhaust)	2.5 °/1.8 mm (0.07 in)




Winding direction (intake)	Counter clockwise
Winding direction (exhaust)	Clockwise
Outer spring	
Free length (intake)	38.40 mm (1.51 in)
Limit	36.50 mm (1.44 in)
Installed length (intake)	32.52 mm (1.28 in)
Spring rate K1 (intake)	20.80 N/mm (118.77 lb/in) (2.12 kgf/mm)
Spring rate K2 (intake)	33.30 N/mm (190.14 lb/in) (3.40 kgf/mm)
Installed compression spring force (intake)	114–132 N (25.63–29.67 lbf) (11.62–13.46 kgf)
Spring tilt (intake)	2.5 °/1.7 mm (0.07 in)
Winding direction (intake)	Clockwise

Cylinder

Bore	65.500–65.510 mm (2.5787–2.5791 in)
Taper limit	0.050 mm (0.0020 in)
Out of round limit	0.050 mm (0.0020 in)

Piston

Piston-to-cylinder clearance	0.010–0.035 mm (0.0004–0.0014 in)
Limit	0.05 mm (0.0020 in)
Diameter D	65.475–65.490 mm (2.5778–2.5783 in)
Height H	4.0 mm (0.16 in)



ENGINE SPECIFICATIONS

Offset	0.50 mm (0.0197 in)
Offset direction	Intake side
Piston pin bore inside diameter	16.002–16.013 mm (0.6300–0.6304 in)
Limit	16.043 mm (0.6316 in)
Piston pin outside diameter	15.991–16.000 mm (0.6296–0.6299 in)
Limit	15.971 mm (0.6288 in)
Piston-pin-to-piston-pin-bore clearance	0.002–0.022 mm (0.0001–0.0009 in)
Limit	0.072 mm (0.0028 in)

Piston ring

Top ring


Ring type	Barrel
Dimensions (B × T)	0.90 × 2.45 mm (0.04 × 0.10 in)



End gap (installed)	0.25–0.35 mm (0.0098–0.0138 in)
Limit	0.60 mm (0.0236 in)
Ring side clearance	0.030–0.065 mm (0.0012–0.0026 in)
Limit	0.115 mm (0.0045 in)

2nd ring


Ring type	Taper
Dimensions (B × T)	0.80 × 2.50 mm (0.03 × 0.10 in)



End gap (installed)	0.70–0.80 mm (0.0276–0.0315 in)
Limit	1.15 mm (0.0453 in)
Ring side clearance	0.030–0.065 mm (0.0012–0.0026 in)
Limit	0.125 mm (0.0049 in)

Oil ring

Dimensions (B × T)	1.50 × 2.00 mm (0.06 × 0.08 in)
--------------------	---------------------------------



End gap (installed)	0.10–0.35 mm (0.0039–0.0138 in)
---------------------	---------------------------------


Connecting rod

Oil clearance (using plastigauge®)	0.028–0.052 mm (0.0011–0.0020 in)
Limit	0.08 mm (0.0032 in)
Bearing color code	1.Blue 2.Black 3.Brown 4.Green

ENGINE SPECIFICATIONS

Crankshaft

Width A	51.850–52.550 mm (2.04–2.06 in)
Width B	268.80–270.00 mm (10.58–10.63 in)
Runout limit C	0.030 mm (0.0012 in)
Big end side clearance D	0.160–0.262 mm (0.0063–0.0103 in)



Big end radial clearance	0.028–0.052 mm (0.0011–0.0020 in)
Small end free play	0.32–0.50 mm (0.01–0.02 in)
Journal oil clearance (using plastigauge®)	0.034–0.058 mm (0.0013–0.0023 in)
Limit	0.10 mm (0.0039 in)
Bearing color code	0.White 1.Black 2.Brown 3.Green 4.Yellow

Clutch

Clutch type	Wet, multiple-disc
Clutch release method	Outer pull, rack and pinion pull
Clutch release method operation	Cable operation
Clutch lever free play	10.0–15.0 mm (0.39–0.59 in)
Friction plate thickness	2.92–3.08 mm (0.115–0.121 in)
Wear limit	2.80 mm (0.1102 in)
Plate quantity	6 pcs
Friction plate thickness	2.92–3.08 mm (0.115–0.121 in)
Plate quantity	2 pcs
Clutch plate thickness	1.90–2.10 mm (0.075–0.083 in)
Plate quantity	7 pcs
Warpage limit	0.10 mm (0.0039 in)
Clutch plate thickness	2.20–2.40 mm (0.087–0.094 in)
Plate quantity	1 pcs
Warpage limit	0.10 mm (0.0039 in)
Clutch spring free length	55.00 mm (2.17 in)
Limit	52.30 mm (2.06 in)
Spring quantity	6 pcs

Transmission

Transmission type	Constant mesh 6-speed
Primary reduction system	Spur gear
Primary reduction ratio	86/44 (1.955)
Secondary reduction system	Chain drive
Secondary reduction ratio	46/16 (2.875)
Operation	Left foot operation

Gear ratio

1st	37/13 (2.846)
2nd	37/19 (1.947)
3rd	28/18 (1.556)
4th	32/24 (1.333)
5th	25/21 (1.190)
6th	26/24 (1.083)
Main axle runout limit	0.02 mm (0.0008 in)
Drive axle runout limit	0.02 mm (0.0008 in)

ENGINE SPECIFICATIONS

Shifting mechanism

Shift mechanism type	Shift drum
Shift fork guide bar bending limit	0.050 mm (0.0020 in)
Shift fork thickness	5.76–5.89 mm (0.2268–0.2319 in)

Air filter

Air filter element	Oil-coated paper element
--------------------	--------------------------

Fuel pump

Pump type	Electrical
Model/manufacture	5VX/DENSO
Maximum consumption amperage	5.5 A
Output pressure	250.0 kPa (36.3 psi) (2.50 kgf/cm ²)

Fuel injector

Model/quantity	0290 x 4
Manufacturer	DENSO

Throttle body

Type/quantity	36EIDW-B1/1 (FZS6W) 36EIDW-B4/1 (FZS6WC)
Manufacturer	MIKUNI
ID mark	5VX1 03 (FZS6W) 5VX4 12 (FZS6WC)
Throttle valve size	#50

Throttle position sensor

Resistance	4.0–6.0 k Ω
Output voltage (at idle)	0.63–0.73 V Adjusted by tachometer

Idling condition

Engine idling speed	1250–1350 r/min
Intake vacuum	29.0 kPa (8.6 inHg) (218 mmHg)
Water temperature	95.0–105.0 °C (203.00–221.00 °F)
Oil temperature	75.0–85.0 °C (167.00–185.00 °F)
Throttle cable free play	3.0–5.0 mm (0.12–0.20 in)

CHASSIS SPECIFICATIONS

EAS20300

CHASSIS SPECIFICATIONS

Chassis

Frame type	Diamond
Caster angle	25.00 °
Trail	97.5 mm (3.84 in)

Front wheel

Wheel type	Cast wheel
Rim size	17M/C x MT3.50
Rim material	Aluminum
Wheel travel	130.0 mm (5.12 in)
Radial wheel runout limit	1.0 mm (0.04 in)
Lateral wheel runout limit	0.5 mm (0.02 in)

Rear wheel

Wheel type	Cast wheel
Rim size	17M/C x MT5.50
Rim material	Aluminum
Wheel travel	130.0 mm (5.12 in)
Radial wheel runout limit	1.0 mm (0.04 in)
Lateral wheel runout limit	0.5 mm (0.02 in)

Front tire

Type	Tubeless
Size	120/70 ZR17M/C (58W)
Manufacturer/model	BRIDGESTONE/BT020F GG
Manufacturer/model	DUNLOP/D252F
Wear limit (front)	0.8 mm (0.03 in)

Rear tire

Type	Tubeless
Size	180/55 ZR17M/C (73W)
Manufacturer/model	BRIDGESTONE/BT020R GG
Manufacturer/model	DUNLOP/D252
Wear limit (rear)	0.8 mm (0.03 in)

Tire air pressure (measured on cold tires)

Loading condition	0–90 kg (0–198 lb)
Front	225 kPa (33 psi) (2.25 kgf/cm ²) (2.25 bar)
Rear	250 kPa (36 psi) (2.50 kgf/cm ²) (2.50 bar)
Loading condition	90–189 kg (198–417 lb) (FZS6WC)
	90–190 kg (198–419 lb) (FZS6W)
Front	250 kPa (36 psi) (2.50 kgf/cm ²) (2.50 bar)
Rear	290 kPa (42 psi) (2.90 kgf/cm ²) (2.90 bar)
High-speed riding	
Front	225 kPa (33 psi) (2.25 kgf/cm ²) (2.25 bar)
Rear	250 kPa (36 psi) (2.50 kgf/cm ²) (2.50 bar)

Front brake

Type	Dual disc brake
Operation	Right hand operation

CHASSIS SPECIFICATIONS

Front disc brake

Disc outside diameter × thickness	298.0 × 5.0 mm (11.73 × 0.20 in)
Brake disc thickness limit	4.5 mm (0.18 in)
Brake disc deflection limit	0.10 mm (0.0039 in)
Brake pad lining thickness (inner)	4.5 mm (0.18 in)
Limit	0.5 mm (0.02 in)
Brake pad lining thickness (outer)	4.5 mm (0.18 in)
Limit	0.5 mm (0.02 in)
Master cylinder inside diameter	16.00 mm (0.63 in)
Caliper cylinder inside diameter	30.20 mm (1.19 in)
Caliper cylinder inside diameter	27.00 mm (1.06 in)
Recommended fluid	DOT 4

Rear brake

Type	Single disc brake
Operation	Right foot operation
Brake pedal position (below the bottom of the forest bracket)	25.8 mm (1.02 in)

Rear disc brake

Disc outside diameter × thickness	245.0 × 5.0 mm (9.65 × 0.20 in)
Brake disc thickness limit	4.5 mm (0.18 in)
Brake disc deflection limit	0.15 mm (0.0059 in)
Brake pad lining thickness (inner)	6.0 mm (0.24 in)
Limit	1.0 mm (0.04 in)
Brake pad lining thickness (outer)	6.0 mm (0.24 in)
Limit	1.0 mm (0.04 in)
Master cylinder inside diameter	12.7 mm (0.50 in)
Caliper cylinder inside diameter	38.10 mm (1.50 in)
Recommended fluid	DOT 4

Steering

Steering bearing type	Angular bearing
Lock to lock angle (left)	35.0 °
Lock to lock angle (right)	35.0 °

Front suspension

Type	Telescopic fork
Spring/shock absorber type	Coil spring/oil damper
Front fork travel	130.0 mm (5.12 in)
Fork spring free length	354.0 mm (13.94 in)
Limit	347 mm (13.56 in)
Collar length	131.5 mm (5.18 in)
Installed length	347.0 mm (13.66 in)
Spring rate K1	7.40 N/mm (42.25 lb/in) (0.75 kgf/mm)
Spring rate K2	11.80 N/mm (67.38 lb/in) (1.20 kgf/mm)
Spring stroke K1	0.0–70.0 mm (0.00–2.76 in)
Spring stroke K2	70.0–130.0 mm (2.76–5.12 in)
Inner tube outer diameter	43.0 mm (1.69 in)
Inner tube bending limit	0.2 mm (0.01 in)
Optional spring available	No
Recommended oil	Suspension oil 01 or equivalent
Quantity	467.0 cm ³ (15.79 US oz) (16.47 Imp.oz)
Level	134.0 mm (5.28 in)

CHASSIS SPECIFICATIONS

Rear suspension

Type	Swingarm (monocross)
Spring/shock absorber type	Coil spring/gas-oil damper
Rear shock absorber assembly travel	50.0 mm (1.97 in)
Spring free length	185.0 mm (7.28 in)
Installed length	172.0 mm (6.77 in)
Spring rate K1	127.40 N/mm (727.45 lb/in) (12.99 kgf/mm)
Spring stroke K1	0.0–50.0 mm (0.00–1.97 in)
Optional spring available	No
Enclosed gas/air pressure (STD)	1200 kPa (170.7 psi) (12.0 kgf/cm ²)
Spring preload adjusting positions (Minimum)	1
Spring preload adjusting positions (Standard)	3
Spring preload adjusting positions (Maximum)	7
Swingarm radial free play	1.0 mm (0.039 in)
Swingarm axial free play	1.0 mm (0.039 in)

Drive chain

Type/manufacturer	50V4/DAIDO
Link quantity	118
Drive chain slack	45.0–55.0 mm (1.77–2.17 in)
15-link length limit	239.3 mm (9.42 in)

ELECTRICAL SPECIFICATIONS

EAS20310

ELECTRICAL SPECIFICATIONS

Voltage

System voltage 12 V

Ignition system

Ignition system Transistorized coil ignition (digital)
Ignition system type DC. TCI
Advancer type Digital
Ignition timing (B.T.D.C.) 5.0 °/1300 r/min

Engine control unit

Model/manufacture FUA0016/MITSUBISHI (FZS6W)
FUA0017/MITSUBISHI (FZS6WC)

Ignition coil

Model/manufacture JO383/DENSO
Minimum ignition spark gap 6.0 mm (0.24 in)
Primary coil resistance 1.53–2.07 Ω at 20°C (68°F)
Secondary coil resistance 12.0–18.0 k Ω at 20°C (68°F)

Spark plug cap

Material Resin
Resistance 10.0 k Ω

AC magneto

Model/manufacture F5VX/MORIC
Stator coil resistance 0.22–0.34 Ω at 20°C (68°F)
Standard output 14.0 V310 W5000 r/min

Rectifier/regulator

Regulator type Semi conductor-short circuit
Model/manufacture SH719AA/SHINDENGEN
No load regulated voltage 14.1–14.9 V
Rectifier capacity 25.0 A
Withstand voltage 240.0 V

Battery

Model GT12B-4
Voltage, capacity 12 V, 10.0 Ah
Specific gravity 1.320
Manufacturer GYM
Ten hour rate amperage 1.00 A

Headlight

Bulb type Halogen bulb

Bulb voltage, wattage × quantity

Headlight 12 V, 60 W/55W × 1
12 V, 55W × 1
Tail/brake light 12 V, 5.0 W/21W × 1
Front turn signal/position light 12 V, 21 W/5.0 W × 2
Rear turn signal light 12 V, 21W × 2
License plate light 12 V, 5.0 W × 1
Meter lighting LED

ELECTRICAL SPECIFICATIONS

Indicator light

Neutral indicator light	LED
Turn signal indicator light	LED
Oil level warning light	LED
High beam indicator light	LED
Coolant temperature warning light	LED
Engine trouble warning light	LED

Electric starting system

System type	Constant mesh
-------------	---------------

Starter motor

Model/manufacture	SM-14/MITSUBA
Power output	0.60 kW
Armature coil resistance	0.0012–0.0022 Ω
Brush overall length	10.0 mm (0.39 in)
Limit	3.50 mm (0.14 in)
Brush spring force	7.16–9.52 N (25.77–34.27 oz) (730–971 gf)
Commutator diameter	28.0 mm (1.10 in)
Limit	27.0 mm (1.06 in)
Mica undercut (depth)	0.70 mm (0.03 in)

Starter relay

Model/manufacture	MS5F-441/JIDECO
Amperage	180.0 A
Coil resistance	4.18–4.62 Ω at 20°C (68°F)

Horn

Horn type	Plane
Quantity	1 pcs
Model/manufacture	HF-12/NIKKO
Maximum amperage	3.0 A
Coil resistance	1.01–1.11 Ω
Performance	105–118 dB/2m

Turn signal relay

Relay type	Full transistor
Model/manufacture	FE246BH/DENSO
Built-in, self-canceling device	No
Turn signal blinking frequency	75.0–95.0 cycles/min
Wattage	21 W \times 2 + LED

Oil level switch

Model/manufacture	5VX/SOMIC ISHIKAWA
-------------------	--------------------

Fuel gauge

Model/manufacture	5VX/DENSO
Sender unit resistance (full)	19.0–21.0 Ω
Sender unit resistance (empty)	139.0–141.0 Ω

Starting circuit cut-off relay

Model/manufacture	G8R-30Y-V3/OMRON
Coil resistance	162–198 Ω

Radiator fan motor relay

Model/manufacture	ACM33211M05/MATSUSHITA
Coil resistance	86.4–105.6 Ω

Headlight relay

Model/manufacture	ACM33211M05/MATSUSHITA
Coil resistance	86.4–105.6 Ω

ELECTRICAL SPECIFICATIONS

Fuel injection system relay

Model/manufacture	G8R-30Y-R/OMRON
Resistance	162–198 Ω

Thermo unit

Model/manufacture	8CC/MITSUBISHI
Resistance at 80°C	290.0–354.0 Ω

Fuses

Main fuse	30.0 A
Headlight fuse	20.0 A
Taillight fuse	10.0 A
Signaling system fuse	10.0 A
Ignition fuse	10.0 A
Radiator fan fuse	20.0 A
Fuel injection system fuse	10.0 A
Backup fuse	10.0 A
Reserve fuse	30.0 A
Reserve fuse	20.0 A
Reserve fuse	10.0 A


EAS20320

TIGHTENING TORQUES

EAS20330

GENERAL TIGHTENING TORQUE SPECIFICATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.



- A. Distance between flats
- B. Outside thread diameter

A (nut)	B (bolt)	General tightening torques		
		Nm	m·kg	ft·lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94

TIGHTENING TORQUES

EAS20340

ENGINE TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Spark plugs	M10	4	18 Nm (1.8 m·kg, 13 ft·lb)	
Cylinder head bolt	M10	10	See NOTE	
Cylinder head bolt	M6	2	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Camshaft caps bolt	M6	20	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Cylinder head cover bolt	M6	6	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Camshaft cap oil check bolt	M8	1	20 Nm (2.0 m·kg, 14 ft·lb)	
Air indication system reed valve cover bolt	M6	4	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Air cut-off valve stay bolt	M6	1	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Camshaft sprocket bolt	M7	4	20 Nm (2.0 m·kg, 14 ft·lb)	
Connecting rod cap bolt	M7	8	15 Nm (1.5 m·kg, 11 ft·lb) + 120°	
Generator rotor bolt	M12	1	75 Nm (7.5 m·kg, 54 ft·lb)	
Timing chain tensioner bolt	M6	2	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Timing chain tensioner cap bolt	M6	1	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Thermostat cover bolt	M6	2	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Coolant hose joint bolt	M6	2	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Water pump cover bolt	M6	2	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Water pump bolt	M6	2	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Thermo sensor	M12	1	18 Nm (1.8 m·kg, 13 ft·lb)	
Coolant drain bolt	M6	1	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Radiator bolt	M6	2	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Radiator stay and crankcase	M6	1	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Radiator cap stopper bolt	M5	1	5 Nm (0.5 m·kg, 3.6 ft·lb)	
Radiator hose stay bolt	M10	1	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Oil pump cover bolt	M6	3	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Oil pump bolt	M6	3	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Oil pan bolt	M6	12	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Center oil pan bolt	M6	1	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Oil cooler union bolt	M20	1	63 Nm (6.3 m·kg, 46 ft·lb)	
Engine oil drain bolt	M14	1	43 Nm (4.3 m·kg, 31 ft·lb)	
Oil filter union bolt	M20	1	70 Nm (7.0 m·kg, 51 ft·lb)	
Oil filter	M20	1	17 Nm (1.7 m·kg, 12 ft·lb)	
Oil pump chain guide bolt	M6	2	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Oil pipe bolt	M6	2	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Throttle body joint bolt	M6	8	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Air filter case cover	M5	6	1.2 Nm (0.12 m·kg, 0.9 ft·lb)	
Throttle body and throttle body joint	M4	4	3 Nm (0.3 m·kg, 2.2 ft·lb)	
Throttle body and air filter case	M5	4	3 Nm (0.3 m·kg, 2.2 ft·lb)	
Front exhaust pipe nut	M8	8	20 Nm (2.0 m·kg, 14 ft·lb)	
Rear exhaust pipe bolt	M8	1	20 Nm (2.0 m·kg, 14 ft·lb)	

TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Catalyst pipe and catalyst pipe stay bolt	M8	1	20 Nm (2.0 m·kg, 14 ft·lb)	
Muffler joint bolt	M8	1	20 Nm (2.0 m·kg, 14 ft·lb)	See NOTE
Catalyst joint bolt	M8	1	20 Nm (2.0 m·kg, 14 ft·lb)	See NOTE
Exhaust pipe stay bolt	M8	2	20 Nm (2.0 m·kg, 14 ft·lb)	
Catalyst pipe stay bolt	M8	1	20 Nm (2.0 m·kg, 14 ft·lb)	
Muffler stay bolt	M8	2	20 Nm (2.0 m·kg, 14 ft·lb)	
Muffler protector screw	M6	2	9 Nm (0.9 m·kg, 6.5 ft·lb)	
Crankcase bolt (main journal)	M8	10	See NOTE	
Crankcase bolt	M6	2	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Crankcase bolt	M6	12	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Crankcase bolt	M6	1	10 Nm (1.0 m·kg, 7.2 ft·lb)	 
Crankcase bolt	M8	2	24 Nm (2.4 m·kg, 17 ft·lb)	
Generator rotor cover bolt	M6	9	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Clutch cover bolt	M6	7	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Clutch cover bolt	M6	1	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Clutch cable holder bolt	M6	2	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Pickup coil rotor cover bolt	M6	7	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Pickup coil rotor cover bolt	M8	1	15 Nm (1.5 m·kg, 11 ft·lb)	
Shift shaft cover bolt	M6	6	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Breather plate screw	M6	3	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Stator coil screw	M6	3	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Pickup rotor cover clamp screw	M6	1	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Drive sprocket cover bolt	M6	3	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Oil gallery bolt	M16	2	8 Nm (0.8 m·kg, 5.8 ft·lb)	
Generator rotor cover and stator coil lead clamp screw	M6	1	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Breather hose cover bolt	M6	4	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Oil pipe bolt	M6	2	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Crankshaft position sensor bolt	M6	2	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Starter clutch screw	M8	3	32 Nm (3.2 m·kg, 23 ft·lb)	
Starter motor cover bolt	M6	2	3.4 Nm (0.34 m·kg, 2.3 ft·lb)	
Clutch pressure plate screw	M6	6	8 Nm (0.8 m·kg, 5.8 ft·lb)	
Clutch boss nut	M20	1	90 Nm (9.0 m·kg, 65 ft·lb)	Use a lock washer
Drive sprocket nut	M20	1	85 Nm (8.5 m·kg, 61 ft·lb)	Use a lock washer
Transmission bearing housing screw	M6	3	12 Nm (1.2 m·kg, 8.7 ft·lb)	
Shift drum retainer bolt	M6	2	10 Nm (1.0 m·kg, 7.2 ft·lb)	


TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
O ₂ sensor	M18	1	45 Nm (4.5 m·kg, 33 ft·lb)	
Shift shaft spring stopper screw	M8	1	22 Nm (2.2 m·kg, 16 ft·lb)	
Shift rod nut	M6	1	7 Nm (0.7 m·kg, 5.0 ft·lb)	Left thread
Shift rod nut	M6	1	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Shift rod joint	M6	1	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Shift arm bolt	M6	1	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Pickup coil rotor bolt	M8	1	35 Nm (3.5 m·kg, 25 ft·lb)	
Starter motor bolt	M6	2	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Neutral switch	M10	1	20 Nm (2.0 m·kg, 14 ft·lb)	
Oil level switch bolt	M6	2	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Speed sensor bolt	M6	1	10 Nm (1.0 m·kg, 7.2 ft·lb)	


NOTE:

- Cylinder head bolt
 1. First, tighten the bolts to approximately 19 Nm (1.9 m·kg, 14 ft·lb) with a torque wrench following the tightening order.
 2. Retighten the bolts 50 Nm (5.0 m·kg, 36 ft·lb) with a torque wrench.
- Crankcase bolt (main journal)
 1. First, tighten the bolts to approximately 12 Nm (1.2 m·kg, 8.7 ft·lb) with a torque wrench following the tightening order.
 2. Retighten the bolts 25 Nm (2.5 m·kg, 18 ft·lb) with a torque wrench.
 3. Loosen the all bolts one by one following the tightening order and then tighten them to 27 Nm (2.7 m·kg, 20 ft·lb) again.
- Muffler joint bolt
Retighten the bolt at 1000 km (600 ml).
- Catalyst joint bolt
Retighten the bolt at 1000 km (600 ml).

Cylinder head tightening sequence.



Crankcase tightening sequence.



TIGHTENING TORQUES

EAS20350

CHASSIS TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Upper bracket pinch bolt	M8	2	30 Nm (3.0 m·kg, 22 ft·lb)	
Steering stem nut	M22	1	110 Nm (11 m·kg, 80 ft·lb)	
Upper bracket and upper handle-bar holder	M8	4	23 Nm (2.3 m·kg, 17 ft·lb)	
Lower bracket pinch bolt	—	2	30 Nm (3.0 m·kg, 22 ft·lb)	
Lower ring nut	M25	1	18 Nm (1.8 m·kg, 13 ft·lb)	See NOTE
Front fork cap bolt	M35	2	24 Nm (2.4 m·kg, 17 ft·lb)	
Damper rod assembly bolt	M10	2	23 Nm (2.3 m·kg, 17 ft·lb)	
Front wheel axle pinch bolt	M8	1	23 Nm (2.3 m·kg, 17 ft·lb)	
Front brake master cylinder bolt	M6	2	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Front brake master cylinder cap screw	M4	2	2 Nm (0.2 m·kg, 1.4 ft·lb)	
Front brake hose union blot	M10	2	30 Nm (3.0 m·kg, 22 ft·lb)	
Front brake hose holder and front fork	M6	1	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Front cowling stay and frame	M8	2	33 Nm (3.3 m·kg, 24 ft·lb)	
Front cowling bracket and frame	M6	2	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Front fender and front fork	M6	2	6 Nm (0.6 m·kg, 4.3 ft·lb)	
Clutch lever holder pinch bolt	M6	1	11 Nm (1.1 m·kg, 8.0 ft·lb)	
Engine mount bolts (left of front side)	M10	1	55 Nm (5.5 m·kg, 40 ft·lb)	See NOTE
Engine mount bolts (left of rear side)	M10	1	55 Nm (5.5 m·kg, 40 ft·lb)	See NOTE
Engine mount bolts (right of front side)	M10	1	55 Nm (5.5 m·kg, 40 ft·lb)	See NOTE
Engine mount self locking nut (upper)	M10	1	55 Nm (5.5 m·kg, 40 ft·lb)	See NOTE
Engine mount self locking nut (lower)	M10	1	55 Nm (5.5 m·kg, 40 ft·lb)	See NOTE
Pivot shaft and frame	M18	1	120 Nm (12 m·kg, 87 ft·lb)	
Rear shock absorber and frame	M10	1	40 Nm (4.0 m·kg, 29 ft·lb)	
Rear shock absorber and rear arm	M10	1	40 Nm (4.0 m·kg, 29 ft·lb)	
Seal guard and rear arm	M6	2	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Rear fender and rear arm	M6	3	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Rear brake hose holder and rear arm	M6	1	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Fuel tank bracket and frame	M6	2	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Fuel tank bracket and fuel tank	M6	2	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Fuel tank and rear frame	M6	1	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Fuel tank and fuel tank cap	M5	5	6 Nm (0.6 m·kg, 4.3 ft·lb)	
Fuel pump and fuel tank	M5	6	4 Nm (0.4 m·kg, 2.9 ft·lb)	
Ignition coil and battery box	M6	2	7 Nm (0.7 m·kg, 5.0 ft·lb)	

TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Seat lock and frame	M6	2	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Licence plate light screw	M5	2	4 Nm (0.4 m·kg, 2.9 ft·lb)	
Rear reflector bolt	M5	2	4 Nm (0.4 m·kg, 2.9 ft·lb)	
Flap and bracket 6	M6	2	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Bracket 6 and rear frame	M6	2	19 Nm (1.9 m·kg, 14 ft·lb)	
Tail/brake right unit screw	M6	2	3 Nm (0.3 m·kg, 2.2 ft·lb)	
Rear fender cover bolt	M5	4	4 Nm (0.4 m·kg, 2.9 ft·lb)	
Seat handle bolt	M8	4	23 Nm (2.3 m·kg, 17 ft·lb)	
Muffler and rear fender bolt	M6	4	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Side cover bolt	M6	2	10 Nm (1.0 m·kg, 7.2 ft·lb)	
Lean angle sensor bolt	M4	2	2 Nm (0.2 m·kg, 1.4 ft·lb)	
Coolant reserver tank cover bolt	M6	2	4 Nm (0.4 m·kg, 2.9 ft·lb)	
Front wheel axle shaft bolt	M18	1	72 Nm (7.2 m·kg, 52 ft·lb)	
Front brake caliper bolt	M10	4	40 Nm (4.0 m·kg, 29 ft·lb)	
Front brake disc bolt	M6	10	18 Nm (1.8 m·kg, 13 ft·lb)	
Brake caliper bleed screw	M7	3	6 Nm (0.6 m·kg, 4.3 ft·lb)	
Rear wheel axle nut	M24	1	120 Nm (12 m·kg, 87 ft·lb)	
Rear brake disc and rear wheel	M8	5	30 Nm (3.0 m·kg, 22 ft·lb)	
Rear brake caliper bolt front and rear brake caliper bracket	M8	1	27 Nm (2.7 m·kg, 20 ft·lb)	
Rear brake caliper bolt rear and rear brake caliper bracket	M8	1	22 Nm (2.2 m·kg, 16 ft·lb)	
Rear wheel sprocket and rear wheel drive hub	M10	6	100 Nm (10 m·kg, 72 ft·lb)	
Chain adjusting bolt lock nut	M8	2	16 Nm (1.6 m·kg, 12 ft·lb)	
Rear brake hose union bolt	M10	1	30 Nm (3.0 m·kg, 22 ft·lb)	
Sidestand bolt	M10	1	46 Nm (4.6 m·kg, 33 ft·lb)	
Sidestand bracket and frame	M10	2	63 Nm (6.3 m·kg, 46 ft·lb)	
Sidestand switch screw	M5	2	4 Nm (0.4 m·kg, 2.9 ft·lb)	
Footrest bracket and frame	M8	4	30 Nm (3.0 m·kg, 22 ft·lb)	
Rear brake reserver tank and bracket	M6	1	3 Nm (0.3 m·kg, 2.2 ft·lb)	
Rear master cylinder and footrest bracket	M8	2	23 Nm (2.3 m·kg, 17 ft·lb)	
Mainstand bolt	M10	2	73 Nm (7.3 m·kg, 53 ft·lb)	
Upper bracket and canister bracket (FZS6WC)	M6	2	7 Nm (0.7 m·kg, 5.0 ft·lb)	
Canister bolt (FZS6WC)	M6	2	7 Nm (0.7 m·kg, 5.0 ft·lb)	

NOTE:

- Lower ring nut
 1. First, tighten the ring nut to approximately 52 Nm (5.2 m·kg, 38 ft·lb) with a torque wrench, then loosen the ring nut completely.
 2. Retighten the lower ring nut to specification.
- Engine mount bolts and engine mount self locking nut
Refer to "INSTALLING THE ENGINE" on page 5-6.

LUBRICATION POINTS AND LUBRICANT TYPES

EAS20360

LUBRICATION POINTS AND LUBRICANT TYPES

EAS20370

ENGINE

Lubrication point	Lubricant
Oil seal lips	
O-rings	
Bearings and bushes	
Crankshaft pins	
Piston surfaces	
Piston pins	
Connecting rod bolts	
Crankshaft journals	
Camshaft lobes	
Camshaft journals	
Valve stems (intake and exhaust)	
Valve stem ends (intake and exhaust)	
Valve lifter surface	
Piston cooler (O-ring)	
Oil pump rotors (inner and outer)	
Oil pump housing	
Oil strainer	
Clutch (pull rod)	
Starter clutch idle gear inner surface	
Starter clutch assembly	
Primary driven gear	
Transmission gears (wheel and pinion)	
Main axle and drive axle	
Shift drum	
Shift forks and shift fork guide bars	
Shift shaft	
Shift shaft boss	
Cylinder head cover mating surface	Yamaha bond No.1215
Cylinder head cover semicircular	Yamaha bond No.1215
Crankcase mating surface	Yamaha bond No.1215
Generator rotor cover (stator coil assembly lead grommet)	Yamaha bond No.1215
Pickup rotor cover (crankshaft position sensor lead grommet)	Yamaha bond No.1215

LUBRICATION POINTS AND LUBRICANT TYPES

EAS20380

CHASSIS

Lubrication point	Lubricant
Steering bearings and bearing races (upper and lower)	
Front wheel oil seal (right and left)	
Rear wheel oil seal	
Rear wheel drive hub oil seal	
Rear wheel drive hub mating surface	
Rear brake pedal shaft	
Sidestand pivoting point and metal-to-metal moving parts	
Link and sidestand switch contact point	
Throttle grip inner surface	
Brake lever pivoting point and metal-to-metal moving parts	
Clutch lever pivoting point and metal-to-metal moving parts	
Rear shock absorber collar	
Pivot shaft	
Swingarm pivot bearing	
Swingarm head pipe end, oil seal and bush	
Engine mount bolts (rear upper and lower)	
Shift pedal shaft	
Shift shaft joint	
Rear footrest ball and metal-to-metal moving parts	
Main stand metal-to-metal moving parts	

LUBRICATION POINTS AND LUBRICANT TYPES


LUBRICATION SYSTEM CHART AND DIAGRAMS

EAS20390

LUBRICATION SYSTEM CHART AND DIAGRAMS

EAS20400

ENGINE OIL LUBRICATION CHART




LUBRICATION SYSTEM CHART AND DIAGRAMS

1. Oil strainer
2. Oil pump
3. Relief valve
4. Oil filter
5. Oil cooler
6. Main axle
7. Mission cooler
8. Drive axle
9. Main gallery
10. Piston cooler
11. Intake camshaft
12. Exhaust camshaft

LUBRICATION SYSTEM CHART AND DIAGRAMS

EAS20410


LUBRICATION DIAGRAMS



LUBRICATION SYSTEM CHART AND DIAGRAMS

1. Oil level switch
2. Oil cooler
3. Relief valve


LUBRICATION SYSTEM CHART AND DIAGRAMS



LUBRICATION SYSTEM CHART AND DIAGRAMS

1. Oil pump
2. Exhaust camshaft
3. Intake camshaft
4. Oil strainer


LUBRICATION SYSTEM CHART AND DIAGRAMS



LUBRICATION SYSTEM CHART AND DIAGRAMS

1. Oil cooler
2. Oil strainer
3. Oil level switch
4. Oil pump


LUBRICATION SYSTEM CHART AND DIAGRAMS



LUBRICATION SYSTEM CHART AND DIAGRAMS

1. Main axle
2. Oil pump
3. Relief valve


LUBRICATION SYSTEM CHART AND DIAGRAMS



LUBRICATION SYSTEM CHART AND DIAGRAMS

1. Cylinder head
2. Intake camshaft
3. Exhaust camshaft
4. Crankshaft

LUBRICATION SYSTEM CHART AND DIAGRAMS




LUBRICATION SYSTEM CHART AND DIAGRAMS

1. Main axle
2. Drive axle

EAS20420


COOLING SYSTEM DIAGRAMS



COOLING SYSTEM DIAGRAMS

1. Radiator
2. Oil cooler


COOLING SYSTEM DIAGRAMS



COOLING SYSTEM DIAGRAMS

1. Water pump
2. Oil cooler
3. Radiator


COOLING SYSTEM DIAGRAMS



COOLING SYSTEM DIAGRAMS

1. Oil cooler
2. Water pump

COOLING SYSTEM DIAGRAMS




COOLING SYSTEM DIAGRAMS

1. Radiator
2. Thermostat


EAS20430

CABLE ROUTING





1. Left handlebar switch lead
2. Main switch lead
3. Clutch cable
4. Throttle cables
5. Right handlebar switch lead
- A. Clamp the right and left handlebar switch leads and handlebars. Point the tip of the clamp downward in front of the handlebar.
- B. 70–90 mm (2.76–3.54 in)
- C. Clamp the horn lead and main switch lead to the inner tube. Point the binding section to the outside of the vehicle body and cut the tip down to the length of 1 to 5 mm (0.04 to 0.20 in).
- D. Route the horn lead by the headmost side.
- E. 5–25 mm (0.20–0.98 in)
- F. Clamp the horn lead to the inner tube. Point the binding section to the outside of the vehicle body and cut the tip down to the length of 1 to 5 mm (0.04 to 0.20 in).
- G. Pass the throttle cables, wire harness lead, clutch cable, main switch lead and left handlebar switch lead in order through the frame hole from the lower side of the vehicle.
- H. Point the lead, which comes from the terminal, to the front side of the vehicle body. There should be no slack of leads between the band and terminals.
- I. Clamp the brake hose to the inner tube. Point the binding section to the outside of the vehicle body and cut the tip down to the length of 1 to 5 mm (0.04 to 0.20 in).
- J. Pass the throttle cables through the wire guide. Route the right handlebar switch lead by the outside of the wire guide.

CABLE ROUTING




1. Rear brake light switch lead
2. Neutral switch lead
3. Fuel tank breather hose
4. Crankshaft position sensor lead
5. Right handlebar switch lead
6. O₂ sensor lead
7. Bracket
8. Fuel tank drain hose
9. Rear brake reservoir hose
- A. Pass the fuel tank breather hose, fuel tank drain hose and brake light switch lead through the guide of the stay assembly 2.
- B. Clamp the tail/brake light switch lead together with the O₂ sensor lead and the neutral switch lead.
- C. To the starter motor
- D. Install the right handlebar switch lead coupler through the hole of the bracket 2 from the downside.
- E. Route the starter motor lead by the inner side of the air cut-off valve hose.
- F. Pass the ignition coil leads #1 and #4 through inner side of the air cut-off valve hose, and then between the frame and bracket 2.
- G. Pass the right handlebar switch lead through the hole located on the right side of the frame.
- H. Route the right handlebar switch lead under the bracket 2.
- I. Route the coolant reservoir tank hose under the cover 2. Route the radiator hose (outside) outside.
- J. Route the radiator hoses (2 pieces) under the cover 2.
- K. Route the crankshaft position sensor lead inner side of the radiator hose.
- L. Pull down the mark-painted sections of the fuel tank breather hose and fuel tank drain hose to be lower than the clamp position of the muffler stay. Any order to take out the fuel tank breather hose and fuel tank drain hose can be accepted.
- M. 0–20mm (0–0.79 in)
- N. Route the O₂ sensor lead by the outer side of the vehicle as viewed from the rear tail/brake light switch lead.
- O. Clamping position should be at the center of bend-R as shown in the illustration for the rear brake reservoir tank hose.
- P. Pass the fuel tank breather hose, fuel tank drain hose and O₂ sensor lead through the clamp and insert them to the bracket.
- Q. Clamp the O₂ sensor lead to the front side of the vehicle.
- R. Outside of the vehicle.
- S. Attach the clamp so that the opening may be turned to the Outside of the vehicle.

CABLE ROUTING






A-A



B


1. Main switch lead
 2. Stay assembly
 3. Left handlebar switch lead
 4. Clutch cable
 5. Throttle cables
 6. Battery negative lead coupler
 7. Starter relay lead
 8. Battery negative lead
 9. Fuel tank drain hose
 10. Rectifier/regulator
 11. Turn signal relay
 12. Radiator fan motor relay
 13. Starting circuit cut-off relay
 14. Clamp
 15. License plate light lead
 16. Rear right turn signal light lead
 17. Rear left turn signal light lead
 18. Dimmer relay
 19. Speed sensor lead
 20. Sidestand switch lead
 21. Oil level switch lead
 22. AC magneto lead
 23. Front brake hose
 24. Throttle cable (return side)
 25. Throttle cable (pull side)
 26. Radiator fan motor lead
- A. Route the throttle cables above the stay assembly 1.
 - B. Line up the left handlebar switch lead coupler and radiator fan motor lead coupler behind the head pipe.
 - C. Route the clutch cable over the wire harness.
 - D. To the main switch
 - E. Place three couplers on the flange of the cover.
 - F. To the fuel pump
 - G. Clamp four wire leads. There should be no excessive slack on the wire leads.
 - H. To the fuel tank
 - I. Either installation position can be accepted, but make sure that the leads are not crossed.
 - J. Clamp the rear turn signal lead and license plate light lead to the frame. Hook the clamp to the bracket. Pull out the lead sufficiently to the frame side and route it along with the side of the back stay. Cut the tip of the clamp to be between 1 and 5 mm (0.04 and 0.20 in) upward.
 - K. Clamp the rear turn signal light lead and license plate light lead to the frame. Cut the tip of the clamp to be between 1 and 5 mm (0.04 and 0.20 in).
 - L. Gap between the lead and muffler should be 10 mm (0.39 in) or more.
 - M. Coupler should not run on the relay assembly.
 - N. To the tail/brake light
 - O. To the license plate light
 - P. To the rear right turn signal light
 - Q. To the rear left turn signal light
 - R. To the engine
 - S. Route the speed sensor lead behind the starter motor lead
 - T. Point the bend-R section of the throttle cable (pull side) to the inner side horizontally. It is also possible to visually check the bend-R section.
 - U. To the headlight lead
 - V. Clamp the seat lock cable to the frame as shown in the illustration. Secure the clamp to the weld of the cross member with the frame. Position the binding section in front of the vehicle body and cut the tip to be between 1 and 5 mm (0.04 and 0.20 in).
 - W. Point the tip of the clamp to the inner side of the vehicle body.

CABLE ROUTING



1. Right handlebar switch lead
 2. Throttle cables
 3. Battery positive lead
 4. Battery cover
 5. Connector cover
 6. Fuel tank breather hose
 7. Lean angle sensor
 8. Fuse box
 9. Rear right turn signal light lead
 10. License plate light lead
 11. Rear left turn signal light lead
 12. Seat lock cable
 13. Rectifier/regulator
 14. ECU (engine control unit)
 15. Fuel tank drain hose
 16. Cover
 17. Starter relay lead
 18. Battery negative lead
 19. Battery negative lead coupler
 20. Clutch cable
 21. Main switch lead
 22. Cover 2
 23. Air cut-off valve hose
 24. Spark plug lead
- A. Either front or rear side arrangement for the left handlebar switch lead coupler and radiator fan motor coupler can be accepted.
- B. Point the L-shape terminal to the front side of the vehicle.
- C. Hook the starter motor lead to the alternate pawls on the battery cover.
- D. To the crankshaft position sensor.
- E. Route the crankshaft position sensor lead above the starter motor leads.
- F. Clamp the starter motor lead and crankshaft position sensor lead. Point the projected part of the tip to the inner side of the vehicle.
- G. Pass the radiator hose, wire harness and starter motor lead in order through the lower side of the vehicle.
- H. Set the 4 couplers in the connector cover after wiring it.
- I. To the sidestand switch
- J. To the speed sensor
- K. To the AC magneto
- L. To the oil level switch
- M. The flap hole is located at the right side of the vehicle.
- N. To the neutral switch. Place the neutral switch lead coupler under other leads so that it is not seen through the frame openings.
- O. To the tail/brake light switch
- P. To the O₂ sensor
- Q. Clamp the neutral switch lead, tail/brake light lead and O₂ sensor lead. Point the clamp opening to the rear side.
- R. Push the wire harness in the groove of the mud guard.
- S. Point the opening section of the clamp upward.
- T. To the tail/brake light
- U. To the license plate light
- V. To the rear left turn signal light
- W. To the rear right turn signal light
- X. Point the tip of the clamp to the outside of the vehicle.
- Y. Insert the enwinding clamp of the wire harness into the hole of the rear frame.
- Z. Attach the rectifier/regulator lead with the clamp of the regulator bracket.
- AA. To the engine ground.
- AB. To the fuel injection
- AC. To the fuel pump
- AD. Route the clutch cable under the fuel injection lead.
- AE. Pass the clutch cables through the clamp, and then install the clamp to the cover. Position of the clamp is forward of the cable stopper.
- AF. To the main switch
- AG. Place the adjuster of the clutch cable above the cover.
- AH. Route the starter relay lead outside of the main switch lead and pass forward the fuse holder.
- AI. Press the battery negative lead into the space between the ribs of the frame.
- AJ. After connecting the coupler of the connector cover, position it inside.
- AK. Pass the spark plug leads #1 and #4 through the slit of the cover 2.
- AL. Pass the spark plug lead #2 through the inner hole of the cover 2.
- AM. Pass the spark plug lead #3 through the outer hole of the cover 2.
- AN. Route the spark plug lead #4 behind the air cutoff valve hose.
- AO. Point the spark plug caps of #1 to #4 to the direction as shown in the illustration.
- AP. Route the spark plug lead #3 under the air cutoff valve hose.
- AQ. Route the spark plug lead #2 behind the air cutoff valve hose.
- AR. Route the spark plug lead #4 by the front side of the spark plug leads #2 and #3.
- AS. Route the spark plug leads #2 and #3 behind the air cut-off valve hose.


CABLE ROUTING



1. Fuel pump assembly
2. Fuel tank breather hose
3. Fuel tank drain hose
4. Fuel hose
5. Clip
6. Clamp
7. Fuel tank protector
8. Charge hose (FZS6WC)
9. Roll over valve (FZS6WC)
 - A. Air opening.
 - B. Install the O-ring with its lip pointed upward.
 - C. Fuel tank breather hose has a white point mark. (fuel tank breather hose side)
 - D. Point the knob of clip front side
 - a. Fuel piping connector attachment directions. (fuel pump side) Don't use tool.
 1. It is inserted until it makes a click sound the connector, and it checks that a connector does not fall out. It takes care that a foreign substance does not enter into a seal portion. (Working grooves should not be used at the time of work.)
 - E. It prevents that this portion falls out.
 2. The clamp is attached from the bottom after the work of "1". It checks being completely equipped with, "A", "B" and "C" section.

CABLE ROUTING

FZS6WC



1. Clip
 2. Roll over valve assembly
 3. Canister hose
 4. Balance hose
 5. Clamp
 6. Canister assembly
 7. Upper bracket
 8. Hose
 9. Canister bracket
 10. Fuel tank drain hose
 11. Roll over valve hose
- A. Front side
 - B. Point the paint marking upward.
 - C. Pass the canister hose outside, pass the balance hose inside.
 - D. Point the knob of clamp front side. The application of water is possible at the time of attachment.
 - E. Point the knob of clamp upward. The application of water is possible at the time of attachment.
 - F. Pass the balance hose under the canister hose.
 - G. Insert to the back, but the tip of the nipple should not come out from the hose.
 - H. Point the knob of clamp downward.
 - I. Install the part pointing the white paint mark to the front side of the vehicle. The application of water is possible at the time of attachment.
 - J. Clamp the fuel tank drain hose so that the distance between the paint mark and the edge of the clamp may become 430–440 mm (16.9–17.3 in).

PERIODIC CHECKS AND ADJUSTMENTS

PERIODIC MAINTENANCE	3-1
INTRODUCTION	3-1
ENGINE	3-4
ADJUSTING THE VALVE CLEARANCE	3-4
SYNCHRONIZING THE THROTTLE BODIES	3-6
ADJUSTING THE ENGINE IDLING SPEED	3-8
ADJUSTING THE THROTTLE CABLE FREE PLAY	3-8
CHECKING THE SPARK PLUGS.....	3-9
MEASURING THE COMPRESSION PRESSURE	3-10
CHECKING THE ENGINE OIL LEVEL.....	3-12
CHANGING THE ENGINE OIL.....	3-12
MEASURING THE ENGINE OIL PRESSURE	3-13
ADJUSTING THE CLUTCH CABLE FREE PLAY	3-14
CLEANING THE AIR FILTER ELEMENT	3-15
CHECKING THE THROTTLE BODY JOINTS	3-16
CHECKING THE FUEL LINE	3-16
CHECKING THE CRANKCASE BREATHER HOSE.....	3-16
CHECKING THE EXHAUST SYSTEM	3-17
CHECKING THE COOLANT LEVEL	3-17
CHECKING THE COOLING SYSTEM	3-18
CHANGING THE COOLANT	3-18
CHASSIS	3-21
ADJUSTING THE FRONT DISC BRAKE	3-21
ADJUSTING THE REAR DISC BRAKE	3-21
CHECKING THE BRAKE FLUID LEVEL.....	3-22
CHECKING THE FRONT BRAKE PADS.....	3-22
CHECKING THE REAR BRAKE PADS	3-23
CHECKING THE FRONT BRAKE HOSES.....	3-23
CHECKING THE REAR BRAKE HOSE	3-23
ADJUSTING THE REAR BRAKE LIGHT SWITCH	3-23
BLEEDING THE HYDRAULIC BRAKE SYSTEM.....	3-24
ADJUSTING THE SHIFT PEDAL	3-25
ADJUSTING THE DRIVE CHAIN SLACK	3-25
LUBRICATING THE DRIVE CHAIN.....	3-26
CHECKING AND ADJUSTING THE STEERING HEAD	3-26
CHECKING THE FRONT FORK	3-28
ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY.....	3-28
CHECKING THE TIRES	3-28
CHECKING THE WHEELS	3-31
CHECKING AND LUBRICATING THE CABLES	3-31
LUBRICATING THE LEVERS.....	3-31
LUBRICATING THE PEDAL	3-31
LUBRICATING THE SIDESTAND.....	3-31
LUBRICATING THE CENTERSTAND	3-31
LUBRICATING THE REAR SUSPENSION	3-31

ELECTRICAL SYSTEM	3-32
REPLACING THE HEADLIGHT BULBS.....	3-32
ADJUSTING THE HEADLIGHT BEAMS	3-32



PERIODIC MAINTENANCE

EAS20450

PERIODIC MAINTENANCE

EAS20460

INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. If followed, these preventive maintenance procedures will ensure more reliable vehicle operation, a longer service life and reduce the need for costly overhaul work. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

Periodic maintenance chart for the emission control system

NO.	ITEM	ROUTINE	INITIAL	ODOMETER READINGS					
			600 mi (1000 km) or 1 month	4000 mi (7000 km) or 6 months	8000 mi (13000 km) or 12 months	12000 mi (19000 km) or 18 months	16000 mi (25000 km) or 24 months	20000 mi (31000 km) or 30 months	
1	* Fuel line	<ul style="list-style-type: none"> Check fuel hoses for cracks or damage. Replace if necessary. 		√	√	√	√	√	√
2	* Spark plugs	<ul style="list-style-type: none"> Check condition. Adjust gap and clean. Replace every 8000 mi (13000 km) or 12 months. 		√	Replace.	√	Replace.	√	√
3	* Valve clearance	<ul style="list-style-type: none"> Check and adjust valve clearance when engine is cold. 	Every 26600 mi (42000 km)						
4	* Crankcase breather system	<ul style="list-style-type: none"> Check breather hose for cracks or damage. Replace if necessary. 		√	√	√	√	√	√
5	* Fuel injection	<ul style="list-style-type: none"> Check and adjust engine idle speed and synchronization. 	√	√	√	√	√	√	√
6	* Exhaust system	<ul style="list-style-type: none"> Check for leakage. Tighten if necessary. Replace gasket(s) if necessary. 	√	√	√	√	√	√	√
7	* Evaporative emission control system (For California only)	<ul style="list-style-type: none"> Check control system for damage. Replace if necessary. 				√			√
8	* Air induction system	<ul style="list-style-type: none"> Check the air cut-off valve, reed valve, and hose for damage. Replace any damaged parts if necessary. 				√			√

* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.

General maintenance and lubrication chart

NO.	ITEM	ROUTINE	INITIAL	ODOMETER READINGS					
			600 mi (1000 km) or 1 month	4000 mi (7000 km) or 6 months	8000 mi (13000 km) or 12 months	12000 mi (19000 km) or 18 months	16000 mi (25000 km) or 24 months	20000 mi (31000 km) or 30 months	
1	* Air filter element	<ul style="list-style-type: none"> Check condition and damage. Replace if necessary. 		√			√		√
2	* Clutch	<ul style="list-style-type: none"> Check operation. Adjust or replace cable. 	√	√	√	√	√	√	√
3	* Front brake	<ul style="list-style-type: none"> Check operation, fluid level, and for fluid leakage. Replace brake pads if necessary. 	√	√	√	√	√	√	√

PERIODIC MAINTENANCE

NO.	ITEM	ROUTINE	INITIAL	ODOMETER READINGS					
			600 mi (1000 km) or 1 month	4000 mi (7000 km) or 6 months	8000 mi (13000 km) or 12 months	12000 mi (19000 km) or 18 months	16000 mi (25000 km) or 24 months	20000 mi (31000 km) or 30 months	
4	* Rear brake	<ul style="list-style-type: none"> Check operation, fluid level, and for fluid leakage. Replace brake pads if necessary. 	√	√	√	√	√	√	√
5	* Brake hoses	<ul style="list-style-type: none"> Check for cracks or damage. Replace. 		√	√	√	√	√	√
6	* Wheels	<ul style="list-style-type: none"> Check runout and for damage. Replace if necessary. 		√	√	√	√	√	√
7	* Tires	<ul style="list-style-type: none"> Check tread depth and for damage. Replace if necessary. Check air pressure. Correct if necessary. 		√	√	√	√	√	√
8	* Wheel bearings	<ul style="list-style-type: none"> Check bearings for smooth operation. Replace if necessary. 		√	√	√	√	√	√
9	* Swingarm pivot bearings	<ul style="list-style-type: none"> Check bearing assemblies for looseness. Moderately repack with lithium-soap-based grease. 			√			Repack.	
10	Drive chain	<ul style="list-style-type: none"> Check chain slack, alignment and condition. Adjust and lubricate chain with a special O-ring chain lubricant thoroughly. 	Every 500 mi (800 km) and after washing the vehicle or riding in the rain						
11	* Steering bearings	<ul style="list-style-type: none"> Check bearing assemblies for looseness. Moderately repack with lithium-soap-based grease. 	√	√	√	√	√	√	√
12	* Chassis fasteners	<ul style="list-style-type: none"> Check all chassis fitting and fasteners. Correct if necessary. 		√	√	√	√	√	√
13	Brake and clutch lever pivot shafts	<ul style="list-style-type: none"> Apply lithium-soap-based grease (all-purpose grease) lightly. 		√	√	√	√	√	√
14	Brake and shift pedal pivot shafts	<ul style="list-style-type: none"> Apply lithium-soap-based grease (all-purpose grease) lightly. 		√	√	√	√	√	√
15	* Centerstand and sidestand pivots	<ul style="list-style-type: none"> Check operation. Apply lithium-soap-based grease (all-purpose grease) lightly. 		√	√	√	√	√	√
16	* Sidestand switch	<ul style="list-style-type: none"> Check operation and replace if necessary. 	√	√	√	√	√	√	√
17	* Front fork	<ul style="list-style-type: none"> Check operation and for oil leakage. Replace if necessary. 		√	√	√	√	√	√
18	* Shock absorber assembly	<ul style="list-style-type: none"> Check operation and for oil leakage. Replace if necessary. 		√	√	√	√	√	√
19	Engine oil	<ul style="list-style-type: none"> Change (warm engine before draining). 	√	√	√	√	√	√	√
20	* Engine oil filter cartridge	<ul style="list-style-type: none"> Replace. 	√		√			√	

PERIODIC MAINTENANCE

NO.	ITEM	ROUTINE	INITIAL	ODOMETER READINGS					
			600 mi (1000 km) or 1 month	4000 mi (7000 km) or 6 months	8000 mi (13000 km) or 12 months	12000 mi (19000 km) or 18 months	16000 mi (25000 km) or 24 months	20000 mi (31000 km) or 30 months	
21	*	Cooling system	<ul style="list-style-type: none"> • Check hoses for cracks or damage. • Replace if necessary. 		√	√	√	√	√
			<ul style="list-style-type: none"> • Change with ethylene glycol antifreeze coolant every 24 months. 					Change.	
22	*	Front and rear brake switches	<ul style="list-style-type: none"> • Check operation. 	√	√	√	√	√	√
23	*	Control cables	<ul style="list-style-type: none"> • Apply Yamaha chain and cable lube or engine oil SAE 10W-30 thoroughly. 	√	√	√	√	√	√
24	*	Throttle grip housing and cable	<ul style="list-style-type: none"> • Check operation and free play. • Adjust the throttle cable free play if necessary. • Lubricate the throttle grip housing and cable. 		√	√	√	√	√
25	*	Lights, signals and switches	<ul style="list-style-type: none"> • Check operation. • Adjust headlight beam. 	√	√	√	√	√	√

* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.

NOTE: _____

From 24000 mi (37000 km) or 36 months, repeat the maintenance intervals starting from 8000 mi (13000 km) or 12 months.

NOTE: _____

- Air filter
 - This model's air filter is equipped with a disposable oil-coated paper element, which must not be cleaned with compressed air to avoid damaging it.
 - The air filter element needs to be replaced more frequently when riding in unusually wet or dusty areas.
- Hydraulic brake service
 - After disassembling the brake master cylinders and calipers, always change the fluid. Regularly check the brake fluid levels and fill the reservoirs as required.
 - Every two years replace the internal components of the brake master cylinders and calipers, and change the brake fluid.
 - Replace the brake hoses every four years and if cracked or damaged.

EAS20470

ENGINE

EAS20490

ADJUSTING THE VALVE CLEARANCE

The following procedure applies to all of the valves.

NOTE: _____

- Valve clearance adjustment should be made on a cold engine, at room temperature.
- When the valve clearance is to be measured or adjusted, the piston must be at top dead center (TDC) on the compression stroke.

1. Remove:


- Seat
Refer to "GENERAL CHASSIS" on page 4-1.
- Fuel tank
Refer to "FUEL TANK" on page 7-1.
- Battery
Refer to "GENERAL CHASSIS" on page 4-1 and "CHECKING AND CHARGING THE BATTERY" on page 8-68.
- Air filter case
Refer to "GENERAL CHASSIS" on page 4-1.
- Battery box
- Battery box bracket
Refer to "GENERAL CHASSIS" on page 4-1.
- Throttle bodies
Refer to "THROTTLE BODIES" on page 7-4.
- Air cut-off valve
Refer to "AIR INDUCTION SYSTEM" on page 7-9.
- Radiator
- Radiator fan motor
Refer to "RADIATOR" on page 6-1.

2. Remove:

- Ignition coils
- Spark plugs
- Cylinder head cover
- Cylinder head cover gasket
Refer to "CAMSHAFTS" on page 5-8.

3. Remove:

- Pickup rotor cover "1"



4. Measure:

- Valve clearance
Out of specification → Adjust.


	Valve clearance (cold)
	Intake
	0.13–0.20 mm (0.0051–0.0079 in)
	Exhaust
	0.23–0.30 mm (0.0091–0.0118 in)



- a. Turn the crankshaft counterclockwise.
- b. When piston #1 is at TDC on the compression stroke, align the TDC mark "a" on the pickup rotor with the crankcase mating surface "b".

NOTE: _____

TDC on the compression stroke can be found when the camshaft lobes are turned away from each other.





- c. Measure the valve clearance with a thickness gauge "1".


NOTE: _____

- If the valve clearance is incorrect, record the measured reading.
- Measure the valve clearance in the following sequence.

Valve clearance measuring sequence
Cylinder #1 → #2 → #4 → #3



A. Front
d. To measure the valve clearances of the other cylinders, starting with cylinder #1 at TDC, turn the crankshaft counterclockwise as specified in the following table.



B	#1	C			
	#2		C		
	#3				C
	#4			C	

11170401

- A. Degrees that the crankshaft is turned counterclockwise
- B. Cylinder
- C. Combustion cycle

Cylinder #2	180°
Cylinder #4	360°
Cylinder #3	540°

5. Remove:

- Camshafts

NOTE:

- Refer to "CAMSHAFTS" on page 5-8.

- When removing the timing chain and camshafts, fasten the timing chain with a wire to retrieve it if it falls into the crankcase.

6. Adjust:

- Valve clearance




a. Remove the valve lifter "1" and the valve pad "2" with a valve lapper "3".




Valve lapper
90890-04101
Valve lapping tool
YM-A8998

NOTE:

- Cover the timing chain opening with a rag to prevent the valve pad from falling into the crankcase.
- Make a note of the position of each valve lifter "1" and valve pad "2" so that they can be installed in the correct place.



11171102




b. Select the proper valve pad from the following table.

Valve pad range	Nos. 120–240
Valve pad thickness	1.20–2.40 mm (0.0472–0.0945 in)
Available valve pads	25 thicknesses in 0.05 mm (0.002 in) increments

NOTE:

- The thickness "a" of each valve pad is marked in hundredths of millimeters on the side that touches the valve lifter.

- Since valve pads of various sizes are originally installed, the valve pad number must be rounded in order to reach the closest equivalent to the original.



- c. Round off the original valve pad number according to the following table.

Last digit	Rounded value
0 or 2	0
5	5
8	10

EXAMPLE:

Original valve pad number = 148 (thickness = 1.48 mm (0.058 in))


Rounded value = 150

- d. Locate the rounded number of the original valve pad and the measured valve clearance in the valve pad selection table. The point where the column and row intersect is the new valve pad number.

NOTE:

The new valve pad number is only an approximation. The valve clearance must be measured again and the above steps should be repeated if the measurement is still incorrect.

- e. Install the new valve pad "1" and the valve lifter "2".



NOTE:

- Lubricate the valve pad with molybdenum disulfide grease.

- Lubricate the valve lifter with molybdenum disulfide oil.
- The valve lifter must turn smoothly when rotated by hand.
- Install the valve lifter and the valve pad in the correct place.

- f. Install the exhaust and intake camshafts, timing chain and camshaft caps.

	<p>Camshaft cap bolt 10 Nm (1.0 m·kg, 7.2 ft·lb)</p>
--	---

NOTE:

- Refer to "CAMSHAFTS" on page 5-8.
- Lubricate the camshaft bearings, camshaft lobes and camshaft journals.
- First, install the exhaust camshaft.
- Align the camshaft marks with the camshaft cap marks.
- Turn the crankshaft counterclockwise several full turns to seat the parts.

- g. Measure the valve clearance again.

- h. If the valve clearance is still out of specification, repeat all of the valve clearance adjustment steps until the specified clearance is obtained.



7. Install:

- All removed parts

NOTE:

For installation, reverse the removal procedure.

EAS20570

SYNCHRONIZING THE THROTTLE BODIES

NOTE:

Prior to synchronizing the throttle bodies, the valve clearance and the engine idling speed should be properly adjusted and the ignition timing should be checked.

1. Stand the vehicle on a level surface.

NOTE:

Place the vehicle on a suitable stand.

2. Remove:

- Seat
Refer to "GENERAL CHASSIS" on page 4-1.
- Fuel tank
Refer to "FUEL TANK" on page 7-1.



Throttle cable free play
3.0–5.0 mm (0.12–0.20 in)

11. Install:
 - Fuel tank
Refer to "FUEL TANK" on page 7-1.
 - Seat
Refer to "GENERAL CHASSIS" on page 4-1.

EAS20610

ADJUSTING THE ENGINE IDLING SPEED

NOTE:

Prior to adjusting the engine idling speed, the throttle bodies synchronization should be adjusted properly, the air filter element should be clean, and the engine should have adequate compression.

1. Start the engine and let it warm up for several minutes.
2. Check:
 - Engine idling speed
Out of specification → Adjust.




Engine idling speed
1250–1350 r/min

3. Adjust:
 - Engine idling speed



- a. Turn the idle adjusting screw "1" in direction "a" or "b" until the specified engine idling speed is obtained.

Direction "a"
Engine idling speed is increased.
Direction "b"
Engine idling speed is decreased.



4. Adjust:
 - Throttle cable free play
Refer to "ADJUSTING THE THROTTLE CABLE FREE PLAY" on page 3-8.



Throttle cable free play
3.0–5.0 mm (0.12–0.20 in)


EAS20630

ADJUSTING THE THROTTLE CABLE FREE PLAY

NOTE:

Prior to adjusting the throttle cable free play, the engine idling speed and throttle bodies synchronization should be adjusted properly.

1. Check:
 - Throttle cable free play "a"
Out of specification → Adjust.



Throttle cable free play
3.0–5.0 mm (0.12–0.20 in)

2. Remove:
 - Seat
Refer to "GENERAL CHASSIS" on page 4-1.
 - Fuel tank
Refer to "FUEL TANK" on page 7-1.
 - Air filter case
Refer to "GENERAL CHASSIS" on page 4-1.
 - Battery
Refer to "GENERAL CHASSIS" on page 4-1 and "CHECKING AND CHARGING THE BATTERY" on page 8-68.
3. Adjust:
 - Throttle cable free play

NOTE:

When the throttle is opened, the accelerator cable "1" is pulled.



Throttle body side

- a. Loosen the locknut "2" on the decelerator cable.

- b. Turn the adjusting nut "3" in direction "a" or "b" to take up any slack on the decelerator cable.


Direction "a"
Throttle cable free play is increased.

Direction "b"
Throttle cable free play is decreased.

- c. Tighten the locknuts

NOTE:

If the specified throttle cable free play cannot be obtained on the throttle body side of the cable, use the adjusting nut on the handlebar side.




Handlebar side

- a. Loosen the locknut "1".
- b. Turn the adjusting nut "2" in direction "a" or "b" until the specified throttle cable free play is obtained.

Direction "a"
Throttle cable free play is increased.

Direction "b"
Throttle cable free play is decreased.

- c. Tighten the locknut



4. Install:
 - Battery
Refer to "GENERAL CHASSIS" on page 4-1 and "CHECKING AND CHARGING THE BATTERY" on page 8-68.
 - Air filter case
Refer to "GENERAL CHASSIS" on page 4-1.
 - Fuel tank
Refer to "FUEL TANK" on page 7-1.
 - Seat
Refer to "GENERAL CHASSIS" on page 4-1.

EWA4S81001

WARNING


After adjusting the throttle cable free play, start the engine and turn the handlebar to the right and to the left to ensure that this does not cause the engine idling speed to change.



EAS20680

CHECKING THE SPARK PLUGS

The following procedure applies to all of the spark plugs.

1. Remove:
 - Radiator lower bolt "1"
 - Radiator lower hose bracket bolt "2"
 Refer to "RADIATOR" on page 6-1.
2. Disconnect:
 - Spark plug caps
3. Remove:
 - Spark plugs





A. Right side #1, #2 and #3

B. Left side #4

ECA13320

CAUTION:

Before removing the spark plugs, blow away any dirt accumulated in the spark plug wells with compressed air to prevent it from falling into the cylinders.

4. Check:

- Spark plug type
Incorrect → Change.



Manufacturer/model
NGK/CR9EK

5. Check:

- Electrode "1"
Damage/wear → Replace the spark plug.
- Insulator "2"
Abnormal color → Replace the spark plug.
Normal color is medium-to-light tan.

6. Clean:


- Spark plug
(with a spark plug cleaner or wire brush)

7. Measure:

- Spark plug gap "a"
(with a wire thickness gauge)
Out of specification → Regap.



Spark plug gap
0.6–0.7 mm (0.024–0.028 in)



8. Install:

- Spark plugs



Spark plug
18 Nm (1.8 m·kg, 13 ft·lb)

NOTE:

Before installing the spark plug, clean the spark plug and gasket surface.

9. Connect:

- Spark plug caps

10. Install:

- Radiator lower hose bracket bolt
- Radiator lower bolt

Refer to "RADIATOR" on page 6-1.

EAS20710

MEASURING THE COMPRESSION PRESSURE

The following procedure applies to all of the cylinders.

NOTE:

Insufficient compression pressure will result in a loss of performance.

1. Measure:

- Valve clearance
Out of specification → Adjust.
Refer to "ADJUSTING THE VALVE CLEARANCE" on page 3-4.

2. Start the engine, warm it up for several minutes, and then turn it off.

3. Remove:

- Seat
Refer to "GENERAL CHASSIS" on page 4-1.
- Fuel tank
Refer to "FUEL TANK" on page 7-1.
- Air filter case
Refer to "GENERAL CHASSIS" on page 4-1.

- Battery
Refer to "GENERAL CHASSIS" on page 4-1 and "CHECKING AND CHARGING THE BATTERY" on page 8-68.
 - Battery box
 - Battery box bracket
Refer to "GENERAL CHASSIS" on page 4-1.
 - Heat protector plate
 - Cover
 - Ignition coils
4. Disconnect:
 - Spark plug caps
 5. Remove:
 - Spark plugs

ECA13340


CAUTION:

Before removing the spark plugs, use compressed air to blow away any dirt accumulated in the spark plug wells to prevent it from falling into the cylinders.

6. Install:
 - Compression gauge "1"



**Compression gauge
90890-03081
Engine compression tester
YU-33223**



7. Measure:
 - Compression pressure
Out of specification → Refer to steps (c) and (d).



Standard compression pressure (at sea level)
1550 kPa/400 r/min (220.5 psi/400 r/min) (15.5 kgf/cm²/400 r/min)
Minimum–maximum
1300–1650 kPa (184.9–234.7 psi) (13.0–16.5 kgf/cm²)



- a. Set the main switch to "ON".
- b. With the throttle wide open, crank the engine until the reading on the compression gauge stabilizes.

EWA4S81003

WARNING

To prevent sparking, ground all spark plug leads before cranking the engine.

ECA13340

CAUTION:

Before removing the spark plugs, use compressed air to blow away any dirt accumulated in the spark plug wells to prevent it from falling into the cylinders.

NOTE:

The difference in compression pressure between cylinders should not exceed 100 kPa (1 kg/cm², 14 psi).

- c. If the compression pressure is above the maximum specification, check the cylinder head, valve surfaces and piston crown for carbon deposits.
Carbon deposits → Eliminate.
- d. If the compression pressure is below the minimum specification, pour a teaspoonful of engine oil into the spark plug bore and measure again.
Refer to the following table.

Compression pressure (with oil applied into the cylinder)	
Reading	Diagnosis
Higher than without oil	Piston ring(s) wear or damage → Repair.
Same as without oil	Piston, valves, cylinder head gasket or piston possibly defective → Repair.



8. Install:
 - Spark plugs



**Spark plug
18 Nm (1.8 m·kg, 13 ft·lb)**

9. Connect:
 - Spark plug caps
10. Install:
 - Ignition coils
 - Cover

- Heat protector plate
- Battery box bracket
- Battery box
Refer to "GENERAL CHASSIS" on page 4-1.
- Battery
Refer to "GENERAL CHASSIS" on page 4-1 and "CHECKING AND CHARGING THE BATTERY" on page 8-68.
- Air filter case
Refer to "GENERAL CHASSIS" on page 4-1.
- Fuel tank
Refer to "FUEL TANK" on page 7-1.
- Seat
Refer to "GENERAL CHASSIS" on page 4-1.


EAS20730

CHECKING THE ENGINE OIL LEVEL


1. Stand the vehicle on a level surface.

NOTE:

- Place the vehicle on a suitable stand.
 - Make sure the vehicle is upright.
2. Start the engine, warm it up for several minutes, and then turn it off.
 3. Check:
 - Engine oil level
The engine oil level should be between the minimum level mark "a" and maximum level mark "b".
Below the minimum level mark → Add the recommended engine oil to the proper level.



Type
YAMALUBE 4, SAE10W30 or SAE 20W40
Recommended engine oil grade
API service SG type or higher,
JASO standard MA



ECA4S82001

CAUTION:

- Engine oil also lubricates the clutch and the wrong oil types or additives could cause clutch slippage. Therefore, do not add any chemical additives.
- Do not allow foreign materials to enter the crankcase.

NOTE:

Before checking the engine oil level, wait a few minutes until the oil has settled.

4. Start the engine, warm it up for several minutes, and then turn it off.
5. Check the engine oil level again.


NOTE:


Before checking the engine oil level, wait a few minutes until the oil has settled.

EAS20790

CHANGING THE ENGINE OIL

1. Start the engine, warm it up for several minutes, and then turn it off.
2. Place a container under the engine oil drain bolt.
3. Remove:
 - Engine oil filler cap "1"
 - Engine oil drain bolt "2" (along with the gasket)






4. Drain:
 - Engine oil (completely from the crankcase)
5. If the oil filter cartridge is also to be replaced, perform the following procedure.

- a. Remove the oil filter cartridge "1" with an oil filter wrench "2".



Oil filter wrench
90890-01426
YU-38411




- b. Lubricate the O-ring "3" of the new oil filter cartridge with a thin coat of engine oil.


ECA13390

CAUTION:

Make sure the O-ring "3" is positioned correctly in the groove of the oil filter cartridge.



- c. Tighten the new oil filter cartridge to specification with an oil filter wrench.




Oil filter cartridge
17 Nm (1.7 m·kg, 12 ft·lb)

6. Check:

- Engine oil drain bolt gasket **New**

7. Install:

- Engine oil drain bolt (along with the new gasket)



Engine oil drain bolt
43 Nm (4.3 m·kg, 31 ft·lb)

8. Fill:

- Crankcase (with the specified amount of the recommended engine oil)



Engine oil quantity

Total amount

3.40 L (3.59 US qt) (2.99 Imp.qt)

Without oil filter cartridge replacement

2.50 L (2.64 US qt) (2.20 Imp.qt)

With oil filter cartridge replacement

2.80 L (2.96 US qt) (2.46 Imp.qt)

9. Install:

- Engine oil filler cap

10. Start the engine, warm it up for several minutes, and then turn it off.

11. Check:

- Engine (for engine oil leaks)

12. Check:

- Engine oil level
 Refer to "CHECKING THE ENGINE OIL LEVEL" on page 3-12.

EAS20820

MEASURING THE ENGINE OIL PRESSURE

1. Check:

- Engine oil level
 Below the minimum level mark → Add the recommended engine oil to the proper level.

2. Start the engine, warm it up for several minutes, and then turn it off.

ECA13410

CAUTION:


When the engine is cold, the engine oil will have a higher viscosity, causing the engine oil pressure to increase. Therefore, be sure to measure the engine oil pressure after warming up the engine.

- Remove:
 - Oil gallery bolt "1"

EWA12980

WARNING


The engine, muffler and engine oil are extremely hot.



- Install:
 - Oil pressure gauge "1"
 - Adapter "2"



Pressure gauge
 90890-03153
 YU-03153
Oil pressure adapter H
 90890-03139



- Measure:
 - Engine oil pressure (at the following conditions)



Engine oil pressure
 240 kPa (34.1 psi) (2.4 kg/cm²)
Engine speed
 Approx 6,600 r/min
Oil temperature
 75.0–85.0 °C (167.00–185.00 °F)


Out of specification → Adjust.

Engine oil pressure	Possible causes
Below specification	<ul style="list-style-type: none"> Faulty oil pump Clogged oil filter Leaking oil passage Broken or damaged oil seal
Above specification	<ul style="list-style-type: none"> Leaking oil passage Faulty oil filter Oil viscosity too high

- Install:
 - Main gallery bolt "1"



Main gallery bolt
 8 Nm (0.8 m·kg, 5.8 ft·lb)




EAS20870

ADJUSTING THE CLUTCH CABLE FREE PLAY

- Check:
 - Clutch cable free play "a"
 Out of specification → Adjust.



Clutch lever free play
 10.0–15.0 mm (0.39–0.59 in)



2. Adjust:
 - Clutch cable free play

Handlebar side


- a. Turn the adjusting bolt "1" in direction "a" or "b" until the specified clutch cable free play is obtained.

Direction "a"
Clutch cable free play is increased.

Direction "b"
Clutch cable free play is decreased.

NOTE:

If the specified clutch cable free play cannot be obtained on the handlebar side of the cable, use the adjusting nut on the engine side.




Engine side

- a. Loosen the locknuts "1".
- b. Turn the adjusting nut "2" in direction "a" or "b" until the specified clutch cable free play is obtained.

Direction "a"
Clutch cable free play is increased.

Direction "b"
Clutch cable free play is decreased.



- c. Tighten the locknuts.



EAS20950

CLEANING THE AIR FILTER ELEMENT

1. Remove:
 - Seat
Refer to "GENERAL CHASSIS" on page 4-1.
 - Fuel tank
Refer to "FUEL TANK" on page 7-1.
2. Remove:
 - Air filter case cover "1"
 - Air filter element "2"



3. Clean:
 - Air filter element
(with solvent)
4. Check:
 - Air filter element
Damage → Replace.
5. Install:
 - Air filter element
 - Air filter case cover

ECA4S81008

CAUTION:

Never operate the engine without the air filter element installed. Unfiltered air will cause rapid wear of engine parts and may damage the engine. Operating the engine without the air filter element will also affect throttle bodies synchronization, leading to poor engine performance and possible overheating.

NOTE:

When installing the air filter element into the air filter case cover, make sure their sealing surfaces are aligned to prevent any air leaks.


6. Install:
 - Fuel tank
Refer to "FUEL TANK" on page 7-1.
 - Seat
Refer to "GENERAL CHASSIS" on page 4-1.

EAS21010

CHECKING THE THROTTLE BODY JOINTS

The following procedure applies to all of the throttle body joints and intake manifolds.

1. Remove:
 - Throttle bodies
Refer to "THROTTLE BODIES" on page 7-4.
2. Check:
 - Throttle body joints "1"
Cracks/damage → Replace.



3. Install:
 - Throttle bodies
Refer to "THROTTLE BODIES" on page 7-4.

EAS21030

CHECKING THE FUEL LINE

The following procedure applies to all of the fuel, vacuum and breather hoses.

1. Remove:
 - Seat

Refer to "GENERAL CHASSIS" on page 4-1.

- Fuel tank
Refer to "FUEL TANK" on page 7-1.
2. Check:
 - Breather hose "1"
 - Fuel hose "2"
Cracks/damage → Replace.
Loose connection → Connect properly.


NOTE:

- Before removing the fuel hose, place a few rags in the area under where it will be removed.
- There is a white mark on the fuel tank breather hose.
Refer to "CABLE ROUTING" on page 2-47.

ECA14940

CAUTION:

Make sure the fuel tank breather hose is routed correctly.



3. Install:
 - Fuel tank
Refer to "FUEL TANK" on page 7-1.
 - Seat
Refer to "GENERAL CHASSIS" on page 4-1.

EAS21070


CHECKING THE CRANKCASE BREATHER HOSE

1. Remove:
 - Seat
Refer to "GENERAL CHASSIS" on page 4-1.
 - Fuel tank
Refer to "FUEL TANK" on page 7-1.
2. Check:
 - Crankcase breather hose "1"
Cracks/damage → Replace.
Loose connection → Connect properly.

ECA13450

CAUTION:

Make sure the crankcase breather hose is routed correctly.




3. Install:
 - Fuel tank
Refer to "FUEL TANK" on page 7-1.
 - Seat
Refer to "GENERAL CHASSIS" on page 4-1.

EAS21080


CHECKING THE EXHAUST SYSTEM

The following procedure applies to all of the exhaust pipes and gaskets.

1. Remove:
 - Radiator
Refer to "RADIATOR" on page 6-1.
2. Check:
 - Exhaust pipe "1"
 - Catalytic converter pipe "2"
 - Muffler "3"
 - Cracks/damage → Replace.
 - Gasket "4"
 - Exhaust gas leaks → Replace.
3. Check:
 - Tightening torque
 - Exhaust pipe nut "5"
 - Catalytic converter joint bolt "6"
 - Muffler joint bolt "7"
 - Muffler stay bolt "8"
 - Exhaust pipe stay bolt "9"
 - Catalytic converter pipe stay bolt "10"



- Exhaust pipe nut**
20 Nm (2.0 m·kg, 15 ft·lb)
- Catalytic converter joint bolt**
20 Nm (2.0 m·kg, 15 ft·lb)
- Muffler joint bolt**
20 Nm (2.0 m·kg, 15 ft·lb)
- Muffler stay bolt**
20 Nm (2.0 m·kg, 15 ft·lb)
- Exhaust pipe stay bolt**
20 Nm (2.0 m·kg, 15 ft·lb)
- Catalytic converter pipe stay bolt**
20 Nm (2.0 m·kg, 15 ft·lb)



4. Install:
 - Radiator
Refer to "RADIATOR" on page 6-1.

EAS21110

CHECKING THE COOLANT LEVEL

1. Stand the vehicle on a level surface.

NOTE:


- Place the vehicle on a suitable stand.
- Make sure the vehicle is upright.

2. Check:
 - Coolant level
The coolant level should be between the maximum level mark "a" and minimum level mark "b".
Below the minimum level mark → Add the recommended coolant to the proper level.

ECA13470

CAUTION:

- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant check, and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, if distilled water is not available, soft water may be used.



3. Start the engine, warm it up for several minutes, and then turn it off.
4. Check:
 - Coolant level


NOTE:

Before checking the coolant level, wait a few minutes until it settles.

EAS21120

CHECKING THE COOLING SYSTEM


1. Check:
 - Radiator "1"
 - Radiator inlet hose "2"
 - Radiator outlet hose "3"
 - Oil cooler "4"
 - Oil cooler inlet hose "5"
 - Oil cooler outlet hose "6"
 - Water jacket joint "7"
 - Water jacket joint hose "8"
 - Oil cooler inlet pipe "9"
 - Water pump outlet hose "10"
 Cracks/damage → Replace.
 Refer to "RADIATOR" on page 6-1.



EAS21130


CHANGING THE COOLANT

1. Remove:
 - Coolant reservoir "1"
 - Coolant reservoir cap "2"



2. Drain:
 - Coolant
(from the coolant reservoir)

3. Remove:
 - Radiator cap lock bolt "1"
 - Radiator cap "2"




EWA13030

⚠ WARNING


A hot radiator is under pressure. Therefore, do not remove the radiator cap when the engine is hot. Scalding hot fluid and steam may be blown out, which could cause serious injury. When the engine has cooled, open the radiator cap as follows: Place a thick rag or a towel over the radiator cap and slowly turn the radiator cap counterclockwise toward the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the radiator cap and turn it counterclockwise to remove.

The following procedure applies to all of the coolant drain bolts and copper washers.


4. Remove:
 - Coolant drain bolt (water pump) "1" (along with the copper washer)



5. Drain:
 - Coolant (from the engine and radiator)
6. Check:
 - Copper washer "1" **New**
7. Install:
 - Coolant drain bolt (water pump) "2"



**Coolant drain bolt (water pump)
10 Nm (1.0 m·kg, 7.2 ft·lb)**



8. Install:
 - Coolant reservoir
9. Fill:
 - Cooling system (with the specified amount of the recommended coolant)



Recommended antifreeze
High-quality ethylene glycol antifreeze containing corrosion inhibitors for aluminum engines

Mixing ratio

1:1 (antifreeze:water)

Radiator capacity (including all routes)

2.00 L (2.11 US qt) (1.76 Imp.qt)

Coolant reservoir capacity (up to the maximum level mark)

0.25 L (0.26 US qt) (0.22 Imp.qt)

Handling notes for coolant
Coolant is potentially harmful and should be handled with special care.

EWA13040

⚠ WARNING

- If coolant splashes in your eyes, thoroughly wash them with water and consult a doctor.
- If coolant splashes on your clothes, quickly wash it away with water and then with soap and water.
- If coolant is swallowed, induce vomiting and get immediate medical attention.

ECA13480

CAUTION:


- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant check, and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, if distilled water is not available, soft water may be used.
- If coolant comes into contact with painted surfaces, immediately wash them with water.
- Do not mix different types of antifreeze.

10. Install:

- Radiator cap

11. Fill:

- Coolant reservoir
(with the recommended coolant to the maximum level mark "a")



12. Install:

- Coolant reservoir cap

13. Start the engine, warm it up for several minutes, and then stop it.

14. Check:

- Coolant level
Refer to "CHECKING THE COOLANT LEVEL" on page 3-17.

NOTE:

Before checking the coolant level, wait a few minutes until the coolant has settled.

EAS21140

CHASSIS

EAS21160

ADJUSTING THE FRONT DISC BRAKE

1. Adjust:

- Brake lever position
(distance “a” from the throttle grip to the brake lever)

NOTE:


- While pushing the brake lever forward, turn the adjusting dial “1” until the brake lever is in the desired position.
- Be sure to align the setting on the adjusting dial with the arrow mark “2” on the brake lever holder.

Position #1

Distance “a” is the largest.

Position #5

Distance “a” is the smallest.



EWA13060

WARNING

- After adjusting the brake lever position, make sure the pin on the brake lever holder is firmly inserted in the hole in the adjusting dial.
- A soft or spongy feeling in the brake lever can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will considerably reduce in loss of control and possibly an accident. Therefore, check and if necessary, bleed the brake system.

ECA13490

CAUTION:

After adjusting the brake lever position, make sure there is no brake drag.

EAS21190


ADJUSTING THE REAR DISC BRAKE

1. Check:

- Brake pedal position
(distance “a” from the top of the rider footrest to the top of the brake pedal)
Out of specification → Adjust.



**Brake pedal position (below the top of the rider footrest)
25.8 mm (1.02 in)**



2. Adjust:

- Brake pedal position



- Loosen the locknut “1”.
- Turn the adjusting bolt “2” in direction “a” or “b” until the specified brake pedal position is obtained.

Direction “a”

Brake pedal is raised.


Direction “b”

Brake pedal is lowered.

EWA13070

WARNING

After adjusting the brake pedal position, check that the end of the adjusting bolt “c” is visible through the hole “d”.



- Tighten the locknut “1” to specification.



Locknut
18 Nm (1.8 m·kg, 13 ft·lb)

EWA4S81005

WARNING

A soft or spongy feeling in the brake pedal can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will considerably reduce braking performance.

ECA13510

CAUTION:

After adjusting the brake pedal position, make sure there is no brake drag.



3. Adjust:
 - Rear brake light switch
Refer to "ADJUSTING THE REAR BRAKE LIGHT SWITCH" on page 3-23.

EAS21240

CHECKING THE BRAKE FLUID LEVEL

1. Stand the vehicle on a level surface.

NOTE:

- Place the vehicle on a suitable stand.
- Make sure the vehicle is upright.


2. Check:

- Brake fluid level
Below the minimum level mark "a" → Add the recommended brake fluid to the proper level.




Recommended fluid
DOT 4

A



B



- A. Front brake
- B. Rear brake

EWA13090

WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540

CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

NOTE:


In order to ensure a correct reading of the brake fluid level, make sure the top of the brake fluid reservoir is horizontal.

EAS21250

CHECKING THE FRONT BRAKE PADS

The following procedure applies to all of the brake pads.

1. Operate the brake.
2. Check:
 - Front brake pad
Wear indicators "a" almost touch the brake disc → Replace the brake pads as a set. Refer to "FRONT BRAKE" on page 4-15.




I2220404

EAS21260

CHECKING THE REAR BRAKE PADS

The following procedure applies to all of the brake pads.

1. Operate the brake.
2. Check:
 - Rear brake pad
Wear indicators "b" almost touch the brake disc → Replace the brake pads as a set. Refer to "REAR BRAKE" on page 4-27.




EAS21280

CHECKING THE FRONT BRAKE HOSES

The following procedure applies to all of the brake hoses and brake hose clamps.

1. Check:
 - Brake hose
Cracks/damage/wear → Replace.




2. Check:
 - Brake hose clamp
Loose → Tighten the clamp bolt.
3. Hold the vehicle upright and apply the brake several times.
4. Check:
 - Brake hose
Brake fluid leakage → Replace the damaged hose. Refer to "FRONT BRAKE" on page 4-15.

EAS21290

CHECKING THE REAR BRAKE HOSE

1. Check:
 - Brake hose
Cracks/damage/wear → Replace.



2. Check:
 - Brake hose clamp
Loose Connection → Tighten the clamp bolt.
3. Hold the vehicle upright and apply the rear brake several times.
4. Check:
 - Brake hose
Brake fluid leakage → Replace the damaged hose. Refer to "REAR BRAKE" on page 4-27.

EAS21330

ADJUSTING THE REAR BRAKE LIGHT SWITCH

NOTE:

The rear brake light switch is operated by movement of the brake pedal. The rear brake light switch is properly adjusted when the brake light comes on just before the braking effect starts.


1. Check:
 - Rear brake light operation timing
Incorrect → Adjust.
2. Adjust:
 - Rear brake light operation timing



- a. Hold the main body "1" of the rear brake light switch so that it does not rotate and turn the adjusting nut "2" in direction "a" or "b" until the rear brake light comes on at the proper time.

Direction "a"
Brake light comes on sooner.

Direction "b"
Brake light comes on later.



EAS21340

BLEEDING THE HYDRAULIC BRAKE SYSTEM

EWA13100

WARNING

Bleed the hydraulic brake system whenever:

- the system is disassembled.
- a brake hose is loosened, disconnected or replaced.
- the brake fluid level is very low.
- brake operation is faulty.

NOTE:



- Be careful not to spill any brake fluid or allow the brake master cylinder reservoir or brake fluid reservoir to overflow.
- When bleeding the hydraulic brake system, make sure there is always enough brake fluid before applying the brake. Ignoring this precaution could allow air to enter the hydraulic brake system, considerably lengthening the bleeding procedure.
- If bleeding is difficult, it may be necessary to let the brake fluid settle for a few hours. Repeat the bleeding procedure when the tiny bubbles in the hose have disappeared.

1. Bleed:

- Hydraulic brake system



- a. Fill the brake fluid reservoir to the proper level with the recommended brake fluid.
- b. Install the diaphragm (brake master cylinder reservoir or brake fluid reservoir).
- c. Connect a clear plastic hose "1" tightly to the bleed screw "2".



A. Front

B. Rear

- d. Place the other end of the hose into a container.
- e. Slowly apply the brake lever several times.
- f. Fully pull the brake lever or fully press down the brake pedal and hold it in position.
- g. Loosen the bleed screw.

NOTE:

Loosening the bleed screw will release the pressure and cause the brake lever to contact the throttle grip or the brake pedal to fully extend.

- h. Tighten the bleed screw and then release the brake lever or brake pedal.
- i. Repeat steps (e) to (h) until all of the air bubbles have disappeared from the brake fluid in the plastic hose.
- j. Tighten the bleed screw to specification.

	<p>Bleed screw 6 Nm (0.6 m·kg, 4.3 ft·lb)</p>
---	--

- k. Fill the brake fluid reservoir to the proper level with the recommended brake fluid. Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-22.

EWA13110

WARNING

After bleeding the hydraulic brake system, check the brake operation.




EAS21370

ADJUSTING THE SHIFT PEDAL

1. Check:
 - Shift pedal position

Align the center of shift pedal "1" and center of footrest bracket bolt "2" in a straight line.


Incorrect → Adjust.



2. Adjust:
 - Shift pedal position
- a. Loosen both locknuts "1".
 - b. Turn the shift rod "2" in direction "a" or "b" to obtain the correct shift pedal position.

Direction "a"
Shift pedal is raised.

Direction "b"
Shift pedal is lowered.



- c. Tighten both locknuts.



EAS21390

ADJUSTING THE DRIVE CHAIN SLACK

NOTE:
The drive chain slack must be checked at the tightest point on the chain.

ECA13550

CAUTION:

A drive chain that is too tight will overload the engine and other vital parts, and one that is too loose can skip and damage the swingarm or cause an accident. Therefore, keep the drive chain slack within the specified limits.

1. Stand the vehicle on a level surface.

EWA13120


WARNING

Securely support the vehicle so that there is no danger of it falling over.

NOTE:
Place the vehicle on a suitable stand so that the rear wheel is elevated.

2. Spin the rear wheel several times and find the tightest position of drive chain.
3. Check:
 - Drive chain slack "a"

Out of specification → Adjust.




Drive chain slack
45.0–55.0 mm (1.77–2.17 in)

4. Adjust:
 - Drive chain slack
- a. Loosen the wheel axle nut "1".
 - b. Loosen both locknuts "2".
 - c. Turn both adjusting nuts "3" in direction "a" or "b" until the specified drive chain slack is obtained.

Direction “a”
 Drive chain is tightened.
Direction “b”
 Drive chain is loosened.

NOTE:
 To maintain the proper wheel alignment, adjust both sides evenly.



d. Tighten both locknuts to specification.

	Locknut 16 Nm (1.6 m·kg, 12 ft·lb)
--	--

e. Tighten the wheel axle nut to specification.

	Wheel axle nut 120 Nm (12 m·kg, 87 ft·lb)
--	---

EAS21440
LUBRICATING THE DRIVE CHAIN

The drive chain consists of many interacting parts. If the drive chain is not maintained properly, it will wear out quickly. Therefore, the drive chain should be serviced, especially when the vehicle is used in dusty areas.

This vehicle has a drive chain with small rubber O-rings between each side plate. Steam cleaning, high-pressure washing, certain solvents, and the use of a coarse brush can damage these O-rings. Therefore, use only kerosene to clean the drive chain. Wipe the drive chain dry and thoroughly lubricate it with engine oil or chain lubricant that is suitable for O-ring chains. Do not use any other lubricants on the drive chain since they may contain solvents that could damage the O-rings.

	Recommended lubricant Engine oil or chain lubricant suitable for O-ring chains
--	--

EAS21500
CHECKING AND ADJUSTING THE STEERING HEAD

1. Stand the vehicle on a level surface.

EWA13120


WARNING

Securely support the vehicle so that there is no danger of it falling over.

NOTE:
 Place the vehicle on a suitable stand so that the front wheel is elevated.

2. Check:
 - Steering head
 Grasp the bottom of the front fork legs and gently rock the front fork.
 Binding/looseness → Adjust the steering head.
3. Remove:
 - Upper bracket
 Refer to "STEERING HEAD" on page 4-51.
4. Adjust:
 - Steering head

a. Remove the lock washer “1”, the upper ring nut “2”, and the rubber washer “3”.



b. Tighten the lower ring nut “4” with a steering nut wrench “5”.

NOTE:
 Set the torque wrench at a right angle to the steering nut wrench.

	Steering nut wrench 90890-01403 Spanner wrench YU-33975
--	--

	Lower ring nut (initial tightening torque) 52 Nm (5.2 m·kg, 38 ft·lb)
--	---

- c. Loosen the lower ring nut "4" completely and then tighten it to specification with a steering nut wrench.

EWA13140




WARNING

Do not overtighten the lower ring nut.




**Lower ring nut (final tightening torque)
18 Nm (1.8 m·kg, 13 ft·lb)**



- d. Check the steering head for looseness or binding by turning the front fork all the way in both directions. If any binding is felt, remove the lower bracket and check the upper and lower bearings. Refer to "STEERING HEAD" on page 4-51.
- e. Install the rubber washer "2".
- f. Install the upper ring nut "3".
- g. Finger tighten the upper ring nut "3", then align the slots of both ring nuts. If necessary, hold the lower ring nut and tighten the upper ring nut until their slots are aligned.
- h. Install the lock washer "1".

NOTE:

Make sure the lock washer tabs "a" sit correctly in the ring nut slots "b".



5. Install:

- Upper bracket
Refer to "STEERING HEAD" on page 4-51.

6. Measure:


- Steering head tension



NOTE:

Make sure all of the cables and wires are properly routed.

- a. Point the front wheel straight ahead.
- b. Install a plastic locking tie "1" loosely around the end of the handlebar as shown.
- c. Hook a spring gauge "2" onto the plastic locking tie.



- d. Hold the spring gauge at a 90° angle from the handlebar, pull the spring gauge, and then record the measurement when the handlebar starts to run.



**Steering head tension
200–500g**

- e. Repeat the above procedure on the opposite handlebar.
- f. If the steering head tension is out of specification (both handlebars should be within specification), remove the upper bracket and loosen or tighten the upper ring nut.
- g. Reinstall the upper bracket and measure the steering head tension again as described above.
- h. Repeat the above procedure until the steering head tension is within specification.
- i. Grasp the bottom of the front fork legs and gently rock the front fork.
Binding/looseness → Adjust the steering head.



EAS21530

CHECKING THE FRONT FORK

1. Stand the vehicle on a level surface.


EWA13120



Securely support the vehicle so that there is no danger of it falling over.

2. Check:


- Inner tube "1"
Damage/scratches → Replace.
- Oil seal "2"
Oil leakage → Replace.



3. Hold the vehicle upright and apply the front brake.

4. Check:

- Front fork operation
Push down hard on the handlebar several times and check if the front fork rebounds smoothly.
Rough movement → Repair.
Refer to "FRONT FORK" on page 4-43.



EAS21590

ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY

EWA13120



Securely support the vehicle so that there is no danger of it falling over.

Spring preload

ECA13590

CAUTION:

Never go beyond the maximum or minimum adjustment positions.

1. Adjust:
 - Spring preload

- a. Adjust the spring preload with the special wrench and extension bar included in the owner's tool kit.
- b. Turn the adjusting ring "1" in direction "a" or "b".
- c. Align the desired position on the adjusting ring with the stopper "2".

Direction "a"

Spring preload is increased (suspension is harder).

Direction "b"

Spring preload is decreased (suspension is softer).



Spring preload adjusting positions

Minimum


1

Standard

3

Maximum

7




EAS21650

CHECKING THE TIRES

The following procedure applies to both of the tires.

1. Check:
 - Tire pressure
Out of specification → Regulate.



EWA13180

⚠ WARNING

- The tire pressure should only be checked and regulated when the tire temperature equals the ambient air temperature.
- The tire pressure and the suspension must be adjusted according to the total weight (including cargo, rider, passenger and accessories) and the anticipated riding speed.
- Operation of an overloaded vehicle could cause tire damage, an accident or an injury.

NEVER OVERLOAD THE VEHICLE.



Tire air pressure (measured on cold tires)

Loading condition*

0–90 kg (0–198 lb)

Front

225 kPa (33 psi) (2.25 kgf/cm²)
(2.25 bar)

Rear

250 kPa (36 psi) (2.50 kgf/cm²)
(2.50 bar)

Loading condition*

90–189 kg (198–417 lb)
(FZS6WC)

90–190 kg (198–419 lb)
(FZS6W)

Front

250 kPa (36 psi) (2.50 kgf/cm²)
(2.50 bar)

Rear

290 kPa (42 psi) (2.90 kgf/cm²)
(2.90 bar)

High-speed riding

Front

225 kPa (33 psi) (2.25 kgf/cm²)
(2.25 bar)

Rear

250 kPa (36 psi) (2.50 kgf/cm²)
(2.50 bar)

Maximum load*

189 kg (417 lb) (FZS6WC)

190 kg (419 lb) (FZS6W)

* Total weight of rider, passenger, cargo and accessories


EWA13190

⚠ WARNING

It is dangerous to ride with a worn-out tire. When the tire tread reaches the wear limit, replace the tire immediately.

2. Check:

- Tire surfaces
Damage/wear → Replace the tire.



1. Tire tread depth
2. Side wall
3. Wear indicator




Wear limit (front)
0.8 mm (0.03 in)
Wear limit (rear)
0.8 mm (0.03 in)

EWA14080


WARNING

- Do not use a tubeless tire on a wheel designed only for tube tires to avoid tire failure and personal injury from sudden deflation.
- When using a tube tire, be sure to install the correct tube.
- Always replace a new tube tire and a new tube as a set.
- To avoid pinching the tube, make sure the wheel rim band and tube are centered in the wheel groove.
- Patching a punctured tube is not recommended. If it is absolutely necessary to do so, use great care and replace the tube as soon as possible with a good quality replacement.

A



- A. Tire
- B. Wheel



Tube wheel	Tube tire only
Tubeless wheel	Tube or tubeless tire

EWA14090

WARNING

After extensive tests, the tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. The front and rear tires should always be by the same manufacturer and of the same design. No guarantee concerning handling characteristics can be given if a tire combination other than one approved by Yamaha is used on this vehicle.



Front tire

Size
120/70 ZR17M/C (58W)
Manufacturer/model
BRIDGESTONE/BT020F GG
Manufacturer/model
DUNLOP/D252F



Rear tire

Size
180/55 ZR17M/C (73W)
Manufacturer/model
BRIDGESTONE/BT020R GG
Manufacturer/model
DUNLOP/D252

EWA13210


WARNING

New tires have a relatively low grip on the road surface until they have been slightly worn. Therefore, approximately 100 km should be traveled at normal speed before any high-speed riding is done.

NOTE:

For tires with a direction of rotation mark "1":

- Install the tire with the mark pointing in the direction of wheel rotation.
- Align the mark "2" with the valve installation point.



EAS21670

CHECKING THE WHEELS

The following procedure applies to both of the wheels.

1. Check:
 - Wheel
Damage/out-of-round → Replace.

EWA13260



WARNING

Never attempt to make any repairs to the wheel.

NOTE:

After a tire or wheel has been changed or replaced, always balance the wheel.

EAS21690

CHECKING AND LUBRICATING THE CABLES

The following procedure applies to all of the inner and outer cables.

EWA13270



WARNING

Damaged outer cable may cause the cable to corrode and interfere with its movement. Replace damaged outer cable and inner cables as soon as possible.

1. Check:
 - Outer cable
Damage → Replace.
2. Check:
 - Cable operation
Rough movement → Lubricate.



Recommended lubricant
Engine oil or a suitable cable lubricant

NOTE:

Hold the cable end upright and pour a few drops of lubricant into the cable sheath or use a suitable lubricating device.

EAS21700

LUBRICATING THE LEVERS

Lubricate the pivoting point and metal-to-metal moving parts of the levers.



Recommended lubricant
Lithium-soap-based grease

EAS21710

LUBRICATING THE PEDAL

Lubricate the pivoting point and metal-to-metal moving parts of the pedal.



Recommended lubricant
Lithium-soap-based grease

EAS21720

LUBRICATING THE SIDESTAND

Lubricate the pivoting point and metal-to-metal moving parts of the sidestand.



Recommended lubricant
Lithium-soap-based grease

EAS21730

LUBRICATING THE CENTERSTAND

Lubricate the pivoting point and metal-to-metal moving parts of the centerstand.




Recommended lubricant
Lithium-soap-based grease

EAS21740

LUBRICATING THE REAR SUSPENSION

Lubricate the pivoting point and metal-to-metal moving parts of the rear suspension.



Recommended lubricant
Molybdenum disulfide grease

CHASSIS

GENERAL CHASSIS	4-1
FRONT WHEEL	4-5
REMOVING THE FRONT WHEEL.....	4-7
CHECKING THE FRONT WHEEL.....	4-7
ADJUSTING THE FRONT WHEEL STATIC BALANCE.....	4-8
INSTALLING THE FRONT WHEEL.....	4-9
REAR WHEEL	4-10
REMOVING THE REAR WHEEL.....	4-13
CHECKING THE REAR WHEEL.....	4-13
CHECKING THE REAR WHEEL DRIVE HUB.....	4-13
CHECKING AND REPLACING THE REAR WHEEL SPROCKET.....	4-14
ADJUSTING THE REAR WHEEL STATIC BALANCE.....	4-14
INSTALLING THE REAR WHEEL.....	4-14
FRONT BRAKE	4-15
INTRODUCTION.....	4-20
CHECKING THE FRONT BRAKE DISCS.....	4-20
REPLACING THE FRONT BRAKE PADS.....	4-21
REMOVING THE FRONT BRAKE CALIPERS.....	4-22
DISASSEMBLING THE FRONT BRAKE CALIPERS.....	4-22
CHECKING THE FRONT BRAKE CALIPERS.....	4-22
ASSEMBLING THE FRONT BRAKE CALIPERS.....	4-23
INSTALLING THE FRONT BRAKE CALIPERS.....	4-23
REMOVING THE FRONT BRAKE MASTER CYLINDER.....	4-24
CHECKING THE FRONT BRAKE MASTER CYLINDER.....	4-24
ASSEMBLING THE FRONT BRAKE MASTER CYLINDER.....	4-25
INSTALLING THE FRONT BRAKE MASTER CYLINDER.....	4-25
REAR BRAKE	4-27
INTRODUCTION.....	4-32
CHECKING THE REAR BRAKE DISC.....	4-32
REPLACING THE REAR BRAKE PADS.....	4-32
REMOVING THE REAR BRAKE CALIPER.....	4-33
DISASSEMBLING THE REAR BRAKE CALIPER.....	4-33
CHECKING THE REAR BRAKE CALIPER.....	4-34
ASSEMBLING THE REAR BRAKE CALIPER.....	4-34
INSTALLING THE REAR BRAKE CALIPER.....	4-35
REMOVING THE REAR BRAKE MASTER CYLINDER.....	4-36
CHECKING THE REAR BRAKE MASTER CYLINDER.....	4-36
ASSEMBLING THE REAR BRAKE MASTER CYLINDER.....	4-37
INSTALLING THE REAR BRAKE MASTER CYLINDER.....	4-37
HANDLEBAR	4-39
REMOVING THE HANDLEBARS.....	4-40
CHECKING THE HANDLEBAR.....	4-40


INSTALLING THE HANDLEBAR	4-40
FRONT FORK	4-43
REMOVING THE FRONT FORK LEGS	4-45
DISASSEMBLING THE FRONT FORK LEGS	4-45
CHECKING THE FRONT FORK LEGS	4-46
ASSEMBLING THE FRONT FORK LEGS	4-47
INSTALLING THE FRONT FORK LEGS	4-49
STEERING HEAD	4-51
REMOVING THE LOWER BRACKET	4-53
CHECKING THE STEERING HEAD	4-53
INSTALLING THE STEERING HEAD	4-54
REAR SHOCK ABSORBER ASSEMBLY	4-55
HANDLING THE REAR SHOCK ABSORBER	4-56
DISPOSING OF A REAR SHOCK ABSORBER	4-56
REMOVING THE REAR SHOCK ABSORBER ASSEMBLY	4-56
CHECKING THE REAR SHOCK ABSORBER ASSEMBLY	4-56
INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY	4-57
SWINGARM	4-58
REMOVING THE SWINGARM	4-60
CHECKING THE SWINGARM	4-60
INSTALLING THE SWINGARM	4-61
CHAIN DRIVE	4-62
REMOVING THE DRIVE CHAIN	4-63
CHECKING THE DRIVE CHAIN	4-63
CHECKING THE DRIVE SPROCKET	4-64
CHECKING THE REAR WHEEL SPROCKET	4-64
CHECKING THE REAR WHEEL DRIVE HUB	4-64
INSTALLING THE DRIVE CHAIN	4-64



EAS21830


GENERAL CHASSIS

Removing the seat




Order	Job/Parts to remove	Q'ty	Remarks
1	Seat	1	
			For installation, reverse the removal procedure.

Removing the cowlings




Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
1	Left front cowling inner panel (with cowling)	1	
2	Right front cowling inner panel (with cowling)	1	
3	Front turn signal light coupler	2	Disconnect.
4	Front cowling	1	
5	Front cowling inner panel (center)	1	
6	Rear view mirrors	2	
7	Windshield	1	
8	Side cover	2	
9	Rear cowling	1	
			For installation, reverse the removal procedure.

Removing the air filter case and battery



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Left front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Right front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
1	Intake air temperature sensor coupler	1	Disconnect.
2	Throttle body hose	2	Disconnect.
3	Air induction system hose	1	Disconnect.
4	Clamp	4	Loosen.
5	Crankcase breather hose	1	Disconnect.
6	Starter relay	1	
7	Battery negative lead	1	Disconnect.
8	Battery positive lead	1	Disconnect.
9	Battery cover	1	
10	Battery	1	
11	Air filter case	1	
			For installation, reverse the removal procedure.

Removing the battery box




Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Left front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Right front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Battery		Refer to "GENERAL CHASSIS" on page 4-1.
	Air filter case		Refer to "GENERAL CHASSIS" on page 4-1.
1	Battery box	1	
2	Battery box bracket	3	
3	Ignition coil	2	
			For installation, reverse the removal procedure.

EAS21880


FRONT WHEEL

Removing the front wheel and brake discs




Order	Job/Parts to remove	Q'ty	Remarks
1	Brake hose holder	1	
2	Reflector stay	2	
3	Reflector	2	
4	Front brake caliper	2	
5	Front wheel axle pinch bolt	1	Loosen.
6	Front wheel axle	1	
7	Collar	2	
8	Front wheel	1	
9	Front brake disc	2	
			For installation, reverse the removal procedure.


Disassembling the front wheel



Order	Job/Parts to remove	Q'ty	Remarks
1	Oil seal	2	
2	Wheel bearing	2	
3	Spacer	1	
			For assembly, reverse the disassembly procedure.



- c. Remove the wheel bearings “3” with a general bearing puller.



- d. Install the new wheel bearings and oil seals in the reverse order of disassembly.


ECA14130

CAUTION:

Do not contact the wheel bearing inner race “4” or balls “5”. Contact should be made only with the outer race “6”.

NOTE:

Use a socket “7” that matches the diameter of the wheel bearing outer race and oil seal.



EAS21970

ADJUSTING THE FRONT WHEEL STATIC BALANCE

NOTE:

- After replacing the tire, wheel or both, the front wheel static balance should be adjusted.

- Adjust the front wheel static balance with the brake disc installed.


1. Remove:
 - Balancing weight(s)
2. Find:
 - Front wheel’s heavy spot

NOTE:


Place the front wheel on a suitable balancing stand.



- a. Spin the front wheel.
- b. When the front wheel stops, put an “X₁” mark at the bottom of the wheel.



- c. Turn the front wheel 90° so that the “X₁” mark is positioned as shown.
- d. Release the front wheel.
- e. When the wheel stops, put an “X₂” mark at the bottom of the wheel.




- f. Repeat steps (d) through (f) several times until all the marks come to rest at the same spot.
- g. The spot where all the marks come to rest is the front wheel’s heavy spot “X”.



3. Adjust:
 - Front wheel static balance




- a. Install a balancing weight “1” onto the rim exactly opposite the heavy spot “X”.



NOTE: _____
Start with the lightest weight.

- b. Turn the front wheel 90° so that the heavy spot is positioned as shown.




- c. If the heavy spot does not stay in that position, install a heavier weight.
d. Repeat steps (b) and (c) until the front wheel is balanced.



4. Check:
• Front wheel static balance



- a. Turn the front wheel and make sure it stays at each position shown.



- b. If the front wheel does not remain stationary at all of the positions, rebalance it.



EAS22000

INSTALLING THE FRONT WHEEL


The following procedure applies to both of the brake discs.

- Lubricate:
 - Wheel axle
 - Oil seal lips

	Recommended lubricant Lithium-soap-based grease
---	--

- Install:
 - Coller
 - Wheel axle

NOTE: _____
Install the tire and wheel with the mark "1" pointing in the direction of wheel rotation.



- Tighten:
 - Wheel axle

	Wheel axle nut 72 Nm (7.2 m·kg, 52 ft·lb)
---	--

- Wheel axle pinch bolt

	Wheel axle pinch bolt 19 Nm (1.9 m·kg, 14 ft·lb)
---	---

ECA14140

CAUTION:

Before tightening the wheel axle nut, push down hard on the handlebar(s) several times and check if the front fork rebounds smoothly.

- Install:
 - Brake calipers

	Front brake caliper bolt 40 Nm (4.0 m·kg, 29 ft·lb)
---	--

EWA13490


WARNING

Make sure the brake cable is routed properly.

EAS22030


REAR WHEEL

Removing the rear wheel



Order	Job/Parts to remove	Q'ty	Remarks
1	Rear brake caliper	1	
2	Locknut	2	Loosen.
3	Adjusting nut	2	Loosen.
4	Rear wheel axle nut	1	
5	Washer	1	
6	Rear wheel axle	1	
7	Washer	1	
8	Drive chain puller	2	
9	Rear wheel	1	
10	Rear brake caliper bracket	1	
			For installation, reverse the removal procedure.


Removing the rear brake disc and rear wheel sprocket



Order	Job/Parts to remove	Q'ty	Remarks
1	Rear brake disc	1	
2	Rear wheel sprocket	1	
3	Collar	2	
4	Oil seal	2	
5	Bearing	2	
6	Rear wheel drive hub	1	
7	Rear wheel drive hub damper	6	
8	Rear wheel	1	
			For installation, reverse the removal procedure.

REAR WHEEL

Disassembling the rear wheel



Order	Job/Parts to remove	Q'ty	Remarks
1	Collar	1	
2	Bearing	1	
3	Spacer	1	
4	Oil seal	1	
5	Circlip	1	
6	Bearing	1	
			For assembly, reverse the disassembly procedure.

EAS22040

REMOVING THE REAR WHEEL

1. Stand the vehicle on a level surface.

EWA13120



WARNING


Securely support the vehicle so that there is no danger of it falling over.

NOTE:

Place the vehicle on a suitable stand so that the rear wheel is elevated.

2. Remove:

- Brake caliper "1"



NOTE:


Do not depress the brake pedal when removing the brake caliper.

3. Loosen:

- Locknut "1"
- Adjusting nut "2"

4. Remove:

- Wheel axle nut "3"
- Wheel axle "4"
- Washers
- Rear wheel




NOTE:

Push the rear wheel forward and remove the drive chain from the rear wheel sprocket.

5. Remove:

- Left collar "1"

- Rear wheel drive hub "2"
- Rear wheel drive hub damper
- Right collar



EAS22090

CHECKING THE REAR WHEEL

1. Check:

- Wheel axle
- Rear wheel
- Wheel bearings
- Oil seals

Refer to "CHECKING THE FRONT WHEEL" on page 4-7.

2. Check:

- Tire
- Rear wheel

Damage/wear → Replace.

Refer to "CHECKING THE TIRES" on page 3-28 and "CHECKING THE WHEELS" on page 3-31.

3. Measure:

- Radial wheel runout
- Lateral wheel runout


Refer to "CHECKING THE FRONT WHEEL" on page 4-7.

EAS22110

CHECKING THE REAR WHEEL DRIVE HUB

1. Check:


- Rear wheel drive hub "1"
- Cracks/damage → Replace.
- Rear wheel drive hub dampers "2"
- Damage/wear → Replace.



EAS22120

CHECKING AND REPLACING THE REAR WHEEL SPROCKET

1. Check:
 - Rear wheel sprocket
More than 1/4 tooth "a" wear → Replace the rear wheel sprocket.
Bent teeth → Replace the rear wheel sprocket.



- b. Correct
 1. Drive chain roller
 2. Rear wheel sprocket
2. Replace:
 - Rear wheel sprocket




- a. Remove the self-locking nuts and the rear wheel sprocket.
- b. Clean the rear wheel drive hub with a clean cloth, especially the surfaces that contact the sprocket.
- c. Install the new rear wheel sprocket.



Rear wheel sprocket self-locking nut
100 Nm (10.0 m·kg, 72 ft·lb)

NOTE:

Tighten the self-locking nuts in stages and in a crisscross pattern.



EAS22150

ADJUSTING THE REAR WHEEL STATIC BALANCE

NOTE:

- After replacing the tire, wheel or both, the rear wheel static balance should be adjusted.
- Adjust the rear wheel static balance with the brake disc and rear wheel drive hub installed.

1. Adjust:
 - Rear wheel static balance
Refer to "ADJUSTING THE FRONT WHEEL STATIC BALANCE" on page 4-8.

EAS22160

INSTALLING THE REAR WHEEL

1. Lubricate:
 - Wheel axle
 - Wheel bearings
 - Oil seal lips




Recommended lubricant
Lithium-soap-based grease

2. Install:
 - Collars
 - Rear brake caliper bracket
 - Rear wheel
 - Washer
 - Rear wheel axle
3. Adjust:
 - Drive chain slack
Refer to "ADJUSTING THE DRIVE CHAIN SLACK" on page 3-25.



Drive chain slack
45.0–55.0 mm (1.77–2.17 in)

4. Tighten:
 - Wheel axle nut
 - Rear brake caliper bolts




Wheel axle nut
120 Nm (12 m·kg, 87 ft·lb)
Rear brake caliper bolt (front side)
27 Nm (2.7 m·kg, 20 ft·lb)
Rear brake caliper bolt (rear side)
22 Nm (2.2 m·kg, 16 ft·lb)

EAS22210


FRONT BRAKE

Removing the front brake pads




Order	Job/Parts to remove	Q'ty	Remarks
1	Brake hose holder	1	
2	Reflector stay	1	
3	Reflector	1	
4	Front brake caliper	1	
5	Brake pad clip	2	
6	Brake pad pin	1	
7	Brake pad spring	1	
8	Brake pad	2	
9	Bleed screw	1	
			For installation, reverse the removal procedure.

Removing the front brake master cylinder



Order	Job/Parts to remove	Q'ty	Remarks
	Brake fluid		Drain. Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.
1	Brake master cylinder reservoir cap	1	
2	Brake master cylinder reservoir diaphragm holder	1	
3	Brake master cylinder reservoir diaphragm	1	
4	Brake lever	1	
5	Front brake light switch lead coupler	1	Disconnect.
6	Front brake light switch	1	
7	Union bolt	1	
8	Copper washer	2	
9	Front brake master cylinder holder	1	
10	Front brake master cylinder	1	
			For installation, reverse the removal procedure.


Disassembling the front brake master cylinder



Order	Job/Parts to remove	Q'ty	Remarks
1	Dust boot	1	
2	Circlip	1	
3	Master cylinder kit	1	
4	Spring	1	
5	Master cylinder	1	
6	Push rod	1	
			For assembly, reverse the disassembly procedure.

FRONT BRAKE


Removing the front brake calipers



Order	Job/Parts to remove	Q'ty	Remarks
	Brake fluid		Drain. Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.
1	Union bolt	2	
2	Copper washer	5	
3	Brake hose	2	
4	Reflector stay	1	
5	Reflector	1	
6	Brake caliper	1	
			For installation, reverse the removal procedure.

FRONT BRAKE

Disassembling the front brake calipers



Order	Job/Parts to remove	Q'ty	Remarks
1	Brake pad clip	2	
2	Brake pad pin	1	
3	Brake pad spring	1	
4	Brake pad	2	
5	Brake caliper piston	4	
6	Brake caliper piston seal	8	
7	Bleed screw	1	
			For assembly, reverse the disassembly procedure.

EAS22220

INTRODUCTION

EWA14100

WARNING

Disc brake components rarely require disassembly. Therefore, always follow these preventive measures:


- Never disassemble brake components unless absolutely necessary.
- If any connection on the hydraulic brake system is disconnected, the entire brake system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.
- Never use solvents on internal brake components.
- Use only clean or new brake fluid for cleaning brake components.
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.
- Avoid brake fluid coming into contact with the eyes as it can cause serious injury.
- **FIRST AID FOR BRAKE FLUID ENTERING THE EYES:**
- Flush with water for 15 minutes and get immediate medical attention.

EAS22240

CHECKING THE FRONT BRAKE DISCS

The following procedure applies to both brake discs.

1. Check:
 - Brake disc
Damage/galling → Replace.
2. Measure:
 - Brake disc deflection
Out of specification → Correct the brake disc deflection or replace the brake disc.




Brake disc deflection limit
0.10 mm (0.0039 in)



- a. Place the vehicle on a suitable stand so that the front wheel is elevated.
- b. Before measuring the front brake disc deflection, turn the handlebar to the left or right to ensure that the front wheel is stationary.
- c. Remove the brake caliper.
- d. Hold the dial gauge at a right angle against the brake disc surface.
- e. Measure the deflection 2–3 mm (0.0787–0.1181 in) below the edge of the brake disc.



3. Measure:
 - Brake disc thickness
Measure the brake disc thickness at a few different locations.
Out of specification → Replace.



Brake disc thickness limit
4.5 mm (0.18 in)


4. Adjust:
 - Brake disc deflection



- a. Remove the brake disc.
- b. Rotate the brake disc by one bolt hole.
- c. Install the brake disc.

NOTE:

Tighten the brake disc bolts in stages and in a crisscross pattern.





Brake disc bolt
18 Nm (1.8 m·kg, 13 ft·lb)
LOCTITE®

- d. Measure the brake disc deflection.
- e. If out of specification, repeat the adjustment steps until the brake disc deflection is within specification.
- f. If the brake disc deflection cannot be brought within specification, replace the brake disc.



EAS22270

REPLACING THE FRONT BRAKE PADS

The following procedure applies to both brake calipers.


NOTE:

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.

1. Measure:
 - Brake pad wear limit "a"
 Out of specification → Replace the brake pads as a set.



Brake pad lining thickness (inner)
4.5 mm (0.18 in)
Limit
0.5 mm (0.02 in)
Brake pad lining thickness (outer)
4.5 mm (0.18 in)
Limit
0.5 mm (0.02 in)



12220404


2. Install:
 - Brake pads
 - Brake pad spring

NOTE:


Always install new brake pads and a brake pad spring as a set.



- a. Connect a clear plastic hose "1" tightly to the bleed screw "2". Put the other end of the hose into an open container.



- b. Loosen the bleed screw and push the brake caliper pistons into the brake caliper with your finger.
- c. Tighten the bleed screw.




Bleed screw
6 Nm (0.6 m·kg, 4.3 ft·lb)


- d. Install new brake pads and a new brake pad spring.

NOTE:

The arrow mark "b" on the brake pad spring must point in the direction of disc rotation.




3. Install:
 - Brake pad pins
 - Brake pad clips
 - Brake caliper



Brake caliper bolt
40 Nm (4.0 m·kg, 29 ft·lb)

4. Check:
 - Brake fluid level

Below the minimum level mark "c" → Add the recommended brake fluid to the proper level.
Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-22.



5. Check:
 - Brake lever operation
Soft or spongy feeling → Bleed the brake system.
Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.

EAS22300


REMOVING THE FRONT BRAKE CALIPERS

The following procedure applies to both of the brake calipers.

NOTE:

Before removing the brake caliper, drain the brake fluid from the entire brake system.

1. Remove:
 - Union bolt "1"
 - Copper washers "2"
 - Brake hose "3"
 - Brake caliper



NOTE:

Put the end of the brake hose into a container and pump out the brake fluid carefully.


EAS22360

DISASSEMBLING THE FRONT BRAKE CALIPERS

The following procedure applies to both of the brake calipers.

1. Remove:

- Brake caliper pistons "1"
- Brake caliper piston seals "2"




- a. Secure the brake caliper pistons with a piece of wood "a".
- b. Blow compressed air into the brake hose joint opening "b" to force out the left side pistons from the brake caliper.

EWA13570

WARNING

- Cover the brake caliper piston with a rag. BE careful not to get injured when the pistons are expelled from the brake caliper.
- Never try to pry out the brake caliper pistons.
- Do not loosen the bolts "3".



- c. Remove the brake caliper piston seals.
- d. Repeat the previous steps to force out the right side pistons from the brake caliper.

EAS22390

CHECKING THE FRONT BRAKE CALIPERS


Recommended brake component replacement schedule

Brake pads	If necessary
Piston seals	Every two years
Brake hoses	Every four years

Recommended brake component replacement schedule

Brake fluid	Every two years and whenever the brake is disassembled
-------------	--

- Check:
 - Brake caliper pistons "1"
Rust/scratches/wear → Replace the brake caliper pistons.
 - Brake caliper cylinders "2"
Scratches/wear → Replace the brake caliper assembly.
 - Brake caliper body "3"
Cracks/damage → Replace the brake caliper assembly.
 - Brake fluid delivery passages (brake caliper body)
Obstruction → Blow out with compressed air.



EWA13600

WARNING

Whenever a brake caliper is disassembled, replace the piston seals.

EAS22410

ASSEMBLING THE FRONT BRAKE CALI-PERS

EWA13620

WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components as they will cause the piston seals to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston seals.



Recommended fluid
DOT 4

- Install:
 - Brake caliper seals **New**
 - Brake caliper pistons

EAS22440

INSTALLING THE FRONT BRAKE CALI-PERS

The following procedure applies to both of the brake calipers.

- Install:
 - Brake caliper "1"
(temporarily)
 - Copper washers **New**
 - Brake hose "2"
 - Union bolt "3"



Brake hose union bolt
30 Nm (3.0 m·kg, 22 ft·lb)

EWA13530


WARNING

Proper brake hose routing is essential to insure safe vehicle operation. Refer to "CABLE ROUTING" on page 2-47.

ECA14170

CAUTION:

When installing the brake hose onto the brake caliper "1", make sure the brake pipe "a" touches the projection "b" on the brake caliper.



- Fill:
 - Brake master cylinder reservoir (with the specified amount of the recommended brake fluid)



Recommended fluid
DOT 4

EWA13090

WARNING


- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540

CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

3. Bleed:
 - Brake system
Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.
4. Check:
 - Brake fluid level
Below the minimum level mark "c" → Add the recommended brake fluid to the proper level.
Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-22.



5. Check:
 - Brake lever operation
Soft or spongy feeling → Bleed the brake system.
Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.

EAS22490

REMOVING THE FRONT BRAKE MASTER CYLINDER


NOTE:

Before removing the front brake master cylinder, drain the brake fluid from the entire brake system.

1. Disconnect:
 - Brake switch coupler (from the brake switch)
2. Remove:
 - Union bolt "1"
 - Copper washers "2"
 - Brake hoses "3"

NOTE:

To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.




3. Remove:
 - Brake lever
 - Brake master cylinder holder
 - Brake master cylinder


EAS22500

CHECKING THE FRONT BRAKE MASTER CYLINDER


1. Check:
 - Brake master cylinder "1"
Damage/scratches/wear → Replace.
 - Brake fluid delivery passages (brake master cylinder body)
Obstruction → Blow out with compressed air.



2. Check:
- Brake master cylinder kit “1”
Damage/scratches/wear → Replace.



3. Check:
- Brake master cylinder reservoir “1”
Cracks/damage → Replace.
 - Brake master cylinder reservoir diaphragm “2”
Damage/wear → Replace.



4. Check:
- Brake hoses
Cracks/damage/wear → Replace.

EAS22520

ASSEMBLING THE FRONT BRAKE MASTER CYLINDER

EWA13520

! WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.




Recommended fluid
DOT 4

1. Install:
- Master cylinder kit
 - Circlip **New**

EAS22530

INSTALLING THE FRONT BRAKE MASTER CYLINDER


1. Install:
- Brake master cylinder “1”



Brake master cylinder holder bolt
10 Nm (1.0 m·kg, 7.2 ft·lb)

NOTE:

- Install the brake master cylinder holder with the “UP” mark facing up.
- Align the end of the brake master cylinder holder with the punch mark “a” on the handlebar.
- First, tighten the upper bolt, then the lower bolt.



2. Install:
- Copper washers “1” **New**
 - Brake hose “2”
 - Union bolt “3”



Brake hose union bolt
30 Nm (3.0 m·kg, 22 ft·lb)

EWA13530


! WARNING

Proper brake hose routing is essential to insure safe vehicle operation. Refer to “CABLE ROUTING” on page 2-47.

ECA4S81013

CAUTION:

When installing the brake hose onto the brake master cylinder, make sure that the brake pipe touches the projection “b” on the brake master cylinder.



NOTE:

- While holding the brake hose, tighten the union bolt as shown.
- Turn the handlebar to the left and right to make sure the brake hose does not touch other parts (e.g., wire harness, cables, leads). Correct if necessary.

3. Fill:

- Brake master cylinder reservoir (with the specified amount of the recommended brake fluid)



**Recommended fluid
DOT 4**

EWA13540

WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540

CAUTION:


Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

4. Bleed:

- Brake system
Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.

5. Check:

- Brake fluid level
Below the minimum level mark “c” → Add the recommended brake fluid to the proper level.
Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-22.




6. Check:

- Brake lever operation
Soft or spongy feeling → Bleed the brake system.
Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.

EAS22550


REAR BRAKE

Removing the rear brake pads




Order	Job/Parts to remove	Q'ty	Remarks
1	Screw plug	1	
2	Brake pad pin	1	
3	Rear brake caliper	1	
4	Brake pad shim	4	
5	Brake pad	2	
6	Brake screw	1	
7	Brake pad spring	1	
			For installation, reverse the removal procedure.

Removing the rear brake master cylinder




Order	Job/Parts to remove	Q'ty	Remarks
	Brake fluid		Drain. Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.
1	Brake fluid reservoir cap	1	
2	Rear brake fluid reservoir diaphragm holder	1	
3	Rear brake fluid reservoir diaphragm	1	
4	Brake fluid reservoir	1	
5	Brake fluid reservoir hose	1	
6	Union bolt	1	
7	Copper washer	1	
8	Brake hose	1	
9	Rear brake master cylinder	1	
			For installation, reverse the removal procedure.

Disassembling the rear brake master cylinder




Order	Job/Parts to remove	Q'ty	Remarks
1	Dust boot	1	
2	Circlip	1	
3	Brake master cylinder kit	1	
4	Spring	1	
5	Brake master cylinder body	1	
			For installation, reverse the removal procedure.

Removing the rear brake caliper



Order	Job/Parts to remove	Q'ty	Remarks
	Brake fluid		Drain. Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.
1	Union bolt	1	
2	Copper washer	2	
3	Brake hose	1	
4	Rear brake caliper	1	
			For installation, reverse the removal procedure.

Disassembling the rear brake caliper



Order	Job/Parts to remove	Q'ty	Remarks
1	Screw plug	1	
2	Brake pad pin	1	
3	Brake pad	2	
4	Brake pad shim	4	
5	Brake pad spring	1	
6	Brake caliper piston	1	
7	Brake caliper piston seal	2	
8	Bleed screw	1	
			For assembly, reverse the disassembly procedure.

EAS22560

INTRODUCTION

EWA14100



WARNING

Disc brake components rarely require disassembly. Therefore, always follow these preventive measures:

- Never disassemble brake components unless absolutely necessary.
- If any connection on the hydraulic brake system is disconnected, the entire brake system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.
- Never use solvents on internal brake components.
- Use only clean or new brake fluid for cleaning brake components.
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.
- Avoid brake fluid coming into contact with the eyes as it can cause serious injury.
- **FIRST AID FOR BRAKE FLUID ENTERING THE EYES:**
- Flush with water for 15 minutes and get immediate medical attention.

EAS22570

CHECKING THE REAR BRAKE DISC

1. Check:
 - Brake disc
Damage/galling → Replace.
2. Measure:
 - Brake disc deflection
Out of specification → Correct the brake disc deflection or replace the brake disc. Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-20.




Brake disc deflection limit
0.15 mm (0.0059 in)

3. Measure:
 - Brake disc thickness
Measure the brake disc thickness at a few different locations.
Out of specification → Replace.
Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-20.



Brake disc thickness limit
4.5 mm (0.18 in)

4. Adjust:
 - Brake disc deflection
Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-20.



Brake disc bolt
30 Nm (3.0 m·kg, 22 ft·lb)
LOCTITE®

EAS22580

REPLACING THE REAR BRAKE PADS


NOTE:

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.

1. Measure:
 - Brake pad wear limit "a"
Out of specification → Replace the brake pads as a set.



Brake pad lining thickness (inner)
6.0 mm (0.24 in)
Limit
1.0 mm (0.04 in)
Brake pad lining thickness (outer)
6.0 mm (0.24 in)
Limit
1.0 mm (0.04 in)




2. Install:
 - Brake pad spring
 - Brake pad shims (onto the brake pads)
 - Brake pads

NOTE:

Always install new brake pads, brake pad shims, and a brake pad spring as a set.



- a. Connect a clear plastic hose "1" tightly to the bleed screw "2". Put the other end of the hose into an open container.




a. Blow compressed air into the brake hose joint opening “a” to force out the piston from the brake caliper.

EWA13550

⚠ WARNING

- Cover the brake caliper piston with a rag. Be careful not to get injured when the piston is expelled from the brake caliper.
- Never try to pry out the brake caliper piston.



b. Remove the brake caliper piston seals.

EAS22640


CHECKING THE REAR BRAKE CALIPER

Recommended brake component replacement schedule	
Brake pads	If necessary
Piston seals	Every two years
Brake hoses	Every four years
Brake fluid	Every two years and whenever the brake is disassembled

1. Check:
 - Brake caliper pistons “1”
Rust/scratches/wear → Replace the brake caliper pistons.
 - Brake caliper cylinders “2”

Scratches/wear → Replace the brake caliper assembly.

- Brake caliper body “3”
Cracks/damage → Replace the brake caliper assembly.
- Brake fluid delivery passages (brake caliper body)
Obstruction → Blow out with compressed air.




EWA13610

⚠ WARNING

Whenever a brake caliper is disassembled, replace the brake caliper piston seals.

2. Check:
 - Rear brake caliper bracket “1”
Cracks/damage → Replace.



EAS22650

ASSEMBLING THE REAR BRAKE CALIPER

EWA13620

⚠ WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components as they will cause the piston seals to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston seals.

	Recommended fluid DOT 4
--	------------------------------------

1. Install:


- Brake caliper seals **New**
- Brake caliper piston

EAS22670

INSTALLING THE REAR BRAKE CALIPER

1. Install:

- Brake caliper "1" (temporarily)
- Copper washers **New**
- Brake hose "2"
- Union bolt "3"



Brake hose union bolt
30 Nm (3.0 m·kg, 22 ft·lb)

EWA13530


WARNING

Proper brake hose routing is essential to insure safe vehicle operation. Refer to "CABLE ROUTING" on page 2-47.

ECA14170

CAUTION:

When installing the brake hose onto the brake caliper "1", make sure the brake pipe "a" touches the projection "b" on the brake caliper.



2. Remove:

- Brake caliper

3. Install:

- Brake pad spring

- Brake pad shims (on to the brake pads)
- Brake pads
- Brake caliper



Brake caliper bolt (front side)
27 Nm (2.7 m·kg, 20 ft·lb)

Brake caliper bolt (rear side)
22 Nm (2.2 m·kg, 16 ft·lb)

Brake pas pin
17 Nm (1.7 m·kg, 12 ft·lb)

Screw plug
3 Nm (0.3 m·kg, 2.2 ft·lb)

4. Fill:

- Brake fluid reservoir (with the specified amount of the recommended brake fluid)



Recommended fluid
DOT 4

EWA13090

WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540

CAUTION:


Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

5. Bleed:

- Brake system
Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.

6. Check:

- Brake fluid level
Below the minimum level mark "c" → Add the recommended brake fluid to the proper level.
Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-22.




7. Check:
- Brake pedal operation
Soft or spongy feeling → Bleed the brake system.
Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.

EAS22700

REMOVING THE REAR BRAKE MASTER CYLINDER

1. Remove:
- Union bolt "1"
 - Copper washers "2"
 - Brake hose "3"



NOTE:


To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.

2. Disconnect:
- Brake fluid reservoir hose
3. Remove:
- Pin (from the brake pedal link)
4. Remove:
- Rear brake master cylinder
5. Remove:
- Circlip (from the rear brake master cylinder)
 - Master cylinder kit


EAS22720

CHECKING THE REAR BRAKE MASTER CYLINDER


1. Check:
- Brake master cylinder "1"
Damage/scratches/wear → Replace.
 - Brake fluid delivery passages (brake master cylinder body)
Obstruction → Blow out with compressed air.



2. Check:
- Brake master cylinder kit "1"
Damage/scratches/wear → Replace.



3. Check:
- Brake fluid reservoir "1"
Cracks/damage → Replace.
 - Brake fluid reservoir diaphragm "2"
Cracks/damage → Replace.



4. Check:
- Brake hoses
Cracks/damage/wear → Replace.

EAS22730

ASSEMBLING THE REAR BRAKE MASTER CYLINDER

EWA13520

WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.



Recommended fluid
DOT 4

1. Install:
 - Master cylinder kit
 - Circlip **New**

EAS22740

INSTALLING THE REAR BRAKE MASTER CYLINDER

1. Install:
 - Copper washers **New**
 - Brake hoses
 - Union bolt



Brake hose union bolt
30 Nm (3.0 m·kg, 22 ft·lb)

EWA13530

WARNING


Proper brake hose routing is essential to insure safe vehicle operation. Refer to "CABLE ROUTING" on page 2-47.

ECA14160

CAUTION:

When installing the brake hose onto the brake master cylinder, make sure the brake pipe touches the projection "a" as shown.

2. Fill:
 - Brake fluid reservoir
(to the maximum level mark "a")



Recommended fluid
DOT 4

EWA13090

WARNING


- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540


CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

3. Bleed:
 - Brake system
Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" on page 3-24.
4. Check:
 - Brake fluid level
Below the minimum level mark "b" → Add the recommended brake fluid to the proper level.
Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-22.



5. Adjust:
 - Brake pedal position "c"
Refer to "ADJUSTING THE REAR DISC BRAKE" on page 3-21.




Brake pedal position
25.8 mm (1.02 in)

6. Adjust:
- Rear brake light operation timing
Refer to "ADJUSTING THE REAR BRAKE LIGHT SWITCH" on page 3-23.

EAS22840

HANDLEBAR

Removing the handlebar




Order	Job/Parts to remove	Q'ty	Remarks
1	Grip end	2	
2	Handlebar grip	1	
3	Clutch switch connector	1	Disconnect.
4	Left handlebar switch	1	
5	Clutch cable	1	
6	Clutch lever	1	
7	Right handlebar switch	1	
8	Throttle grip	1	
9	Throttle cable	2	
10	Front brake light switch connector	1	Disconnect.
11	Front brake master cylinder holder	1	
12	Front brake master cylinder	1	
13	Upper handlebar holder	1	
14	Handlebar	1	
			For installation, reverse the removal procedure.

2. Install:

- Handlebar "1"
- Upper handlebar holders "2"
- Upper handlebar holder caps "3" (Standard)



Upper handlebar holder bolt
23 Nm (2.3 m·kg, 17 ft·lb)




ECA14250

CAUTION:

- **First, tighten the bolts on the front side of the handlebar holder, and then on the rear side.**
- **Turn the handlebar all the way to the left and right. If there is any contact with the fuel tank, adjust the handlebar position.**

NOTE:

Align the match marks "a" on the handlebar with the upper surface of the lower handlebar holders.




3. Install:

- Throttle cables
- Right handlebar switch "1"
- Throttle grip "2"

NOTE:

Align the projections "a" on the handlebar switch with the holes "b" in the handlebar.




4. Install:

- Brake master cylinder "1"
 - Brake master cylinder holder "2"
- Refer to "INSTALLING THE FRONT BRAKE MASTER CYLINDER" on page 4-25.

NOTE:

Align the mating surfaces of the brake master cylinder bracket with the punch mark (right handlebar switch side) "a" on the handlebar.




5. Install:

- Clutch lever holder "1"
- Clutch cable

NOTE:

Align the slit on the clutch lever holder with the punch mark "a" on the handlebar.




6. Install:

- Left handlebar switch

EAS22950


FRONT FORK

Removing the front fork legs



Order	Job/Parts to remove	Q'ty	Remarks
	Front wheel		Refer to "FRONT WHEEL" on page 4-5.
	Front brake calipers		Refer to "FRONT BRAKE" on page 4-15.
1	Front fender	1	
2	Cap bolt	1	Loosen.
3	Upper bracket pinch bolt	1	Loosen.
4	Under bracket pinch bolt	1	Loosen.
5	Front fork leg	1	
			For installation, reverse the removal procedure.

Disassembling the front fork legs



Order	Job/Parts to remove	Q'ty	Remarks
1	Cap bolt	1	
2	O-ring	1	
3	Spacer	1	
4	Washer	1	
5	Front fork spring	1	
6	Dust seal	1	
7	Oil seal clip	1	
8	Damper rod assembly bolt	1	
9	Copper washer	1	
10	Damper rod assembly	1	
11	Oil seal	1	
12	Washer	1	
13	Inner tube	1	
14	Outer tube bushing	1	
15	Inner tube bushing	1	
16	Oil flow stopper	1	
17	Outer tube	1	
			For assembly, reverse the disassembly procedure.

EAS22970

REMOVING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

1. Stand the vehicle on a level surface.

EWA13120

WARNING

Securely support the vehicle so that there is no danger of it falling over.

NOTE:

Place the vehicle on a suitable stand so that the front wheel is elevated.


2. Loosen:

- Upper bracket pinch bolts "1"
- Cap bolt "2"
- Lower bracket pinch bolts "3"

EWA13640

WARNING

Before loosening the upper and lower bracket pinch bolts, support the front fork leg.



3. Remove:

- Front fork leg

EAS22990

DISASSEMBLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

1. Remove:

- Cap bolt
- Washer
- Spacer
- Fork spring

2. Drain:

- Fork oil

NOTE:

Stroke the inner tube several times while draining the fork oil.

3. Remove:


- Dust seal "1"
- Oil seal clip "2"

(with a flat-head screwdriver)

ECA14180

CAUTION:

Do not scratch the inner tube.



4. Remove:

- Damper rod assembly bolt
- Damper rod assembly

NOTE:

While holding the damper rod with the damper rod holder "1" and T-handle "2", loosen the damper rod assembly bolt.



Damper rod holder

90890-01294


Damping rod holder set

YM-01300

T-handle

90890-01326

YM-01326



5. Remove:


- Inner tube

- a. Hold the front fork leg horizontally.
- b. Securely clamp the brake caliper bracket in a vise with soft jaws.
- c. Separate the inner tube from the outer tube by pulling the inner tube forcefully but carefully.

ECA14190

CAUTION:

- Excessive force will damage the oil seal and bushing. A damaged oil seal or bushing must be replaced.
- Avoid bottoming the inner tube into the outer tube during the above procedure, as the oil flow stopper will be damaged.



EAS23010

CHECKING THE FRONT FORK LEGS



The following procedure applies to both of the front fork legs.

1. Check:
 - Inner tube "1"
 - Outer tube "2"
 Bends/damage/scratches → Replace.

EWA13650

WARNING


Do not attempt to straighten a bent inner tube as this may dangerously weaken it.



2. Measure:
 - Spring free length "a"
 Out of specification → Replace.



Fork spring free length
 354.0 mm (13.94 in)
Limit
 347.0 mm (13.66 in)




3. Check:
 - Damper rod "1"
 Damage/wear → Replace.
 Obstruction → Blow out all of the oil passages with compressed air.
 - Oil flow stopper "2"
 Damage → Replace.


ECA14200

CAUTION:


- The front fork leg has a built-in damper adjusting rod and a very sophisticated internal construction, which are particularly sensitive to foreign material.
- When disassembling and assembling the front fork leg, do not allow any foreign material to enter the front fork.



12310603



4. Check:
 - Cap bolt O-ring
 Damage/wear → Replace.



I2310302

EAS23020

ASSEMBLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

EWA13660

WARNING

- Make sure the oil levels in both front fork legs are equal.
- Uneven oil levels can result in poor handling and a loss of stability.

NOTE:

- When assembling the front fork leg, be sure to replace the following parts:
 - Inner tube bushing
 - Outer tube bushing
 - Oil seal
 - Dust seal
- Before assembling the front fork leg, make sure all of the components are clean.


1. Install:

- Inner tube bushing
- Outer tube bushing
- Oil flow stopper
- Damper rod assembly "1"
- Copper washer **New**

ECA14210

CAUTION:

Allow the damper rod assembly to slide slowly down the inner tube until it protrudes from the bottom of the inner tube. Be careful not to damage the inner tube.



2. Lubricate:


- Inner tube's outer surface



Recommended lubricant
Suspension oil 01 or equivalent

3. Tighten:

- Damper rod assembly bolt "1"




Damper rod assembly bolt
23 Nm (2.3 m·kg, 17 ft·lb)
LOCTITE®

NOTE:

While holding the damper rod assembly with the damper rod holder "2" and T-handle "3", tighten the damper rod assembly bolt.



Damper rod holder
90890-01294
Damping rod holder set
YM-01300
T-handle
90890-01326
YM-01326




4. Install:

- Outer tube bushing "1"
(with the fork seal driver "2" and fork seal attachment "3")



Fork seal driver weight
90890-01367
Replacement hammer
YM-A9409-7
Fork seal driver attachment
(ø43)
90890-01374
Replacement 43 mm
YM-A5142-3



5. Install:
- Washer
 - Oil seal "1"
(with the fork seal driver and adapter)



ECA14220

CAUTION:

Make sure the numbered side of the oil seal faces up.

NOTE:


- Before installing the oil seal, lubricate its lips with lithium soap base grease.
- Lubricate the outer surface of the inner tube with fork oil.
- Before installing the oil seal, cover the top of the front fork leg with a plastic bag "2" to protect the oil seal during installation.



6. Install:
- Oil seal clip "1"

NOTE:

Adjust the oil seal clip so that it fits into the outer tube's groove.




7. Install:

- Dust seal "1"
(with the fork seal driver weight)



**Fork seal driver weight
90890-01367
Replacement hammer
YM-A9409-7**



8. Fill:

- Front fork leg
(with the specified amount of the recommended fork oil)



**Quantity
467.0 cm³ (15.79 US oz) (16.47 Imp.oz)
Recommended oil
Suspension oil 01 or equivalent**

ECA4S81015

CAUTION:

- **Be sure to use the recommended fork oil. Other oils may have an adverse effect on front fork performance.**
- **When disassembling and assembling the front fork leg, do not allow any foreign material to enter the front fork.**

9. Measure:



- Front fork leg oil level “a”
Out of specification → Correct.



Level
134.0 mm (5.28 in)

NOTE:

- While filling the front fork leg, keep it upright.
- After filling, slowly pump the front fork leg up and down to distribute the fork oil.





10. Install:

- Spring “1”
- Spring seat “2”
- Spacer “3”
- Cap bolt

NOTE:

- Install the spring with the smaller pitch “a” facing down.
- Before installing the cap bolt, lubricate its O-ring with grease.
- Temporarily tighten the cap bolt.



b. Lager pitch

EAS23050

INSTALLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

1. Install:

- Front fork leg
Temporarily tighten the upper and lower bracket pinch bolts.

NOTE:

Make sure the inner fork tube is flush with the top of the handlebar holder.

2. Tighten:

- Lower bracket pinch bolt “1”



Lower bracket pinch bolt
30 Nm (3.0 m·kg, 22 ft·lb)

- Cap bolt “2”



Cap bolt
24 Nm (2.4 m·kg, 17 ft·lb)

- Upper bracket pinch bolt “3”




Upper bracket pinch bolt
30 Nm (3.0 m·kg, 22 ft·lb)

EWA13680

WARNING

Make sure the brake hoses are routed properly.


FRONT FORK



EAS23090

STEERING HEAD


Removing the lower bracket



Order	Job/Parts to remove	Q'ty	Remarks
	Front wheel		Refer to "FRONT WHEEL" on page 4-5.
	Front fender		Refer to "FRONT FORK" on page 4-43.
	Front fork		Refer to "FRONT FORK" on page 4-43.
	Handlebar		Refer to "HANDLEBAR" on page 4-39.
	Front cowling inner panel (left side)		Refer to "GENERAL CHASSIS" on page 4-1.
	Front cowling inner panel (right side)		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
1	Main switch coupler	2	Disconnect.
2	Steering stem nut	1	
3	Washer	1	
4	Upper bracket	1	
5	Horn stay	1	
6	Lock washer	1	
7	Upper ring nut	1	
8	Rubber washer	1	
9	Lower ring nut	1	
10	Lower bracket	1	
11	Bearing cover	1	
12	Bearing inner race	2	

STEERING HEAD

Removing the lower bracket



Order	Job/Parts to remove	Q'ty	Remarks
13	Upper bearing	1	
14	Lower bearing	1	
15	Dust seal	1	
16	Bearing outer race	2	
			For installation, reverse the removal procedure.

EAS23110

REMOVING THE LOWER BRACKET

1. Stand the vehicle on a level surface.

EWA13120



WARNING

Securely support the vehicle so that there is no danger of it falling over.

2. Remove:

- Steering stem nut
- Washer
- Upper ring nut
- Lock washer
- Rubber washer
- Lower ring nut "1"
(with the steering nut wrench "2")
- Lower bracket

NOTE:

Hold the lower ring nut with the exhaust and steering nut wrench, and then remove the upper ring nut with the ring nut wrench.




Steering nut wrench
90890-01403
Spanner wrench
YU-33975

EWA13730



WARNING

Securely support the lower bracket so that there is no danger of it falling.




EAS23130

CHECKING THE STEERING HEAD

1. Wash:


- Bearing balls
- Bearing races



Recommended cleaning solvent
Kerosene

2. Check:

- Bearing balls "1"
- Bearing races "2"
Damage/pitting → Replace.



3. Replace:

- Bearing balls
- Bearing races



- a. Remove the bearing races "1" from the steering head pipe with a long rod "2" and hammer.
- b. Remove the bearing race "3" from the lower bracket with a floor chisel "4" and hammer.
- c. Install a new dust seal and new bearing races.



ECA14270

CAUTION:

If the bearing race is not installed properly, the steering head pipe could be damaged.

NOTE:

- Always replace the bearings and bearing races as a set.
- Whenever the steering head is disassembled, replace the rubber seal.



4. Check:
 - Upper bracket
 - Lower bracket
(along with the steering stem)
Bends/cracks/damage → Replace.


EAS23140

INSTALLING THE STEERING HEAD

1. Lubricate:
 - Upper bearing
 - Lower bearing
 - Bearing races



2. Install:
 - Lower bracket
 - Lower ring nut "1"
 - Rubber washer "2"
 - Upper ring nut "3"
 - Lock washer "4"Refer to "CHECKING THE STEERING HEAD" on page 4-53.



3. Install:
 - Upper bracket
 - Washer
 - Steering stem nut

NOTE: _____
Temporarily tighten the steering stem nut.

4. Install:
 - Front fork legs
Refer to "INSTALLING THE FRONT FORK LEGS" on page 4-49.


NOTE: _____
Temporarily tighten the upper and lower bracket pinch bolts.

REAR SHOCK ABSORBER ASSEMBLY

EAS23160

REAR SHOCK ABSORBER ASSEMBLY

Removing the rear shock absorber assembly



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Side cover		Refer to "GENERAL CHASSIS" on page 4-1.
	Rear brake caliper		Refer to "REAR BRAKE" on page 4-27.
	Rear wheel		Refer to "REAR WHEEL" on page 4-10.
1	Self-locking nut/collar/bolt	1/1/1	
2	Self-locking nut/washer/bolt	1/1/1	
3	Rear shock absorber assembly	1	
4	Oil seal/bearing	2/1	
			For installation, reverse the removal procedure.

REAR SHOCK ABSORBER ASSEMBLY

EAS23180

HANDLING THE REAR SHOCK ABSORBER

EWA13740

WARNING

This rear shock absorber contains highly compressed nitrogen gas. Before handling the rear shock absorber, read and make sure you understand the following information. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling of the rear shock absorber.

- Do not tamper or attempt to open the rear shock absorber.
- Do not subject the rear shock absorber to an open flame or any other source of high heat. High heat can cause an explosion due to excessive gas pressure.
- Do not deform or damage the rear shock absorber in any way. Rear shock absorber damage will result in poor damping performance.

EAS23190


DISPOSING OF A REAR SHOCK ABSORBER

1. Gas pressure must be released before disposing of a rear shock absorber. To release the gas pressure, drill a 2–3-mm hole through the rear shock absorber at a point 15–20 mm from its end as shown.

EWA13760

WARNING

Wear eye protection to prevent eye damage from released gas or metal chips.



EAS23210

REMOVING THE REAR SHOCK ABSORBER ASSEMBLY

1. Stand the vehicle on a level surface.

EWA13120

WARNING

Securely support the vehicle so that there is no danger of it falling over.

NOTE:


Place the vehicle on a suitable stand so that the rear wheel is elevated.

2. Remove:


- Seat
 - Side cover
Refer to "GENERAL CHASSIS" on page 4-1.
 - Rear wheel
Refer to "REAR WHEEL" on page 4-10.
3. Remove:
 - Rear shock absorber assembly lower bolt "1"

NOTE:

While removing the rear shock absorber assembly lower bolt, hold the swingarm so that it does not drop down.



4. Remove:
 - Rear shock absorber assembly upper bolt "2"
 - Rear shock absorber assembly





EAS23240

CHECKING THE REAR SHOCK ABSORBER ASSEMBLY

1. Check:
 - Rear shock absorber rod
Bends/damage → Replace the rear shock absorber assembly.
 - Rear shock absorber
Gas leaks/oil leaks → Replace the rear shock absorber assembly.
 - Spring
Damage/wear → Replace the rear shock absorber assembly.

REAR SHOCK ABSORBER ASSEMBLY


- Bushings
Damage/wear → Replace.
- Dust seals
Damage/wear → Replace.
- Bolts
Bends/damage/wear → Replace.



EAS23300

INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY

1. Lubricate:
 - Collar
 - Bearings
 - Oil seals



Recommended lubricant
Molybdenum disulfide grease

2. Install:
 - Rear shock absorber assembly


NOTE:

When installing the rear shock absorber assembly, lift up the swingarm.

3. Tighten:
 - Rear shock absorber assembly upper nut
"1"



Rear shock absorber assembly upper nut
40 Nm (4.0 m·kg, 29 ft·lb)



- Rear shock absorber assembly lower nut
"2"



Rear shock absorber assembly lower nut
40 Nm (4.0 m·kg, 29 ft·lb)

4. Install:
 - Rear wheel
Refer to "REAR WHEEL" on page 4-10.
5. Adjust:
 - Drive chain slack
Refer to "ADJUSTING THE DRIVE CHAIN SLACK" on page 3-25.




Drive chain slack
45.0–55.0 mm (1.77–2.17 in)

EAS23330

SWINGARM


Removing the swingarm



Order	Job/Parts to remove	Q'ty	Remarks
	Muffler assembly		Refer to "ENGINE REMOVAL" on page 5-1.
	Catalyst assembly		Refer to "ENGINE REMOVAL" on page 5-1.
	Exhaust pipe assembly		Refer to "ENGINE REMOVAL" on page 5-1.
	Rear brake caliper		Refer to "REAR BRAKE" on page 4-27.
	Rear wheel		Refer to "REAR WHEEL" on page 4-10.
	Rear shock absorber assembly		Refer to "REAR SHOCK ABSORBER ASSEMBLY" on page 4-55.
	Drive sprocket cover		Refer to "ENGINE REMOVAL" on page 5-1.
1	Locknut	2	Loosen.
2	Adjusting nut	2	Loosen.
3	Rear fender	1	
4	Pivot shaft nut/washer	1/1	
5	Pivot shaft	1	
6	Swingarm	1	
7	Drive chain	1	
8	Drive chain guide	1	
9	Dust cover	2	
10	Bearing	2	
11	Spacer	1	

SWINGARM

Removing the swingarm



Order	Job/Parts to remove	Q'ty	Remarks
			For installation, reverse the removal procedure.

EAS23340

REMOVING THE SWINGARM

1. Stand the vehicle on a level surface.

EWA13120

WARNING

Securely support the vehicle so that there is no danger of it falling over.

NOTE:

Place the vehicle on a suitable stand so that the rear wheel is elevated.

2. Measure:

- Swingarm side play
- Swingarm vertical movement

a. Measure the tightening torque of the swingarm pivot shaft bolt and nut.




Pivot shaft nut
120 Nm (12.0 m·kg, 87 ft·lb)

- b. Measure the swingarm side play "A" by moving the swingarm from side to side.
- c. If the swingarm side play is out of specification, check the spacers, bearings, washers and dust covers.



Swingarm side play (at the end of the swingarm)
1.0 mm (0.039 in)

- d. Check the swingarm vertical movement "B" by moving the swingarm up and down. If swingarm vertical movement is not smooth or if there is binding, check the spacers, bearings and dust covers.




EAS23370

CHECKING THE SWINGARM

1. Check:

- Swingarm
Bends/cracks/damage → Replace.




2. Check:

- Pivot shaft
Roll the pivot shaft on a flat surface.
Bends → Replace.

EWA4S81007

WARNING

Do not attempt to straighten a bent pivot shaft.



3. Wash:


- Pivot shaft
- Dust covers
- Spacer
- Washers
- Bearings



Recommended cleaning solvent
Kerosene

4. Check:

- Dust covers "1"
- Spacer "2"
Damage/wear → Replace.
- Bearings
Damage/pitting → Replace.



EAS23380


INSTALLING THE SWINGARM

1. Lubricate:

- Bearings
- Spacers
- Dust covers
- Pivot shaft "1"



Recommended lubricant
Lithium-soap-based grease




2. Install:

- Swingarm
- Pivot shaft nut "2"



Pivot shaft nut
120 Nm (12.0 m·kg, 87 ft·lb)



3. Install:

- Rear shock absorber assembly
Refer to "INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY" on page 4-57.
- Rear wheel
Refer to "INSTALLING THE REAR WHEEL" on page 4-14.

4. Adjust:

- Drive chain slack
Refer to "ADJUSTING THE DRIVE CHAIN SLACK" on page 3-25.




Drive chain slack
45.0–55.0 mm (1.77–2.17 in)

EAS23400

CHAIN DRIVE

Removing the drive chain

 7 Nm (0.7 m•kg, 5.1 ft•lb)



Order	Job/Parts to remove	Q'ty	Remarks
	Drive sprocket cover		Refer to "ENGINE REMOVAL" on page 5-1.
	Swingarm		Refer to "REMOVING THE SWINGARM" on page 4-60.
1	Rear fender	1	
2	Drive chain	1	
3	Chain protector	1	
			For installation, reverse the removal procedure.

EAS23410

REMOVING THE DRIVE CHAIN

1. Stand the vehicle on a level surface.

EWA13120



Securely support the vehicle so that there is no danger of it falling over.

NOTE:

Place the vehicle on a suitable stand so that the rear wheel is elevated.

2. Remove:

- Drive chain
(with the drive chain cutter)

EAS23440

CHECKING THE DRIVE CHAIN

1. Measure:



- Measure the dimension between 15-links on the inner side "a" and outer side "b" of the roller and calculate the dimension between pin centers.
- Dimension "c" between pin centers = (Inner dimension "a" + Outer dimension "b")/2
- 15-link section "c" of the drive chain
Out of specification → Replace the drive chain, front drive sprocket and rear drive sprocket as a set.



15-link drive chain section limit (maximum)
239.3 mm (9.42 in)


NOTE:

- While measuring the 15-link section, push down on the drive chain to increase its tension.
- Perform this measurement at two or three different places.



2. Check:

- Drive chain
Stiffness → Clean and lubricate or replace.



I2510204

3. Clean:

- Drive chain




- Wipe the drive chain with a clean cloth.
- Put the drive chain in kerosene and remove any remaining dirt.
- Remove the drive chain from the kerosene and completely dry it.


ECA14290

CAUTION:

- **This vehicle has a drive chain with small rubber O-rings "1" between the drive chain side plates. Never use high-pressure water or air, steam, gasoline, certain solvents (e.g., benzene), or a coarse brush to clean the drive chain. High-pressure methods could force dirt or water into the drive chain's internals, and solvents will deteriorate the O-rings. A coarse brush can also damage the O-rings. Therefore, use only kerosene to clean the drive chain.**
- **Do not soak the drive chain in kerosene for more than ten minutes, otherwise the O-rings can be damaged.**




I2510302



I2510201

More than 1/4 tooth "a" wear → Replace the drive chain sprockets as a set.
Bent teeth → Replace the drive chain sprockets as a set.



- a. Correct
- 1. Drive chain roller
- 2. Drive chain sprocket

EAS23470

CHECKING THE REAR WHEEL SPROCKET

Refer to "CHECKING AND REPLACING THE REAR WHEEL SPROCKET" on page 4-14.

EAS23480

CHECKING THE REAR WHEEL DRIVE HUB

Refer to "CHECKING THE REAR WHEEL DRIVE HUB" on page 4-13.

EAS28800

INSTALLING THE DRIVE CHAIN

1. Lubricate:
 - Drive chain


	Recommended lubricant Engine oil or chain lubricant suitable for O-ring chains
---	---

2. Install:
 - Drive chain
3. Install:
 - SwingarmRefer to "INSTALLING THE SWINGARM" on page 4-61.



4. Check:

- O-rings "1"
Damage → Replace the drive chain.
- Drive chain rollers "2"
Damage/wear → Replace the drive chain.
- Drive chain side plates "3"
Damage/wear → Replace the drive chain.
Cracks → Replace the drive chain and make sure the battery breather hose is properly routed away from the drive chain and below the swingarm.



I2510201

5. Lubricate:

- Drive chain

	Recommended lubricant Engine oil or chain lubricant suitable for O-ring chains
---	---

EAS23460

CHECKING THE DRIVE SPROCKET

1. Check:
 - Drive sprocket

ENGINE

ENGINE REMOVAL	5-1
INSTALLING THE ENGINE	5-6
CAMSHAFTS	5-8
REMOVING THE CAMSHAFTS	5-10
CHECKING THE CAMSHAFTS	5-11
CHECKING THE TIMING CHAIN AND CAMSHAFT SPROCKET	5-12
CHECKING THE TIMING CHAIN GUIDES	5-12
CHECKING THE TIMING CHAIN TENSIONER	5-13
INSTALLING THE CAMSHAFTS	5-13
CYLINDER HEAD	5-16
REMOVING THE CYLINDER HEAD	5-17
CHECKING THE CYLINDER HEAD	5-17
INSTALLING THE CYLINDER HEAD	5-17
VALVES AND VALVE SPRINGS	5-19
REMOVING THE VALVES	5-21
CHECKING THE VALVES AND VALVE GUIDES	5-22
CHECKING THE VALVE SEATS	5-23
CHECKING THE VALVE SPRINGS	5-25
CHECKING THE VALVE LIFTERS	5-26
INSTALLING THE VALVES	5-26
GENERATOR AND STARTER CLUTCH	5-28
REMOVING THE GENERATOR	5-30
REMOVING THE STARTER CLUTCH	5-30
CHECKING THE STARTER CLUTCH	5-31
INSTALLING THE STARTER CLUTCH	5-31
INSTALLING THE GENERATOR	5-32
PICKUP ROTOR	5-33
REMOVING THE PICKUP ROTOR	5-34
INSTALLING THE PICKUP ROTOR	5-34
ELECTRIC STARTER	5-36
CHECKING THE STARTER MOTOR	5-38
ASSEMBLING THE STARTER MOTOR	5-39
INSTALLING THE STARTER MOTOR	5-39
OIL PUMP	5-40
REMOVING THE OIL PAN	5-43
CHECKING THE OIL PUMP	5-43
CHECKING THE RELIEF VALVE	5-43
CHECKING THE OIL DELIVERY PIPES	5-44
CHECKING THE OIL STRAINER	5-44


CHECKING THE OIL NOZZLES	5-44
ASSEMBLING THE OIL PUMP	5-44
INSTALLING THE OIL PUMP	5-45
INSTALLING THE OIL STRAINER	5-45
INSTALLING THE OIL PAN	5-45
CLUTCH	5-46
REMOVING THE CLUTCH.....	5-49
CHECKING THE FRICTION PLATES	5-49
CHECKING THE CLUTCH PLATES.....	5-50
CHECKING THE CLUTCH SPRINGS.....	5-50
CHECKING THE CLUTCH HOUSING	5-50
CHECKING THE CLUTCH BOSS	5-50
CHECKING THE PRESSURE PLATE.....	5-51
CHECKING THE PULL LEVER SHAFT AND PULL ROD.....	5-51
INSTALLING THE CLUTCH.....	5-51
SHIFT SHAFT	5-53
CHECKING THE SHIFT SHAFT	5-54
CHECKING THE STOPPER LEVER.....	5-54
INSTALLING THE SHIFT SHAFT	5-54
CRANKCASE	5-55
DISASSEMBLING THE CRANKCASE.....	5-57
CHECKING THE CRANKCASE	5-57
CHECKING THE BEARINGS AND OIL SEALS	5-57
CHECKING THE OIL PUMP DRIVE CHAIN	5-57
ASSEMBLING THE CRANKCASE.....	5-58
CRANKSHAFT	5-60
REMOVING THE CONNECTING RODS AND PISTONS.....	5-62
REMOVING THE CRANKSHAFT ASSEMBLY	5-62
CHECKING THE CYLINDER AND PISTON.....	5-63
CHECKING THE PISTON RINGS	5-63
CHECKING THE PISTON PINS	5-64
CHECKING THE BIG END BEARINGS	5-65
INSTALLING THE CONNECTING ROD AND PISTON	5-68
CHECKING THE CRANKSHAFT	5-70
CHECKING THE CRANKSHAFT JOURNAL BEARINGS.....	5-70
INSTALLING THE CRANKSHAFT	5-72
TRANSMISSION	5-74
REMOVING THE TRANSMISSION.....	5-78
CHECKING THE SHIFT FORKS.....	5-78
CHECKING THE SHIFT DRUM ASSEMBLY	5-78
CHECKING THE TRANSMISSION	5-79
INSTALLING THE TRANSMISSION.....	5-79



EAS23710

ENGINE REMOVAL


Removing the drive sprocket



Order	Job/Parts to remove	Q'ty	Remarks
	Drive chain		Loosen Refer to "ADJUSTING THE SHIFT PEDAL" on page 3-25.
1	Locknut	1	
2	Shift rod	1	
3	Shift arm	1	
4	Drive sprocket cover	1	
5	Drive sprocket nut	1	
6	Lock washer	1	
7	Drive sprocket	1	
			For installation, reverse the removal procedure.

ENGINE REMOVAL


Removing the exhaust pipe



Order	Job/Parts to remove	Q'ty	Remarks
1	Exhaust pipe assembly	1	
2	Exhaust pipe gasket	4	
3	Catalytic converter pipe	1	
4	Muffler cover	1	
5	Muffler	1	
			For installation, reverse the removal procedure.

ENGINE REMOVAL


Disconnecting the leads and hoses



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Right front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Left front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Battery		Refer to "GENERAL CHASSIS" on page 4-1.
	Air filter case		Refer to "GENERAL CHASSIS" on page 4-1.
	Battery box		Refer to "GENERAL CHASSIS" on page 4-1.
	Battery box bracket		Refer to "GENERAL CHASSIS" on page 4-1.
	Throttle body		Refer to "THROTTLE BODIES" on page 7-4.
	Engine oil		Drain. Refer to "CHANGING THE ENGINE OIL" on page 3-12.
	Oil cooler		Refer to "OIL COOLER" on page 6-4.
	Air cut-off valve		Refer to "AIR INDUCTION SYSTEM" on page 7-9.
	Radiator		Refer to "RADIATOR" on page 6-1.
	Starter motor		Refer to "ELECTRIC STARTER" on page 5-36.
1	Battery negative lead	1	
2	Battery positive lead	1	
3	Clutch cable	1	
4	Ground lead	1	

ENGINE REMOVAL


Disconnecting the leads and hoses



Order	Job/Parts to remove	Q'ty	Remarks
5	Starter motor lead	1	Disconnect.
6	Stator coil assembly coupler	1	Disconnect.
7	Oil level switch connector	1	Disconnect.
8	Neutral switch coupler	1	Disconnect.
9	Speed sensor coupler	1	Disconnect.
			For assembly, reverse the removal procedure.

ENGINE REMOVAL

Removing the engine



Order	Job/Parts to remove	Q'ty	Remarks
1	Right front engine mounting bolt	1	
2	Left front engine mounting bolt	2	
3	Self-locking nut	2	
4	Rear engine mounting bolt	2	
5	Engine	1	
			For installation, reverse the removal procedure.

ENGINE REMOVAL

EAS23720


INSTALLING THE ENGINE

1. Install:

- Rear engine mounting bolts "1"

NOTE:

Lubricate the rear engine mounting bolt threads with engine oil.





2. Install:

- Right front engine mounting bolt "2"
- Left front engine mounting bolts "3"

NOTE:

Do not fully tighten the bolts.



3. Tighten:


- Self-locking nut "4"



Self-locking nut
55 Nm (5.5 m·kg, 40 ft·lb)


NOTE:

First tighten the lower self-locking nut.




4. Tighten:

- Left front engine mounting bolts "5"



Left front engine mounting bolt
55 Nm (5.5 m·kg, 40 ft·lb)




5. Tighten:

- Right front engine mounting bolt "6"



Right front engine mounting bolt
55 Nm (5.5 m·kg, 40 ft·lb)



6. Install:


- Shift arm bolt "7"



Shift arm bolt
10 Nm (1.0 m·kg, 7.2 ft·lb)

NOTE:

- Before installing, make sure to align the punch mark “a” of the shift shaft with the punch mark “b” of the shift arm.
- Align the bottom edge of the shift pedal with the mark on the frame-to-swingarm bracket.




EAS23760

CAMSHAFTS


Removing the cylinder head cover



18 Nm (1.8 m·kg, 13 ft·lb)




12 Nm (1.2 m·kg, 8.7 ft·lb)



Order	Job/Parts to remove	Q'ty	Remarks
	Battery		Refer to "GENERAL CHASSIS" on page 4-1.
	Air filter case		Refer to "GENERAL CHASSIS" on page 4-1.
	Battery box		Refer to "FUEL TANK" on page 7-1.
	Battery box bracket		Refer to "GENERAL CHASSIS" on page 4-1.
	Throttle body		Refer to "THROTTLE BODIES" on page 7-4.
	Radiator		Refer to "RADIATOR" on page 6-1.
	Air cut-off valve		Refer to "AIR INDUCTION SYSTEM" on page 7-9.
1	Ignition coil	2	
2	Spark plug	4	
3	Cylinder head cover	1	
4	Cylinder head cover gasket	1	
5	Timing chain guide (top side)	1	
			For installation, reverse the removal procedure.

Removing the camshafts



Order	Job/Parts to remove	Q'ty	Remarks
	Pickup rotor cover		Refer to "PICKUP ROTOR" on page 5-33.
1	Camshaft sprocket bolt	4	
2	Timing chain tensioner	1	
3	Timing chain tensioner gasket	1	
4	Timing chain guide (exhaust side)	1	
5	Intake camshaft cap	3	
6	Dowel pin	6	
7	Exhaust camshaft cap	3	
8	Dowel pin	6	
9	Intake camshaft	1	
10	Exhaust camshaft	1	
11	Pin	1	
12	Timing chain guide (intake side)	1	
13	Camshaft sprocket	2	
			For installation, reverse the removal procedure.

EAS23810

REMOVING THE CAMSHAFTS


1. Remove:
 - Pickup rotor cover
 Refer to "PICKUP ROTOR" on page 5-33.
2. Align:
 - "T" mark "a" on the pickup rotor (with the crankcase mating surface "b")




- a. Turn the crankshaft clockwise.
- b. When piston #1 is at TDC on the compression stroke, align the "T" mark "a" on the pickup rotor with the crankcase mating surface "b".

NOTE:


TDC on the compression stroke can be found when the camshaft lobes are turned away from each other.



3. Loosen:
 - Camshaft sprocket bolts "1"



4. Loosen:
 - Timing chain tensioner cap bolt "1"
5. Remove:
 - Timing chain tensioner "2"
 - Gasket




6. Remove:
 - Timing chain guide (exhaust side)
 - Camshaft caps "1"
 - Dowel pins

ECA13720

CAUTION:


To prevent damage to the cylinder head, camshafts or camshaft caps, loosen the camshaft cap bolts in stages and in a criss-cross pattern, working from the outside in.



7. Remove:
 - Intake camshaft "1"
 - Exhaust camshaft "2"

NOTE:

To prevent the timing chain from falling into the crankcase, fasten it with a wire "a".





NOTE:

- Tighten the camshaft cap bolts in stages and in a crisscross pattern, working from the inner caps out.
- Do not turn the camshaft when measuring the camshaft journal-to-camshaft cap clearance with the Plastigauge®.



Camshaft cap bolt
10 Nm (1.0 m·kg, 7.2 ft·lb)

- d. Remove the camshaft caps and then measure the width of the Plastigauge® “2”.




5. Measure:

- Camshaft journal diameter “a”
 Out of specification → Replace the camshaft.
 Within specification → Replace the cylinder head and the camshaft caps as a set.



Camshaft journal diameter
22.967–22.980 mm (0.9042–0.9047 in)




H151003

EAS23870

CHECKING THE TIMING CHAIN AND CAMSHAFT SPROCKET


1. Check:

- Timing chain “1”
 Damage/stiffness → Replace the timing chain and camshaft sprocket as a set.



2. Check:

- Camshaft sprocket
 More than 1/4 tooth wear “a” → Replace the camshaft sprocket and the timing chain as a set.



- a. 1/4 tooth
- b. Correct
- 1. Timing chain roller
- 2. Camshaft sprocket


EAS23950

CHECKING THE TIMING CHAIN GUIDES

1. Check:

- Timing chain guide (exhaust side) “1”
- Timing chain guide (intake side) “2”

- Timing chain guide (top side) “3”
Damage/wear → Replace the defective part(s).



EAS23970

CHECKING THE TIMING CHAIN TENSIONER



1. Check:
 - Timing chain tensioner
Cracks/damage → Replace.
2. Check:
 - One-way cam
Rough movement → Replace the timing chain tensioner assembly.

- a. Lightly press the timing chain tensioner rod into the timing chain tensioner housing by hand.

NOTE:

While pressing the timing chain tensioner rod, wind it clockwise with a thin screwdriver “1” until it stops.

- b. Remove the screwdriver and slowly release the timing chain tensioner rod.
- c. Make sure that the timing chain tensioner rod comes out of the timing chain tensioner housing smoothly. If there is rough movement, replace the timing chain tensioner.




3. Check:
 - Timing chain tensioner cap bolt
 - Aluminum washer **New**
 - Gasket **New**
Damage/wear → Replace the defective part(s).

EAS24010

INSTALLING THE CAMSHAFTS


1. Align:
 - “T” mark “a” on the pickup rotor
(with the crankcase mating surface “b”)
- a. Turn the crankshaft clockwise.
 - b. When piston #1 is at TDC, align the “T” mark “a” with the crankcase mating surface “b”.



2. Install:
 - Exhaust camshaft “1”
 - Intake camshaft “2”
(with the camshaft sprockets temporarily tightened)

NOTE:



Make sure the match mark “a” on the camshaft sprockets is aligned with the cylinder head edge “b”.



3. Install:
- Dowel pins
 - Intake camshaft caps
 - Exhaust camshaft caps

NOTE:

- Make sure each camshaft cap is installed in its original place. Refer to the identification marks as follows:
 “I1”, “I2”: Intake side camshaft cap mark
 “E1”, “E2”: Exhaust side camshaft cap mark
- Make sure the arrow mark “a” on each camshaft points towards the right side of the engine.



4. Install:
- Camshaft cap bolts

	Camshaft cap bolt 10 Nm (1.0 m·kg, 7.2 ft·lb)
---	---

NOTE:

Tighten the camshaft cap bolts in stages and in a crisscross pattern, working from the inner caps out.

ECA4S81016

CAUTION:

- Lubricate the camshaft cap bolts with the engine oil.
- The camshaft cap bolts must be tightened evenly or damage to the cylinder head, camshaft caps, and camshafts will result.
- Do not turn the crankshaft when installing the camshaft to avoid damage or improper valve timing.

5. Install:
- Timing chain guide (exhaust side)

NOTE:

When installing the timing chain guide, be sure to keep the timing chain as tight as possible on the exhaust side.

6. Install:
- Timing chain tensioner



- a. While lightly pressing the timing chain tensioner rod by hand, turn the tensioner rod fully clockwise with a thin screwdriver “1”.
- b. With the timing chain tensioner rod turned all the way into the timing chain tensioner housing (with the thin screwdriver still installed), install the gasket and the timing chain tensioner “2” onto the cylinder block.

EWA4S81008

WARNING





Always use a new gasket.

- c. Tighten the timing chain tensioner bolts “3” to the specified torque.

	Timing chain tensioner bolt 12 Nm (1.2 m·kg, 8.7 ft·lb)
---	---

- d. Remove the screwdriver, make sure the timing chain tensioner rod releases, and then tighten the cap bolt to the specified torque.

	Timing chain tensioner cap bolt 7 Nm (0.7 m·kg, 5.1 ft·lb)
---	--



7. Turn:

- Crankshaft
(several full turns clockwise)

8. Check:

- “T” mark “a”
Make sure the “T” mark on the pickup rotor is aligned with the crankcase mating sure face “b”.
- Camshaft sprocket match mark “c”
Make sure the match marks on the camshaft sprockets are aligned with the edge of the cylinder head “d”.
Out of alignment → Adjust.
Refer to the installation steps above.

9. Tighten:

- Camshaft sprocket bolts “1”

10. Measure:

- Valve clearance
Out of specification → Adjust.
Refer to "ADJUSTING THE VALVE CLEARANCE" on page 3-4.



Camshaft sprocket bolts
20 Nm (2.0 m·kg, 1.5 ft·lb)

ECA4S81017

CAUTION:

Be sure to tighten the camshaft sprocket bolts to the specified torque to avoid the possibility of the bolts coming loose and damaging the engine.



EAS24100

CYLINDER HEAD

Removing the cylinder head



	1st	19 Nm (1.9 m·kg, 14 ft·lb)
	2nd	50 Nm (5.0 m·kg, 36 ft·lb)



Order	Job/Parts to remove	Q'ty	Remarks
	Intake camshaft		Refer to "CAMSHAFTS" on page 5-8.
	Exhaust camshaft		Refer to "CAMSHAFTS" on page 5-8.
1	Cylinder head	1	
2	Cylinder head gasket	1	
3	Dowel pin	2	
			For installation, reverse the removal procedure.



EAS24120

REMOVING THE CYLINDER HEAD


- Remove:
 - Cylinder head bolts

NOTE:

- Loosen the bolts in the proper sequence as shown.
- Loosen each bolts 1/2 of a turn at a time. After all of the bolts are fully loosened, remove them.



- Place a straightedge "1" and a thickness gauge "2" across the cylinder head.



- Measure the warpage.
- If the limit is exceeded, resurface the cylinder head as follows.
- Place a 400–600 grit wet sandpaper on the surface plate and resurface the cylinder head using a figure-eight sanding pattern.

NOTE:

To ensure an even surface, rotate the cylinder head several times.

EAS24160


CHECKING THE CYLINDER HEAD

- Eliminate:
 - Combustion chamber carbon deposits (with a rounded scraper)

NOTE:

Do not use a sharp instrument to avoid damaging or scratching:

- Spark plug bore threads
- Valve seats




- Check:
 - Cylinder head
Damage/scratches → Replace.
 - Cylinder head water jacket
Mineral deposits/rust → Eliminate.
- Measure:
 - Cylinder head warpage
Out of specification → Resurface the cylinder head.

EAS24240

INSTALLING THE CYLINDER HEAD

- Install:
 - Cylinder head gasket "1" **New**
 - Dowel pins "2"



- Install:
 - Cylinder head



Warpage limit
0.05 mm (0.0020 in)

NOTE:

Pass the timing chain through the timing chain cavity.

3. Tighten:

- Cylinder head bolts "1" – "10"



Cylinder head bolt (1st)
19 Nm (1.9 m·kg, 14 ft·lb)



Cylinder head bolt (2 nd)
50 Nm (5.0 m·kg, 36 ft·lb)


- Cylinder head bolts "11" "12"



Cylinder head bolt
12 Nm (1.2 m·kg, 8.7 ft·lb)

NOTE:

- Lubricate the cylinder head bolts with engine oil.
- Tighten the cylinder head bolts in the proper tightening sequence as shown and torque them in two stages.
- First, tighten the bolts "1" – "10" to approximately 19 Nm (1.9 m·kg, 14 ft·lb) with a torque wrench and then tighten the 50 Nm (5.0 m·kg, 36 ft·lb).



4. Install:


- Exhaust camshaft
- Intake camshaft

Refer to "INSTALLING THE CAMSHAFTS"
on page 5-13.

EAS24270

VALVES AND VALVE SPRINGS


Removing the valves and valve springs



Order	Job/Parts to remove	Q'ty	Remarks
	Cylinder head		Refer to "CYLINDER HEAD" on page 5-16.
1	Intake valve lifter	8	
2	Intake valve pad	8	
3	Intake valve cotter	16	
4	Intake valve upper spring seat	8	
5	Intake valve spring outer	8	
6	Intake valve spring inner	8	
7	Intake valve stem seal	8	
8	Intake valve lower spring seat	8	
9	Intake valve	8	
10	Intake valve guide	8	
11	Exhaust valve lifter	8	
12	Exhaust valve pad	8	
13	Exhaust valve cotter	16	
14	Exhaust valve upper spring seat	8	
15	Exhaust valve spring	8	
16	Exhaust valve stem seal	8	
17	Exhaust valve lower spring seat	8	
18	Exhaust valve	8	
19	Exhaust valve guide	8	

VALVES AND VALVE SPRINGS

Removing the valves and valve springs



Order	Job/Parts to remove	Q'ty	Remarks
			For installation, reverse the removal procedure.

EAS24280

REMOVING THE VALVES

The following procedure applies to all of the valves and related components.

NOTE:


Before removing the internal parts of the cylinder head (e.g., valves, valve springs, valve seats), make sure the valves properly seal.

1. Remove:

- Valve lifter "1"
- Valve pad "2"

NOTE:

Make a note of the position of each valve lifter and valve pad so that they can be reinstalled in their original place.



11172201

2. Check:


- Valve sealing
Leakage at the valve seat → Check the valve face, valve seat, and valve seat width. Refer to "CHECKING THE VALVE SEATS" on page 5-23.



- a. Pour a clean solvent "a" into the intake and exhaust ports.
- b. Check that the valves properly seal.

NOTE:

There should be no leakage at the valve seat "1".



3. Remove:

- Valve cotters "1"

NOTE:


Remove the valve cotters by compressing the valve springs with the valve spring compressor "2" and the valve spring compressor attachment "3".



Valve spring compressor
90890-04019
YM-04019

Valve spring compressor
attachment
90890-04108

Valve spring compressor
adapter 22 mm
YM-04108




4. Remove:

- Upper spring seat "1"
- Valve spring outer "2"
- Valve spring inner (intake only) "3"
- Valve "4"
- Valve stem seal "5"
- Lower spring seat "6"

NOTE:

Identify the position of each part very carefully so that it can be reinstalled in its original place.



EAS24290

CHECKING THE VALVES AND VALVE GUIDES

The following procedure applies to all of the valves and valve guides.

1. Measure:

- Valve-stem-to-valve-guide clearance
Out of specification → Replace the valve guide.

- Valve-stem-to-valve-guide clearance =
Valve guide inside diameter "a" -
Valve stem diameter "b"





Valve-stem-to-valve-guide clearance

Valve-stem-to-valve-guide clearance (intake)
0.010–0.037 mm (0.0004–0.0015 in)

Limit
0.080 mm (0.0032 in)

Valve-stem-to-valve-guide clearance (exhaust)
0.025–0.052 mm (0.0010–0.0020 in)

Limit
0.100 mm (0.0039 in)



2. Replace:


- Valve guide

NOTE:


To ease valve guide removal and installation, and to maintain the correct fit, heat the cylinder head to 100°C (212°F) in an oven.




- Remove the valve guide with the valve guide remover "1".



- Install the new valve guide with the valve guide installer "2" and valve guide remover "1".



- After installing the valve guide, bore the valve guide with the valve guide reamer "3" to obtain the proper valve-stem-to-valve-guide clearance.



NOTE:

After replacing the valve guide, reface the valve seat.




Valve guide remover (ø4)
90890-04111
Valve guide remover (4.0 mm)
YM-04111
Valve guide installer (ø4)
90890-04112
Valve guide installer (4.0 mm)
YM-04112
Valve guide reamer (ø4)
90890-04113
Valve guide reamer (4.0 mm)
YM-04113



3. Eliminate:
 - Carbon deposits
(from the valve face and valve seat)
4. Check:
 - Valve face
Pitting/wear → Grind the valve face.
 - Valve stem end
Mushroom shape or diameter larger than the body of the valve stem → Replace the valve.
5. Measure:
 - Valve margin thickness “a”
Out of specification → Replace the valve.



Valve margin thickness
Valve margin thickness D (intake)
0.60–0.80 mm (0.0236–0.0315 in)
Limit
0.5 mm (0.02 in)
Valve margin thickness D (exhaust)
0.60–0.80 mm (0.0236–0.0315 in)
Limit
0.5 mm (0.02 in)



6. Measure:
 - Valve stem runout


Out of specification → Replace the valve.

NOTE:

- When installing a new valve, always replace the valve guide.
- If the valve is removed or replaced, always replace the oil seal.



Valve stem runout
Valve stem runout
0.040 mm (0.0016 in)



EAS24300


CHECKING THE VALVE SEATS

The following procedure applies to all of the valves and valve seats.


1. Eliminate:
 - Carbon deposits
(from the valve face and valve seat)
2. Check:
 - Valve seat
Pitting/wear → Replace the cylinder head.
3. Measure:
 - Valve seat width “a”
Out of specification → Replace the cylinder head.



Valve seat width
Valve seat width C (intake)
0.90–1.10 mm (0.0354–0.0433 in)
Limit
1.6 mm (0.06 in)
Valve seat width C (exhaust)
0.90–1.10 mm (0.0354–0.0433 in)
Limit
1.6 mm (0.06 in)



-
- a. Apply Mechanic's blueing dye (Dykem) "b" onto the valve face.



- b. Install the valve into the cylinder head.
c. Press the valve through the valve guide and onto the valve seat to make a clear impression.
d. Measure the valve seat width.

NOTE: _____
Where the valve seat and valve face contacted one another, the blueing will have been removed.

-
4. Lap:
- Valve face
 - Valve seat


NOTE: _____
After replacing the cylinder head or replacing the valve and valve guide, the valve seat and valve face should be lapped.

-
- a. Apply a coarse lapping compound "a" to the valve face.


ECA13790

CAUTION: _____

Do not let the lapping compound enter the gap between the valve stem and the valve guide.




- b. Apply molybdenum disulfide oil onto the valve stem.




- c. Install the valve into the cylinder head.
d. Turn the valve until the valve face and valve seat are evenly polished, then clean off all of the lapping compound.


NOTE: _____
For the best lapping results, lightly tap the valve seat while rotating the valve back and forth between your hands.



- e. Apply a fine lapping compound to the valve face and repeat the above steps.
f. After every lapping procedure, be sure to clean off all of the lapping compound from the valve face and valve seat.
g. Apply Mechanic's blueing dye (Dykem) "b" onto the valve face.




11171601




11171902

- h. Install the valve into the cylinder head.
- i. Press the valve through the valve guide and onto the valve seat to make a clear impression.
- j. Measure the valve seat width "c" again. If the valve seat width is out of specification, reface and lap the valve seat.



11171603

- 2. Measure:
 - Compressed valve spring force "a"
 Out of specification → Replace the valve spring.



b. Installed length



EAS24310

CHECKING THE VALVE SPRINGS

The following procedure applies to all of the valve springs.


- 1. Measure:
 - Valve spring free length "a"
 Out of specification → Replace the valve spring.



Inner spring
Free length (intake)
 37.04 mm (1.46 in)
Limit
 35.20 mm (1.39 in)
Free length (exhaust)
 41.79 mm (1.65 in)
Limit
 39.70 mm (1.56 in)
Outer spring
Free length (intake)
 38.40 mm (1.51 in)
Limit
 36.50 mm (1.44 in)




Inner spring
Installed compression spring force (intake)
 69–79 N (15.51–17.76 lbf)
 (7.04–8.06 kgf)
Installed compression spring force (exhaust)
 160–184 N (35.97–41.36 lbf)
 (16.32–18.76 kgf)
Outer spring
Installed compression spring force (intake)
 114–132 N (25.63–29.67 lbf)
 (11.62–13.46 kgf)
Inner spring
Installed length (intake)
 30.02 mm (1.18 in)
Installed length (exhaust)
 36.12 mm (1.42 in)
Outer spring
Installed length (intake)
 32.52 mm (1.28 in)



3. Measure:
- Valve spring tilt "a"
Out of specification → Replace the valve spring.



Spring tilt limit
Spring tilt (intake)
 2.5 °/1.6 mm (0.06 in)
Spring tilt (exhaust)
 2.5 °/1.8 mm (0.07 in)
Spring tilt (intake)
 2.5 °/1.7 mm (0.07 in)




EAS24320

CHECKING THE VALVE LIFTERS

The following procedure applies to all of the valve lifters.

1. Check:
- Valve lifter
Damage/scratches → Replace the valve lifters and cylinder head.




EAS24340


INSTALLING THE VALVES

The following procedure applies to all of the valves and related components.


1. Deburr:
- Valve stem end
(with an oil stone)



2. Lubricate:
- Valve stem "1"
 - Valve stem seal "2"
(with the recommended lubricant)



Recommended lubricant
Molybdenum disulfide oil



3. Install:
- Valve "1"
 - Lower spring seat "2"
 - Valve stem seal "3"
 - Valve spring inner (intake only) "4"
 - Valve spring outer "5"
 - Upper spring seat "6"
(into the cylinder head)

NOTE:



- Make sure each valve is installed in its original place.
- Install the valve springs with the larger pitch "a" facing up.

VALVES AND VALVE SPRINGS

ECA13800

CAUTION:

Hitting the valve tip with excessive force could damage the valve.



b. Smaller pitch

4. Install:


- Valve cotters "1"

NOTE:

Install the valve cotters by compressing the valve spring with the valve spring compressor "2" and the valve spring compressor attachment "3".



Valve spring compressor
90890-04019
YM-04019
Valve spring compressor attachment
90890-04108
Valve spring compressor adapter 22 mm
YM-04108




6. Lubricate:


- Valve pad "1"
 - Valve lifter "2"
- (with the recommended lubricant)

NOTE:

- Lubricate the valve lifter and valve pad with molybdenum disulfide oil.
- The valve lifter must move smoothly when rotated with a finger.
- Each valve lifter and valve pad must be reinstalled in its original position.



11171102




5. To secure the valve cotters onto the valve stem, lightly tap the valve tip with a soft-face hammer.

GENERATOR AND STARTER CLUTCH

EAS4S81014

GENERATOR AND STARTER CLUTCH


Removing the generator and starter clutch



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Coolant		Drain Refer to "CHANGING THE COOLANT" on page 3-18.
	Coolant reservoir tank		Refer to "RADIATOR" on page 6-1.
	Engine oil		Drain Refer to "CHANGING THE ENGINE OIL" on page 3-12.
1	Stator coil assembly lead coupler	1	Disconnect.
2	Generator rotor cover	1	
3	Generator rotor cover gasket	1	
4	Dowel pin	2	
5	Stator coil assembly lead holder	2	
6	Stator coil assembly	1	
7	Generator rotor bolt	1	
8	Washer	1	
9	Generator rotor	1	
10	Starter clutch assembly	1	

GENERATOR AND STARTER CLUTCH

Removing the generator and starter clutch



Order	Job/Parts to remove	Q'ty	Remarks
11	Idler gear shaft	1	
12	Idler gear	1	
13	Starter clutch drive gear	1	
			For installation, reverse the removal procedure.

GENERATOR AND STARTER CLUTCH

EAS24490

REMOVING THE GENERATOR

1. Remove:
 - Seat
Refer to "GENERAL CHASSIS" on page 4-1.
 - Fuel tank
Refer to "FUEL TANK" on page 7-1.
2. Drain:
 - Coolant
Refer to "CHANGING THE COOLANT" on page 3-18.
 - Engine oil
Refer to "CHANGING THE ENGINE OIL" on page 3-12.
3. Remove:
 - Generator rotor cover

NOTE:

Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.


4. Remove:
 - Generator rotor bolt "1"
 - Washer

NOTE:

- While holding the generator rotor "2" with the sheave holder "3", loosen the generator rotor bolt.
- Do not allow the sheave holder to touch the projection on the generator rotor.



Sheave holder
90890-01701
Primary clutch holder
YS-01880-A



5. Remove:
 - Generator rotor "1"
(with the flywheel puller "2" and flywheel puller attachment)
 - Woodruff key

ECA13880

CAUTION:


To protect the end of the crankshaft, place an appropriate sized socket between the flywheel puller set's center bolt and the crankshaft.

NOTE:

Make sure the flywheel puller is centered over the generator rotor.



Flywheel puller
90890-01362
Heavy duty puller
YU-33270-B
Flywheel puller attachment
90890-04089
Crankshaft protector
YM-33282



EAS24560

REMOVING THE STARTER CLUTCH

1. Remove:
 - Starter clutch bolt "1"


NOTE:

- While holding the generator rotor with the sheave holder, remove the starter clutch bolt.
- Do not allow the sheave holder to touch the projection on the generator rotor.



Sheave holder
90890-01701
Primary clutch holder
YS-01880-A


GENERATOR AND STARTER CLUTCH




EAS24570

CHECKING THE STARTER CLUTCH

1. Check:
 - Starter clutch rollers "1"
 - Damage/wear → Replace.



2. Check:
 - Starter clutch idle gear "1"
 - Starter clutch drive gear "2"
 - Burrs/chips/roughness/wear → Replace the defective part(s).
3. Check:
 - Starter clutch gear's contacting surfaces "a"
 - Damage/pitting/wear → Replace the starter clutch gear.





4. Check:
 - Starter clutch operation

- a. Install the starter clutch drive gear "1" onto the starter clutch "2" and hold the starter clutch.
- b. When turning the starter clutch drive gear clockwise "A", the starter clutch and the starter clutch drive gear should engage,

otherwise the starter clutch is faulty and must be replaced.


- c. When turning the starter clutch drive gear counterclockwise "B", it should turn freely, otherwise the starter clutch is faulty and must be replaced.



EAS24600

INSTALLING THE STARTER CLUTCH

1. Install:
 - Starter clutch



Starter clutch bolt
32 Nm (3.2 m·kg, 23 ft·lb)
LOCTITE®


NOTE:

- While holding the generator rotor "1" with the sheave holder "2", tighten the starter clutch bolt.
- Do not allow the sheave holder to touch the projection on the generator rotor.



Sheave holder
90890-01701
Primary clutch holder
YS-01880-A

GENERATOR AND STARTER CLUTCH



EAS24500

INSTALLING THE GENERATOR

1. Install:

- Generator rotor
- Washer **New**
- Generator rotor bolt

NOTE:

- Clean the tapered portion of the crankshaft and the generator rotor hub.
- Replace the washer with a new one.

2. Tighten:

- Generator rotor bolt "1"




Generator rotor bolt
75 Nm (7.5 m·kg, 54 ft·lb)

NOTE:

- While holding the generator rotor "2" with the sheave holder "3", tighten the generator rotor bolt.
- Do not allow the sheave holder to touch the projection on the generator rotor.



Sheave holder
90890-01701
Primary clutch holder
YS-01880-A




3. Apply:

- Sealart
(onto the stator coil assembly lead grommet)



Yamaha bond No. 1215
(Three bond No.1215®)
90890-85505




4. Install:

- Stator coil

5. Install:

- Generator rotor cover



Timing plate bolt
12 Nm (1.2 m·kg, 8.7 ft·lb)

NOTE:

Tighten the generator rotor cover bolts in stages and in a crisscross pattern.

6. Fill:

- Engine oil
Refer to "CHANGING THE ENGINE OIL" on page 3-12.
- Coolant
Refer to "CHANGING THE COOLANT" on page 3-18.


7. Install:

- Fuel tank
Refer to "FUEL TANK" on page 7-1.
- Seat
Refer to "GENERAL CHASSIS" on page 4-1.

EAS4S81015

PICKUP ROTOR

Removing the pickup rotor



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Right front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Left front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Engine oil		Drain Refer to "CHANGING THE ENGINE OIL" on page 3-12.
	Generator rotor cover		Refer to "GENERATOR AND STARTER CLUTCH" on page 5-28.
1	Crankshaft position sensor lead coupler	1	Disconnect.
2	Pickup rotor cover	1	
3	Pickup rotor cover gasket	1	
4	Dowel pin	2	
5	Crankshaft position sensor	1	
6	Pickup rotor	1	
7	Cover	1	
			For assembly, reverse the removal procedure.


EAS4S81041

REMOVING THE PICKUP ROTOR

1. Remove:
 - Pickup rotor cover "1"

NOTE:

Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.





2. Remove:
 - Pickup rotor bolt "1"
 - Washer "2"
 - Pickup rotor "3"

NOTE:

While holding the generator rotor "4" with the sheave holder "5", loosen the pickup rotor bolt.



Sheave holder
90890-01701
Primary clutch holder
YS-01880-A




EAS4S81042

INSTALLING THE PICKUP ROTOR

1. Install:
 - Pickup rotor "1"
 - Washer
 - Pickup rotor bolt

NOTE:

When installing the pickup rotor, align the groove "a" in the crankshaft sprocket with the projection "b" in the pickup rotor.



2. Tighten:
 - Pickup rotor bolt "1"






Pickup rotor bolt
35 Nm (3.5 m·kg, 25 ft·lb)

NOTE:

While holding the generator rotor "2" with the sheave holder "3", tighten the pickup rotor bolt.




Sheave holder
90890-01701
Primary clutch holder
YS-01880-A



3. Apply:
- Sealant
(onto the crankshaft position sensor lead grommet)



Yamaha bond No. 1215
90890-85505
(Three Bond No.1215®)



4. Install:
- Pickup rotor cover gasket **New**
 - Pickup rotor cover


NOTE:

- When installing the pickup rotor cover, align the timing chain guide (intake side) pin "1" with the hole "2" in the pickup rotor cover.
- Tighten the pickup rotor cover bolts in stages and in a crisscross pattern.

EAS24780

ELECTRIC STARTER


Removing the starter motor



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Right front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Left front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Throttle body		Refer to "THROTTLE BODIES" on page 7-4.
1	Starter motor lead	1	
2	Starter motor	1	
			For installation, reverse the removal procedure.

ELECTRIC STARTER

Disassembling the starter motor




Order	Job/Parts to remove	Q'ty	Remarks
1	O-ring	1	
2	Starter motor front cover	1	
3	Lock washer	1	
4	Oil seal	1	
5	Bearing	1	
6	Washer set	1	
7	Starter motor rear cover	1	
8	Washer set	1	
9	O-ring	2	
10	Brush holder	1	
11	Armature assembly	1	
12	Starter motor yoke	1	
13	O-ring	2	
			For assembly, reverse the disassembly procedure.

EAS24790

CHECKING THE STARTER MOTOR

1. Check:
 - Commutator
Dirt → Clean with 600 grit sandpaper.
2. Measure:
 - Commutator diameter “a”
Out of specification → Replace the starter motor.

Limit
27.0 mm (1.06 in)



18210101

3. Measure:
 - Mica undercut “a”
Out of specification → Scrape the mica to the proper measurement with a hacksaw blade that has been grounded to fit the commutator.

Mica undercut (depth)
0.70 mm (0.03 in)

NOTE:
The mica of the commutator must be undercut to ensure proper operation of the commutator.




4. Measure:
 - Armature assembly resistances (commutator and insulation)
Out of specification → Replace the starter motor.

- a. Measure the armature assembly resistances with the pocket tester.

Pocket tester
90890-03112
Analog pocket tester
YU-03112-C


Armature coil
Commutator resistance “1”
0.0012–0.0022 Ω at 20°C (68°F)
Insulation resistance “2”
Above 1 MΩ at 20°C (68°F)

- b. If any resistance is out of specification, replace the starter motor.




5. Measure:
 - Brush length “a”
Out of specification → Replace the brushes as a set.

Limit
3.50 mm (0.14 in)



6. Measure:
 - Brush spring force
Out of specification → Replace the brush springs as a set.

Brush spring force
7.16–9.52 N (25.77–34.27 oz)
(730–971 gf)



7. Check:
 - Gear teeth
Damage/wear → Replace the gear.
8. Check:
 - Bearing
 - Oil seal
Damage/wear → Replace the defective part(s).


EAS24800

ASSEMBLING THE STARTER MOTOR

1. Install:
 - Brush seat "1"
2. Install:
 - Armature "2"
 - O-ring "3" **New**

NOTE:

Align the tab "a" on the brush seat with the slot "b" in the starter motor yoke.




3. Install:
 - Starter motor yoke "1"
 - O-ring "2" **New**
 - Starter motor front cover "3"
 - Starter motor rear cover "4"
 - Starter motor assembling bolts "5"



Starter motor assembling bolt
3.4 Nm (0.34 m·kg, 2.5 ft·lb)

NOTE:


Align the match marks "a" on the starter motor yoke with the match marks "b" on the starter motor front and rear covers.



EAS24810

INSTALLING THE STARTER MOTOR

1. Install:
 - Starter motor
 - Starter motor bolts




Starter motor bolt
10 Nm (1.0 m·kg, 7.2 ft·lb)

2. Connect:
 - Starter motor lead

EAS24920


OIL PUMP

Removing the oil pan and oil pump




Order	Job/Parts to remove	Q'ty	Remarks
	Engine oil		Drain. Refer to "CHANGING THE ENGINE OIL" on page 3-12.
	Coolant		Drain. Refer to "CHANGING THE COOLANT" on page 3-18.
	Exhaust pipe assembly		Refer to "ENGINE REMOVAL" on page 5-1.
	Water pump		Refer to "WATER PUMP" on page 6-9.
1	Oil level switch lead coupler	1	Disconnect.
2	Oil level switch	1	
3	Oil level switch lead holder	1	
4	Oil pan	1	
5	Oil pan gasket	1	
6	Dowel pin	2	
7	Oil strainer	1	
8	Oil strainer gasket	1	
9	Oil pipe	1	
10	Oil delivery pipe	1	
11	Oil pump assembly	1	
12	Dowel pin	2	

Removing the oil pan and oil pump



Order	Job/Parts to remove	Q'ty	Remarks
13	Relief valve assembly	1	
			For installation, reverse the removal procedure.

Disassembling the oil pump



Order	Job/Parts to remove	Q'ty	Remarks
1	Oil pump cover	1	
2	Pin	2	
3	Oil pump inner rotor	1	
4	Oil pump outer rotor	1	
5	Pin	1	
6	Washer	1	
7	Oil pump rotor housing	1	
8	Oil pump driven sprocket	1	
			For assembly, reverse the removal procedure.


EAS24930

REMOVING THE OIL PAN

1. Remove:
 - Oil level switch "1"
 - Oil pan "2"
 - Oil pan gasket
 - Dowel pins

NOTE:

Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.



Inner-rotor-to-outer-rotor-tip clearance

0.030–0.090 mm (0.0012–0.0035 in)

Limit


0.15 mm (0.0059 in)

Outer-rotor-to-oil-pump-housing clearance

0.030–0.080 mm (0.0012–0.0032 in)

Limit


0.150 mm (0.0059 in)




EAS24960

CHECKING THE OIL PUMP

1. Check:
 - Oil pump driven gear "1"
 - Oil pump rotor housing "2"
 - Oil pump cover
 Cracks/damage/wear → Replace the defective part(s).



1. Inner rotor
2. Outer rotor
3. Oil pump housing
3. Check:
 - Oil pump operation
 Rough movement → Repeat steps (1) and (2) or replace the defective part(s).




2. Measure:
 - Inner-rotor-to-outer-rotor-tip clearance "a"
 - Outer-rotor-to-oil-pump-housing clearance "b"

EAS24970


CHECKING THE RELIEF VALVE

1. Check:
 - Relief valve body "1"
 - Relief valve "2"
 - Spring "3"
 - O-ring "4"
 Damage/wear → Replace the defective part(s).



Damage/wear → Replace.

- Oil nozzle passage
Obstruction → Blow out with compressed air.




EAS24980

CHECKING THE OIL DELIVERY PIPES

1. Check:
 - Oil delivery pipe “1”
 - Oil pipe “2”

Damage → Replace.
Obstruction → Wash and blow out with compressed air.



EAS25010

ASSEMBLING THE OIL PUMP

1. Lubricate:
 - Inner rotor
 - Outer rotor
 - Oil pump shaft
(with the recommended lubricant)

	Recommended lubricant Engine oil
---	---

2. Install:
 - Oil pump housing “1”
 - Oil pump shaft “2”
 - Washer “3”
 - Pin “4”
 - Inner rotor “5”
 - Outer rotor “6”
 - Dowel pins “7”
 - Oil pump cover “8”
 - Oil pump housing screw

	Oil pump housing screw 12 Nm (1.2 m·kg, 8.7 ft·lb)
---	---


NOTE: When installing the inner rotor, align the pin “4” in the oil pump shaft with the groove “a” in the inner rotor “5”.

EAS24990

CHECKING THE OIL STRAINER

1. Check:
 - Oil strainer “1”

Damage → Replace.
Contaminants → Clean with solvent.



EAS4S81016


CHECKING THE OIL NOZZLES

The following procedure applies to all of the oil nozzles.

1. Check:
 - Oil nozzle “1”

Damage/wear → Replace the oil nozzle.

 - O-ring “2”



3. Check:
 - Oil pump operation
 Refer to "CHECKING THE OIL PUMP" on page 5-43.

EAS25030

INSTALLING THE OIL PUMP

1. Install:
 - Oil pump drive chain
 - Gear cover
 - Oil pump
 - Oil pump bolts

	Oil pump bolt 12 Nm (1.2 m·kg, 8.7 ft·lb)
--	--

ECA4S81018

CAUTION:

After tightening the bolts, make sure the oil pump turns smoothly.


EAS25040

INSTALLING THE OIL STRAINER

1. Install:
 - Oil strainer "1"
 - Relief valve "2"

NOTE:

Make sure to check the arrow mark "a" located on the oil strainer housing for the front and rear direction of the engine and then install the oil strainer so that its arrow mark points to the front side of the engine.



EAS25050

INSTALLING THE OIL PAN

1. Install:
 - Oil pipe
 - Oil delivery pipe
2. Install:
 - Dowel pins
 - Gasket **New**
 - Oil pan "1"

	Oil pan bolt 12 Nm (1.2 m·kg, 8.7 ft·lb)
---	---

- Oil level switch "2"

	Oil level switch bolt 10 Nm (1.0 m·kg, 7.2 ft·lb)
---	--

- Engine oil drain bolt

	Engine oil drain bolt 43 Nm (4.3 m·kg, 31 ft·lb)
---	---


EWA12820

WARNING

Always use new copper washers.

NOTE:


- Tighten the oil pan bolts in stages and in a crisscross pattern.
- Lubricate the oil level switch O-ring with engine oil.



EAS25060

CLUTCH


Removing the clutch cover



Order	Job/Parts to remove	Q'ty	Remarks
	Engine oil		Drain Refer to "CHANGING THE ENGINE OIL" on page 3-12.
	Coolant		Drain Refer to "CHANGING THE COOLANT" on page 3-18.
1	Coolant hose	1	
2	Clutch cable	1	
3	Clutch cable holder	1	
4	Clutch cover	1	
5	Clutch cover gasket	1	
6	Dowel pin	2	
			For installation, reverse the removal procedure.

* Yamaha bond No.1215 (Three Bond No.1215®)

Removing the clutch



Order	Job/Parts to remove	Q'ty	Remarks
1	Compression spring	6	
2	Pressure plate	1	
3	Pull rod	1	
4	Bearing	1	
5	Friction plate 1	6	
6	Clutch plate 1	7	
7	Friction plate 2	2	
8	Clutch plate 2	1	
9	Clutch boss nut	1	
10	Lock washer	1	
11	Clutch boss	1	
12	Thrust plate	1	
			For assembly, reverse the removal procedure.

EAS25070


REMOVING THE CLUTCH

1. Remove:

- Clutch cable holder "1"
- Clutch cover "2"
- Gasket


NOTE:

Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.



2. Remove:

- Compression spring bolts "1"
- Compression springs
- Pressure plate "2"
- Pull rod "3"
- Friction plates
- Clutch plates



3. Straighten the lock washer tab.

4. Loosen:


- Clutch boss nut "1"

NOTE:

While holding the clutch boss "2" with the universal clutch holder, loosen the clutch boss nut.




Universal clutch holder
90890-04086
YM-91042



5. Remove:

- Clutch boss nut "1"
- Lock washer "2"
- Clutch boss "3"
- Thrust plate "4"



EAS25100

CHECKING THE FRICTION PLATES

The following procedure applies to all of the friction plates.

1. Check:

- Friction plate
Damage/wear → Replace the friction plates as a set.

2. Measure:


- Friction plate thickness
Out of specification → Replace the friction plates as a set.

NOTE:

Measure the friction plate at four places.



Friction plate thickness
2.92–3.08 mm (0.115–0.121 in)
Wear limit
2.80 mm (0.1102 in)



1141101

EAS25110


CHECKING THE CLUTCH PLATES

The following procedure applies to all of the clutch plates.

1. Check:
 - Clutch plate
Damage → Replace the clutch plates as a set.
2. Measure:
 - Clutch plate warpage
(with a surface plate and thickness gauge “1”)
Out of specification → Replace the clutch plates as a set.



Warpage limit
0.10 mm (0.0039 in)



EAS25140


CHECKING THE CLUTCH SPRINGS

The following procedure applies to all of the clutch springs.

1. Check:
 - Clutch spring
Damage → Replace the clutch springs as a set.
2. Measure:
 - Clutch spring free length “a”
Out of specification → Replace the clutch springs as a set.



Clutch spring free length
55.00 mm (2.17 in)
Minimum length
54.00 mm (2.13 in)
Limit
52.3 mm (2.06 in)




EAS25150

CHECKING THE CLUTCH HOUSING

1. Check:
 - Clutch housing dogs “1”
Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.

NOTE:

Pitting on the clutch housing dogs will cause erratic clutch operation.



1141201

2. Check:
 - Bearing
Damage/wear → Replace the bearing and clutch housing.


EAS25160

CHECKING THE CLUTCH BOSS

1. Check:
 - Clutch boss splines
Damage/pitting/wear → Replace the clutch boss.

NOTE:

Pitting on the clutch boss splines will cause erratic clutch operation.




EAS25170

CHECKING THE PRESSURE PLATE

1. Check:

- Pressure plate “1”
Cracks/damage → Replace.
- Bearing “2”
Damage/wear → Replace.




EAS25220

CHECKING THE PULL LEVER SHAFT AND PULL ROD

1. Check:

- Pull lever shaft pinion gear teeth “1”
- Pull rod teeth “2”
Damage/wear → Replace the pull rod and pull lever shaft pinion gear as a set.



2. Check:


- Pull rod bearing
Damage/wear → Replace.

EAS25270

INSTALLING THE CLUTCH

1. Install:

- Thrust plate “1”
- Clutch boss “2”
- Lock washer “3” **New**
- Clutch boss nut “4”



2. Tighten:


- Clutch boss nut

	Clutch boss nut 90 Nm (9.0 m·kg, 65 ft·lb)
---	--

NOTE:

While holding the clutch boss with the universal clutch holder “1”, tighten the clutch boss nut.

	Universal clutch holder 90890-04086 YM-91042
---	---



3. Bend the lock washer tab along a flat side of the nut.

4. Lubricate:

- Friction plates
- Clutch plates
(with the recommended lubricant)

	Recommended lubricant Engine oil
---	--

5. Install:
- Friction plates
 - Clutch plates

NOTE: _____
 First, install a friction plate and then alternate between a clutch plate and a friction plate.




a Install the clutch plate and friction plate as shown in the illustration.

Clutch plate "1": t=2.3 mm (0.09 in)

Clutch plate "2": t=2.0 mm (0.08 in)


Friction plate "3"

Friction plate "4": Color/Brown



6. Install:
- Pressure plate "1"


NOTE: _____
 Align the punch mark "a" in the pressure plate with the punch mark "b" in the clutch boss.



7. Install:
- Bearing "1"
 - Pull rod "2"
 - Pressure plate "3"
 - Clutch springs
 - Clutch spring bolts

	<p>Clutch spring bolt 8 Nm (0.8 m·kg, 5.8 ft·lb)</p>
---	---


NOTE: _____
 Tighten the clutch spring bolts in stages and in a crisscross pattern.



8. Install:
- Pull lever
9. Install:
- Clutch cover
 - Gasket **New**
 - Clutch cable holder

NOTE: _____

- Install the pull rod so that the teeth a face towards the rear of the vehicle. Then, install the clutch cover.
- Apply oil onto the bearing.
- Apply molybdenum disulfide grease onto the pull rod.
- When installing the clutch cover, push the pull lever and check that the punch mark "a" on the pull lever aligns with the mark "b" on the clutch cover. Make sure that the pull rod teeth and pull lever shaft pinion gear are engaged.
- Tighten the clutch cover bolts in stages and in a crisscross pattern.




10. Adjust:
- Clutch cable free play
- Refer to "ADJUSTING THE CLUTCH CABLE FREE PLAY" on page 3-14.

EAS25410

SHIFT SHAFT

Removing the shift shaft and stopper lever





Order	Job/Parts to remove	Q'ty	Remarks
	Drive sprocket cover		Refer to "ENGINE REMOVAL" on page 5-1.
1	Shift shaft cover	1	
2	Shift shaft cover gasket	1	
3	Dowel pin	2	
4	Oil seal	1	
5	Shift shaft	1	
6	Shift shaft spring	1	
7	Collar	1	
8	Stopper lever spring	1	
9	Circlip	1	
10	Washer	1	
11	Stopper lever	1	
12	Collar	1	
13	Washer	1	
14	Shift shaft spring stopper	1	
			For installation, reverse the removal procedure.

EAS25420

CHECKING THE SHIFT SHAFT

1. Check:

- Shift shaft "1"
Bends/damage/wear → Replace.
- Shift shaft spring "2"
Damage/wear → Replace.



2. Install:

- Shift shaft cover

NOTE:


Lubricate the oil seal lips with lithium-soap-based grease.

EAS25430

CHECKING THE STOPPER LEVER

1. Check:

- Stopper lever "1"
Bends/damage → Replace.
Roller turns roughly → Replace the stopper lever.



EAS25450

INSTALLING THE SHIFT SHAFT

1. Install:

- Shift shaft spring stopper "1"
- Washers
- Shift shaft "2"


NOTE:

- Apply LOCTITE® to the threads of the shift shaft spring stopper.
- Hook the ends of the stopper lever spring "3" onto the stopper lever "4" and the crankcase boss.
- Mesh the stopper lever with the shift drum segment assembly.

EAS25540


CRANKCASE

Separating the crankcase



Order	Job/Parts to remove	Q'ty	Remarks
	Engine		Refer to "ENGINE REMOVAL" on page 5-1.
	Cylinder head		Refer to "CYLINDER HEAD" on page 5-16.
	Generator		Refer to "GENERATOR AND STARTER CLUTCH" on page 5-28.
	Starter clutch		Refer to "GENERATOR AND STARTER CLUTCH" on page 5-28.
	Shift shaft		Refer to "SHIFT SHAFT" on page 5-53.
	Crankshaft position sensor		Refer to "PICKUP ROTOR" on page 5-33.
	Pickup rotor		Refer to "PICKUP ROTOR" on page 5-33.
	Clutch		Refer to "CLUTCH" on page 5-46.
	Water pump		Refer to "WATER PUMP" on page 6-9.
	Oil pan		Refer to "OIL PUMP" on page 5-40.
	Oil pump		Refer to "OIL PUMP" on page 5-40.
1	Timing chain	1	
2	Oil pump drive chain	1	
3	Oil pump drive chain guide	1	
4	Lower crankcase	1	
5	Dowel pin	3	
6	Thrust plate	1	
7	Washer	1	

Separating the crankcase



Order	Job/Parts to remove	Q'ty	Remarks
8	Plate	1	
			For installation, reverse the removal procedure.

EAS25550


DISASSEMBLING THE CRANKCASE

1. Place the engine upside down.
2. Remove:
 - Crankcase bolts

NOTE:

- Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.
- Loosen the bolts in decreasing numerical order (refer to the numbers in the illustration).
- The numbers embossed on the crankcase indicate the crankcase tightening sequence.

M8 × 85 mm (3.3 in) bolts: “1”–“7”, “10”
 M8 × 115 mm (4.5 in) bolts: “8”, “9”
 M8 × 65 mm (2.6 in) bolts: “11”, “12”
 M6 × 65 mm (2.6 in) bolts: “13”, “14”
 M6 × 55 mm (2.2 in) bolts: “15”, “22”–“26”
 M6 × 45 mm (1.8 in) bolts: “16”, “19”, “20”
 M6 × 65 mm (2.6 in) bolts: “17”, “27”
 M6 × 75 mm (3.0 in) bolt: “18”
 M6 × 100 mm (3.9 in) bolt: “21”



3. Remove:
 - Lower crankcase

ECA13900

CAUTION:

Tap on one side of the crankcase with a soft-face hammer. Tap only on reinforced portions of the crankcase, not on the crankcase mating surfaces. Work slowly and carefully and make sure the crankcase halves separate evenly.

4. Remove:
 - Dowel pins
5. Remove:
 - Crankshaft journal lower bearing (from the lower crankcase)

NOTE:

Identify the position of each crankshaft journal lower bearing so that it can be reinstalled in its original place.

EAS25580

CHECKING THE CRANKCASE

1. Thoroughly wash the crankcase halves in a mild solvent.
2. Thoroughly clean all the gasket surfaces and crankcase mating surfaces.
3. Check:
 - Crankcase
Cracks/damage → Replace.
 - Oil delivery passages
Obstruction → Blow out with compressed air.

EAS4S81034


CHECKING THE BEARINGS AND OIL SEALS

1. Check:
 - Bearings
Clean and lubricate the bearings, then rotate the inner race with your finger. Rough movement → Replace.
2. Check:
 - Oil seals
Damage/wear → Replace.

EAS25620

CHECKING THE OIL PUMP DRIVE CHAIN

1. Check:
 - Oil pump drive chain “1”
Damage/stiffness → Replace the oil pump drive chain, oil pump drive sprocket and oil pump shaft as a set.



2. Check:
 - Oil pump drive sprocket
Cracks/damage/wear → Replace the oil pump drive sprocket and the oil pump drive chain as a set.

EAS25660

ASSEMBLING THE CRANKCASE

- Lubricate:
 - Crankshaft journal bearings (with the recommended lubricant)



Recommended lubricant
Engine oil


- Apply:
 - Sealant (onto the crankcase mating surfaces)



Yamaha bond No. 1215
(Three bond No. 1215®)
90890-85505

NOTE:

Do not allow any sealant to come into contact with the oil gallery or crankshaft journal bearings. Do not apply sealant to within 2–3 mm of the crankshaft journal bearings.




- Install:
 - Dowel pin
- Set the shift drum assembly and transmission gears in the neutral position.
- Install:
 - Lower crankcase “1” (onto the upper crankcase “2”)

ECA13980

CAUTION:

Before tightening the crankcase bolts, make sure the transmission gears shift correctly when the shift drum assembly is turned by hand.



- Install:
 - Crankcase bolts

NOTE:

- Lubricate the bolt threads with engine oil.
- Install a washer on bolts “1”–“10”
- Seal bolt “18”
- Tighten the bolts in the tightening sequence cast on the crankcase.

M8 × 85 mm (3.3 in) bolts: “1”–“7”, “10”
 M8 × 115 mm (4.5 in) bolts: “8”, “9”
 M8 × 65 mm (2.6 in) bolts: “11”, “12”
 M6 × 65 mm (2.6 in) bolts: “13”, “14”
 M6 × 55 mm (2.2 in) bolts: “15”, “22”–“26”
 M6 × 45 mm (1.8 in) bolts: “16”, “19”, “20”
 M6 × 65 mm (2.6 in) bolts: “17”, “27”
 M6 × 75 mm (3.0 in) bolt: “18” LOCTITE®
 M6 × 100 mm (3.9 in) bolt: “21”



Crankcase bolt

Bolt “1”–“10”

1st: 12 Nm (1.2 m·kg, 8.7 ft·lb)

2nd: 25 Nm (2.5 m·kg, 18 ft·lb)

3rd*: 27 Nm (2.7 m·kg, 20 ft·lb)

Bolt “11”, “12”

24 Nm (2.4 m·kg, 17 ft·lb)

Bolt “13”, “14”


14 Nm (1.4 m·kg, 1.0 ft·lb)

Bolt “15”–“27”

12 Nm (1.2 m·kg, 8.7 ft·lb)

*Loosen the bolts following the tightening order and then tighten to specification torque.


CRANKCASE



EAS25950


CRANKSHAFT

Removing the connecting rods and pistons



Order	Job/Parts to remove	Q'ty	Remarks
	Lower crankcase		Refer to "CRANKCASE" on page 5-55.
1	Connecting rod cap	4	
2	Big end lower bearing	4	
3	Big end upper bearing	4	
4	Piston pin clip	8	
5	Piston pin	4	
6	Piston	4	
7	Connecting rod	4	
8	Top ring	4	
9	2nd ring	4	
10	Oil ring	4	
			For installation, reverse the removal procedure.

Removing the crankshaft



Order	Job/Parts to remove	Q'ty	Remarks
	Crankcase		Separate. Refer to "CRANKCASE" on page 5-55.
	Connecting rods caps		Refer to "CRANKSHAFT" on page 5-60.
1	Crankshaft	1	
2	Crankshaft journal lower bearing	5	
3	Crankshaft journal upper bearing	5	
			For installation, reverse the removal procedure.

EAS26030


REMOVING THE CONNECTING RODS AND PISTONS

The following procedure applies to all of the connecting rods and pistons.

1. Remove:
 - Connecting rod cap "1"
 - Big end bearings

NOTE: _____

Identify the position of each big end bearing so that it can be reinstalled in its original place.



2. Remove:
 - Piston pin clips "1"
 - Piston pin "2"
 - Piston "3"

ECA4S81024

CAUTION: _____



Do not use a hammer to drive the piston pin out.

NOTE: _____

- For reference during installation, put identification marks on the piston crown.
- Before removing the piston pin, deburr the piston pin clip groove and the piston pin bore area. If both areas are deburred and the piston pin is still difficult to remove, remove it with the piston pin puller set "4".




Piston pin puller set
90890-01304
Piston pin puller
YU-01304



3. Remove:
 - Top ring
 - 2nd ring
 - Oil ring

NOTE: _____

When removing a piston ring, open the end gap with your fingers and lift the other side of the ring over the piston crown.



EAS25980

REMOVING THE CRANKSHAFT ASSEMBLY

1. Remove:
 - Crankshaft assembly
 - Crankshaft journal upper bearings (from the upper crankcase)

Refer to "CRANKSHAFT" on page 5-60.

NOTE: _____

Identify the position of each crankshaft journal upper bearing so that it can be reinstalled in its original place.

EAS24390

CHECKING THE CYLINDER AND PISTON

1. Check:

- Piston wall
 - Cylinder wall
- Vertical scratches → Replace the cylinder, and replace the piston and piston rings as a set.

2. Measure:

- Piston-to-cylinder clearance



- a. Measure cylinder bore "C" with the cylinder bore gauge.

NOTE:

Measure cylinder bore "C" by taking side-to-side and front-to-back measurements of the cylinder. Then, find the average of the measurements.




Bore
65.500–65.510 mm (2.5787–2.5791 in)
Wear limit
65.56 mm (2.5811 in)
Taper limit
0.050 mm (0.0020 in)
Out of round limit
0.050 mm (0.0020 in)

"C" = maximum of D_1 – D_6

"T" = maximum of D_1 or D_2 - maximum of D_5 or D_6

"R" = maximum of D_1 , D_3 or D_5 - minimum of D_2 , D_4 or D_6




- b. If out of specification, replace the cylinder, and replace the piston and piston rings as a set.
- c. Measure piston skirt diameter "P" with the micrometer.



Piston size "P"

Standard

65.475–65.490 mm (2.5778–2.5783 in)



- a. 4 mm (0.16 in) from the bottom edge of the piston
- d. If out of specification, replace the piston and piston rings as a set.
- e. Calculate the piston-to-cylinder clearance with the following formula.

• Piston-to-cylinder clearance =
Cylinder bore "C" -
Piston skirt diameter "P"



Piston-to-cylinder clearance

0.010–0.035 mm (0.0004–0.0014 in)

Limit

0.05 mm (0.0020 in)

- f. If out of specification, replace the cylinder, and the piston and piston rings as a set.



EAS24430

CHECKING THE PISTON RINGS

1. Measure:

- Piston ring side clearance
- Out of specification → Replace the piston and piston rings as a set.


NOTE:

Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston rings.



Top ring
Ring side clearance
 0.030–0.065 mm (0.0012–0.0026 in)
Limit
 0.115 mm (0.0045 in)

2nd ring
Ring side clearance
 0.030–0.065 mm (0.0012–0.0026 in)
Limit
 0.125 mm (0.0049 in)




11221402

2. Install:
- Piston ring (into the cylinder)

NOTE:

Level the piston ring into the cylinder with the piston crown.



11221401

- a. 5 mm (0.20 in)
3. Measure:
- Piston ring end gap
 Out of specification → Replace the piston ring.

NOTE:

The oil ring expander spacer's end gap cannot be measured. If the oil ring rail's gap is excessive, replace all three piston rings.



Top ring
End gap (installed)
 0.25–0.35 mm (0.0098–0.0138 in)
Limit
 0.60 mm (0.0236 in)

2nd ring
End gap (installed)
 0.70–0.80 mm (0.0276–0.0315 in)
Limit
 1.15 mm (0.0453 in)

Oil ring
End gap (installed)
 0.10–0.35 mm (0.0039–0.0138 in)

EAS24440


CHECKING THE PISTON PINS

The following procedure applies to all of the piston pins.

1. Check:
 - Piston pin
 Blue discoloration/grooves → Replace the piston pin and then check the lubrication system.
2. Measure:
 - Piston pin outside diameter "a"
 Out of specification → Replace the piston pin.




Piston pin outside diameter
 15.991–16.000 mm (0.6296–0.6299 in)
Limit
 15.971 mm (0.6288 in)



3. Measure:
 - Piston pin bore inside diameter "b"
 Out of specification → Replace the piston.



Piston pin bore inside diameter
 16.002–16.013 mm (0.6300–0.6304 in)
Limit
 16.043 mm (0.6316 in)



4. Calculate:

- Piston-pin-to-piston-pin-bore clearance
 Out of specification → Replace the piston pin and piston as a set.

• Piston-pin-to-piston-pin-bore clearance =
 Piston pin bore diameter “b” -
 Piston pin outside diameter “a”



Piston-pin-to-piston-pin-bore clearance
 0.002–0.022 mm (0.0001–0.0009 in)
Limit
 0.072 mm (0.0028 in)

EAS4S81037

CHECKING THE BIG END BEARINGS

1. Measure:

- Crankshaft-pin-to-big-end-bearing clearance
 Out of specification → Replace the big end bearings.



Crankshaft-pin-to-big-end-bearing clearance
 0.028–0.052 mm
 (0.0011–0.0020 in)

The following procedure applies to all of the connecting rods.

ECA4S81025

CAUTION:


Do not interchange the big end bearings and connecting rods. To obtain the correct crankshaft-pin-to-big-end-bearing clearance and prevent engine damage, the big

end bearings must be installed in their original positions.

- Clean the big end bearings, crankshaft pins, and the inside of the connecting rod halves.
- Install the big end upper bearing into the connecting rod and the big end lower bearing into the connecting rod cap.


NOTE:

Align the projections “a” on the big end bearings with the notches “b” in the connecting rod and connecting rod cap.



I1630301




- Put a piece of Plastigauge® “1” on the crankshaft pin.



- Assemble the connecting rod halves.

NOTE:

- Do not move the connecting rod or crankshaft until the clearance measurement has been completed.
- Lubricate the bolt threads and seats with molybdenum disulfide grease.
- Make sure that the “Y” mark “c” on the connecting rod faces towards the left side of the crankshaft.
- Make sure that the characters “d” on both the connecting rod and connecting rod cap are aligned.



e. Tighten the connecting rod bolts.

NOTE:

Install by carrying out the following procedures in order to assemble in the most suitable condition.

- Connecting rod bolts

	Connecting rod bolt 24.5 Nm (2.5 m·kg, 17.7 ft·lb)
---	---

- Replace the connecting rod bolts with new ones.
- Clean the connecting rod bolts.
- After installing the big end bearing, assemble the connecting rod and connecting rod cap once using a single unit of the connecting rod.
- Tighten the connecting rod bolt while checking that the sections shown "a" and "b" are flush with each other by touching the surface.
 - Side machined face "a"
 - Thrusting faces (4 places at front and rear "b")

NOTE:

To install the big end bearing, care should be taken not to install it at an angle and the position should not be out of alignment.

- Loosen the connecting rod bolt, remove the connecting rod and connecting rod cap and install these parts to the crankshaft with the big end bearing kept in the current condition.
- Tighten the connecting rod bolts.


	Connecting rod bolt 15 Nm (1.5 m·kg, 11 ft·lb) + 120°
---	--

ECA4S81026


CAUTION:

Tighten the connecting rod bolts using the plastic-region tightening angle method. Always install new bolts.

- Clean the connecting rod bolts.
- Tighten the connecting rod bolts.
- Put a mark "1" on the corner of the connecting rod bolt "2" and the connecting rod cap "3"



- Tighten the bolt further to reach the specified angle (120°).



p. After the installation, check that the section show "a" is flush with each other by touching the surface.

- Side machined face "a"

EWA4S81014


WARNING

- When the bolt is tightened more than the specified angle, do not loosen the bolt and then retighten it. Replace the bolt with a new one and perform the procedure again.
- If they are not flush with each other, remove the connecting rod bolt and big end bearing and restart from step "e". In this case, make sure to replace the connecting rod bolt.

ECA4S81027

CAUTION:


- Do not use a torque wrench to tighten the nut to the specified angle.
- Tighten the bolt until it is at the specified angles.



q. Remove the connecting rod and big end bearings. Refer to "REMOVING THE CONNECTING RODS AND PISTONS" on page 5-62.

r. Measure the compressed Plastigauge® width on the crankshaft pin.

If the crankshaft-pin-to-big-end-bearing clearance is out of specification, select replacement big end bearings.



2. Select:

- Big end bearings (P1–P4)


NOTE:


- The numbers "A" stamped into the crankshaft web and the numbers "1" on the connecting rods are used to determine the replacement big end bearing sizes.
- "P1"–"P4" refer to the bearings shown in the crankshaft illustration.

For example, if the connecting rod "P₁" and the crankshaft web "P₁" numbers are "5" and "2" respectively, then the bearing size for "P₁" is:

P ₁ (connecting rod) – P ₁ (crankshaft web) =
5 – 2 = 3 (brown)

COLOR CODE	
1	Blue
2	Black
3	Brown
4	Green





EAS26190

INSTALLING THE CONNECTING ROD AND PISTON


The following procedure applies to all of the connecting rods and pistons.

1. Install:

- Top ring "1"
- 2nd ring "2"
- Upper oil ring rail "3"
- Oil ring expander "4"
- Lower oil ring rail "5"

NOTE:

Be sure to install the piston rings so that the manufacturer's marks or numbers "a" face up.




2. Install:

- Piston "1"
- (onto the respective connecting rod "2")
- Piston pin "3"
- Piston pin clip "4" **New**

NOTE:

- Apply engine oil onto the piston pin.

- Make sure that the "Y" mark "a" on the connecting rod faces left when the arrow mark "b" on the piston is pointing up as shown.
- Reinstall each piston into its original cylinder (numbering order starting from the left: #1 to #4).




3. Lubricate:

- Piston
- Piston rings
- Cylinder (with the recommended lubricant)



4. Offset:

- Piston ring end gaps



11221202

- a. Top ring
- b. Lower oil ring rail
- c. Upper oil ring rail
- d. 2nd ring
- e. Oil ring expander

5. Lubricate:



- Crankshaft pins
- Big end bearings
- Connecting rod big end inner surface (with the recommended lubricant)



6. Install:
- Big end bearings
 - Connecting rod cap (onto the connecting rod)

NOTE:

- Align the projections on the big end bearings with the notches in the connecting rods and connecting rod caps.
- Make sure that the characters “a” on both the connecting rod and connecting rod cap are aligned.



- a. Side machined face
- b. Thrusting faces (4 places at front and rear)

NOTE:

To install the big end bearing, care should be taken not to install it at an angle and the position should not be out of alignment.

7. Tighten:
- Connecting rod bolts



Connecting rod bolt
24.5 Nm (2.5 m·kg, 17.7 ft·lb)

NOTE:

Install by carrying out the following procedures in order to assemble in the most suitable condition.

- a. Replace the connecting rod bolts with new ones.
- b. Clean the connecting rod bolts.
- c. After installing the big end bearing, assemble the connecting rod and connecting rod cap once using a single unit of the connecting rod.
- d. Tighten the connecting rod bolt while checking that the sections shown “a” and “b” are flush with each other by touching the surface.

- e. Loosen the connecting rod bolt, remove the connecting rod and connecting rod cap and install these parts to the crankshaft with the big end bearing kept in the current condition.




8. Install:

- Connecting rod assembly (into the cylinder and onto the crankshaft pin)

NOTE:

- While compressing the piston rings with one hand, install the connecting rod assembly into the cylinder with the other hand.
- Make sure that the “Y” marks “a” on the connecting rods face towards the left side of the crankshaft.



9. Tighten:
- Connecting rod bolts



Connecting rod bolt
15 Nm (1.5 m·kg, 11 ft·lb) + 120°




ECA14980


CAUTION:

Tighten the connecting rod bolts using the plastic-region tightening angle method.


- a. Clean the connecting rod bolts.
- b. Tighten the connecting rod bolts.
- c. Put a mark "1" on the corner of the connecting rod bolt "2" and the connecting rod cap "3".



- d. Tighten the bolt further to reach the specified angle (120°).



- e. After the installation, check that the section shown "a" is flush with each other by touching the surface.



a. Side machined face

EWA13990

WARNING

- When the bolt is tightened more than the specified angle, do not loosen the bolt and then retighten it. Replace the bolt

with a new one and perform the procedure again.

- If they are not flush with each other, remove the connecting rod bolt and big end bearing and restart from step "7". In this case, make sure to replace the connecting rod bolt.

ECA4S81029

CAUTION:

- Do not use a torque wrench to tighten the bolt to the specified angle.
- Tighten the bolt until it is at the specified angles.




EAS4S81038

CHECKING THE CRANKSHAFT

1. Measure:
 - Crankshaft runout
 Out of specification → Replace the crankshaft.

	<p>Crankshaft runout Less than 0.03 mm (0.0012 in)</p>
--	---



11631006

2. Check:
 - Crankshaft journal surfaces
 - Crankshaft pin surfaces
 - Bearing surfaces
 Scratches/wear → Replace the crankshaft.

EAS4S81039

CHECKING THE CRANKSHAFT JOURNAL BEARINGS

1. Measure:
 - Crankshaft-journal-to-crankshaft-journal-bearing clearance
 Out of specification → Replace the crankshaft journal bearings.

	<p>Crankshaft-journal-to-crankshaft journal bearing clearance 0.034–0.058 mm (0.0013–0.0023 in)</p>
--	--

ECA4S81028

CAUTION:


Do not interchange the crankshaft journal bearings. To obtain the correct crankshaft-journal- to-crankshaft-journal-bearing clearance and prevent engine damage, the crankshaft journal bearings must be installed in their original positions.



- a. Clean the crankshaft journal bearings, crankshaft journals, and bearing portions of the crankcase.
- b. Place the upper crankcase upside down on a bench.
- c. Install the crankshaft journal upper bearings "1" and the crankshaft into the upper crankcase.

NOTE:


Align the projections "a" on the crankshaft journal upper bearings with the notches "b" in the upper crankcase.



- d. Put a piece of Plastigauge® "2" on each crankshaft journal.

NOTE:


Do not put the Plastigauge® over the oil hole in the crankshaft journal.



- e. Install the crankshaft journal lower bearings "1" into the lower crankcase and assemble the crankcase halves.

NOTE:

- Align the projections "a" of the crankshaft journal lower bearings with the notches "b" in the lower crankcase.
- Do not move the crankshaft until the clearance measurement has been completed.



- f. Tighten the bolts to specification in the tightening sequence cast on the crankcase.



Crankcase bolt

Bolt "1"-"10"

1st: 12 Nm (1.2 m·kg, 8.7 ft·lb)

2nd: 25 Nm (2.5 m·kg, 18 ft·lb)

3rd*: 27 Nm (2.7 m·kg, 20 ft·lb)

Bolt "11", "12"

24 Nm (2.4 m·kg, 17 ft·lb)

Bolt "13", "14"

14 Nm (1.4 m·kg, 1.0 ft·lb)


Bolt "15"-"27"

12 Nm (1.2 m·kg, 8.7 ft·lb)

*Loosen the bolts following the tightening order and then tighten to specification torque.

NOTE:

Lubricate the crankcase bolt threads with engine oil.
Refer to "CRANKCASE" on page 5-55.






“2” respectively, than the bearing size for “J₁” is:

$\begin{aligned} & \text{“J}_1\text{” (crankcase) – “J}_1\text{”} \\ & \text{(crankshaft web) – 1 =} \\ & 6 - 2 - 1 = 3 \text{ (brown)} \end{aligned}$
--

CRANKSHAFT JOURNAL BEARING COLOR CODE	
0	White
1	Blue
2	Black
3	Brown
4	Green


- g. Remove the lower crankcase and the crankshaft journal lower bearings.
- h. Measure the compressed Plastigauge® width “c” on each crankshaft journal. If the crankshaft-journal-to-crankshaft-journal-bearing clearance is out of specification, select replacement crankshaft journal bearings.



2. Select:
- Crankshaft journal bearings (J₁–J₅)

NOTE:

- The numbers “A” stamped into the crankshaft web and the numbers “1” stamped into the lower crankcase are used to determine the replacement crankshaft journal bearing sizes.
- “J₁–J₅” refer to the bearings shown in the crankshaft illustration.
- If “J₁–J₅” are the same, use the same size for all of the bearings.
- If the size is the same for all “J₁ to J₅” one digit for that size is indicated. (Crankcase side only)



For example, if the crankcase “J₁” and crankshaft web “J₁” numbers are “6” and

EAS4S81040


INSTALLING THE CRANKSHAFT

1. Install:
 - Crankshaft journal upper bearings “1” (into the upper crankcase)

NOTE:

- Align the projections “a” on the crankshaft journal upper bearings with the notches “b” in the upper crankcase.

- Be sure to install each crankshaft journal upper bearing in its original place.




2. Install:
 - Crankshaft
3. Install:
 - Lower crankcaseRefer to "CRANKCASE" on page 5-55.

EAS26240


TRANSMISSION

Removing the transmission, shift drum assembly, and shift forks




Order	Job/Parts to remove	Q'ty	Remarks
	Lower crankcase	1	Refer to "CRANKCASE" on page 5-55.
1	Drive axle assembly	1	
2	Circlip	1	
3	Oil seal	1	
4	Bearing	1	
5	Shift drum retainer	1	
6	Shift fork guide bar	2	
7	Spring	4	
8	Shift fork-L	1	
9	Shift fork-R	1	
10	Shift drum assembly	1	
11	Shift fork-C	1	
12	Main axle assembly	1	
13	Oil pipe	1	
14	Oil baffle plate	1	
15	Thrust plate	1	
16	Washer	1	
			For installation, reverse the removal procedure.

Disassembling the main axle assembly




Order	Job/Parts to remove	Q'ty	Remarks
1	Bearing	1	
2	2nd pinion gear	1	
3	Toothed lock washer	1	
4	Toothed lock washer retainer	1	
5	6th pinion gear	1	
6	Collar	1	
7	Washer	1	
8	Circlip	1	
9	3rd pinion gear	1	
10	Circlip	1	
11	Washer	1	
12	5th pinion gear	1	
13	Collar	1	
14	Main axle	1	
15	Bearing housing	1	
16	Bearing	1	
			For installation, reverse the removal procedure.

Disassembling the drive axle assembly



Order	Job/Parts to remove	Q'ty	Remarks
1	Washer	1	
2	1st wheel gear	1	
3	Collar	1	
4	5th wheel gear	1	
5	Circlip	1	
6	Washer	1	
7	Collar	1	
8	3rd wheel gear	1	
9	Toothed lock washer	1	
10	Toothed lock washer retainer	1	
11	4th wheel gear	1	
12	Collar	1	
13	Washer	1	
14	Circlip	1	
15	6th wheel gear	1	
16	Circlip	1	
17	Washer	1	
18	2nd wheel gear	1	
19	Collar	1	
20	Collar	1	
21	Oil seal	1	
22	Bearing	1	
23	Circlip	1	
24	Drive axle	1	

Disassembling the drive axle assembly




Order	Job/Parts to remove	Q'ty	Remarks
			For installation, reverse the removal procedure.


EAS26250

REMOVING THE TRANSMISSION

1. Remove:
 - Main axle assembly "1" (with the Torx® wrench)



- a. Insert two bolts "2" of the proper size, as shown in the illustration, into the main axle assembly bearing housing.
- b. Tighten the bolts until they contact the crankcase surface.
- c. Continue tightening the bolts until the main axle assembly comes free from the upper crankcase.




EAS26260

CHECKING THE SHIFT FORKS

The following procedure applies to all of the shift forks.

1. Check:
 - Shift fork cam follower "1"
 - Shift fork pawl "2"
 Bends/damage/scoring/wear → Replace the shift fork.




2. Check:
 - Shift fork guide bar
 Roll the shift fork guide bar on a flat surface.
 Bends → Replace.

EWA12840


WARNING

Do not attempt to straighten a bent shift fork guide bar.



319-010

3. Check:
 - Shift fork movement (along the shift fork guide bar)
 Rough movement → Replace the shift forks and shift fork guide bar as a set.




319-011

EAS26270

CHECKING THE SHIFT DRUM ASSEMBLY

1. Check:
 - Shift drum groove
 - Shift drum segment "1"
 Damage/scratches/wear → Replace the shift drum assembly.

- Shift drum bearing “2”
Damage/pitting → Replace the shift drum assembly.





11530101

EAS26300



CHECKING THE TRANSMISSION

1. Measure:
 - Main axle runout
(with a centering device and dial gauge “1”)
Out of specification → Replace the main axle.



11650702


2. Measure:
 - Drive axle runout
(with a centering device and dial gauge “1”)
Out of specification → Replace the drive axle.



11650701

3. Check:

- Transmission gears
Blue discoloration/pitting/wear → Replace the defective gear(s).
- Transmission gear dogs
Cracks/damage/rounded edges → Replace the defective gear(s).



4. Check:
 - Transmission gear engagement
(each pinion gear to its respective wheel gear)
Incorrect → Reassemble the transmission axle assemblies.
5. Check:
 - Transmission gear movement
Rough movement → Replace the defective part(s).
6. Check:
 - Circlips
Bends/damage/looseness → Replace.

EAS26350

INSTALLING THE TRANSMISSION


1. Install:
 - Oil pipe “1”
 - Main axle assembly “2”
(with the Torx® wrench)

NOTE: _____
Make sure to caulk the bolts at three positions after installing the bearing housing.

2. Install:
 - Shift fork-C “3”
 - Shift drum assembly “4”
 - Shift fork guide bar

NOTE: _____
• The embossed marks on the shift forks should face towards the right side of the engine and be in the following sequence: “R”, “C”, “L”.
• Carefully position the shift forks so that they are installed correctly into the transmission gears.

- Install shift fork-C into the groove in the 3rd and 4th pinion gear on the main axle.





3. Install:
- Shift fork-R “1”
 - Shift fork-L “2”
 - Drive axle “3”
 - Shift fork guide bar
 - Shift drum retainer



Shift drum retainer bolt
10 Nm (1.0 m·kg, 7.2 ft·lb)
LOCTITE®

NOTE:

- Install shift fork-L into the groove in the 6th wheel gear and shift fork-R into the groove in the 5th wheel gear on the drive axle.
- Make sure that the drive axle bearing circlip “a” is inserted into the grooves in the upper crankcase.



4. Check:
- Transmission
Rough movement → Repair.

NOTE:

Oil each gear, shaft, and bearing thoroughly.


COOLING SYSTEM

RADIATOR	6-1
CHECKING THE RADIATOR.....	6-3
INSTALLING THE RADIATOR.....	6-3
OIL COOLER	6-4
CHECKING THE OIL COOLER.....	6-5
INSTALLING THE OIL COOLER.....	6-5
THERMOSTAT	6-6
CHECKING THE THERMOSTAT.....	6-7
INSTALLING THE THERMOSTAT ASSEMBLY.....	6-7
WATER PUMP	6-9
DISASSEMBLING THE WATER PUMP.....	6-11
CHECKING THE WATER PUMP.....	6-11
ASSEMBLING THE WATER PUMP.....	6-12
INSTALLING THE WATER PUMP.....	6-13

EAS26380

RADIATOR

Removing the radiator




Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Left front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Right front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Air filter case		Refer to "GENERAL CHASSIS" on page 4-1.
	Coolant		Drain. Refer to "CHANGING THE COOLANT" on page 3-18.
1	Coolant reservoir hose	1	
2	Thermo wax outlet hose	1	
3	Water pump breather hose	1	
4	Radiator outlet hose	1	
5	Radiator inlet hose	1	
6	Oil cooler outlet hose	1	
7	Radiator	1	
8	Radiator cap	1	
9	Radiator fan	1	
10	Coolant reservoir cover	1	
11	Coolant reservoir	1	
12	Coolant reservoir cap	1	

EAS26410

OIL COOLER

Removing the oil cooler




Order	Job/Parts to remove	Q'ty	Remarks
	Radiator assembly		Refer to "RADIATOR" on page 6-1.
	Coolant reservoir		Refer to "RADIATOR" on page 6-1.
	Engine oil		Drain. Refer to "CHANGING THE ENGINE OIL" on page 3-12.
1	Oil cooler outlet hose	1	
2	Union bolt	1	
3	Washer	1	
4	Oil cooler	1	
5	O-ring	1	
6	Oil cooler inlet hose	1	
7	Oil cooler inlet pipe	1	
8	Water jacket joint hose	1	
9	Water jacket joint	1	
10	O-ring	1	
11	Water pump outlet hose	1	
12	Radiator outlet hose	1	
			For installation, reverse the removal procedure.

EAS26420

CHECKING THE OIL COOLER

1. Check:
 - Oil cooler
Cracks/damage → Replace.



2. Check:
 - Oil cooler inlet hose
 - Oil cooler outlet hose
Cracks/damage/wear → Replace.

EAS26430

INSTALLING THE OIL COOLER


1. Clean:
 - Mating surfaces of the oil cooler and the crankcase
(with a cloth dampened with lacquer thinner)
2. Install:
 - O-ring **New**
 - Oil cooler "1"
 - Washer "2"
 - Union bolt "3"



Oil cooler
63 Nm (6.3 m·kg, 46 ft·lb)

NOTE:

- Before installing the oil cooler, lubricate the oil cooler bolt and O-ring with a thin coat of engine oil.
- Make sure the O-ring is positioned properly.



3. Fill:
 - Cooling system

(with the specified amount of the recommended coolant)


Refer to "CHANGING THE COOLANT" on page 3-18.

- Crankcase
(with the specified amount of the recommended engine oil)
Refer to "CHANGING THE ENGINE OIL" on page 3-12.
4. Check:
 - Cooling system
Leaks → Repair or replace any faulty part.
 5. Measure:
 - Radiator cap opening pressure
Below the specified pressure → Replace the radiator cap.
Refer to "CHECKING THE RADIATOR" on page 6-3.

EAS26440

THERMOSTAT

Removing the thermostat



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Left front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Right front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Air filter case		Refer to "GENERAL CHASSIS" on page 4-1.
	Coolant		Drain. Refer to "CHANGING THE ENGINE OIL" on page 3-12.
	Throttle body assembly		Refer to "THROTTLE BODIES" on page 7-4.
1	Radiator inlet hose	1	
2	Thermostat cover	1	
3	Thermostat	1	
			For installation, reverse the removal procedure.


5. Measure:

- Radiator cap opening pressure
Below the specified pressure → Replace
the radiator cap.
Refer to "CHECKING THE RADIATOR" on
page 6-3.

EAS26500

WATER PUMP


Removing the water pump



Order	Job/Parts to remove	Q'ty	Remarks
			It is not necessary to remove the water pump unless the coolant level is extremely low or the coolant contains engine oil.
	Coolant		Drain. Refer to "CHANGING THE COOLANT" on page 3-18.
1	Radiator outlet hose	1	Disconnect.
2	Water pump outlet hose	1	
3	Water pump breather hose	1	Disconnect.
4	Water pump	1	
			For installation, reverse the removal procedure.

WATER PUMP

Disassembling the water pump



Order	Job/Parts to remove	Q'ty	Remarks
1	Water pump cover	1	
2	O-ring	1	
3	Impeller shaft	1	
4	Circlip	1	
5	Water pump seal	1	
6	Oil seal	1	
7	Bearing	1	
8	Water pump housing	1	
9	O-ring	1	
10	Copper washer	1	
			For assembly, reverse the disassembly procedure.


EAS26510

DISASSEMBLING THE WATER PUMP

1. Remove:
 - Water pump cover
 - O-ring
 - Circlip
 - Impeller shaft
2. Remove:
 - Water pump seal "1"

NOTE: _____


Remove the water pump seal from the inside of the water pump housing "2".



3. Remove:
 - Oil seal "3"
(with a thin, flat-head screwdriver)

NOTE: _____


Remove the oil seal from the outside of the water pump housing.



4. Remove:
 - Bearing "4"

NOTE: _____


Remove the bearing from inside of the water pump housing.



5. Remove:
 - Rubber damper holder "5"
 - Rubber damper "6"
(from the impeller, with a thin, flat-head screwdriver)

NOTE: _____

Do not scratch the impeller shaft.




EAS26540

CHECKING THE WATER PUMP

1. Check:
 - Water pump housing cover "1"
 - Water pump housing cover "2"
 - Impeller "3"
 - Rubber damper "4"
 - Rubber damper holder "5"
 - Water pump seals
 - Oil seal

Cracks/damage/wear → Replace.



2. Check:
 - Bearing

Rough movement → Replace.

3. Check:

- Water pump outlet pipe
- Radiator outlet hose
- Cracks/damage/wear → Replace.

EAS26560


ASSEMBLING THE WATER PUMP

1. Install:

- Bearing
- Oil seal "1" **New**
(into the water pump housing "2")

NOTE:

- Before installing the oil seal, apply tap water or coolant onto its out surface.
- Install the oil seal with a socket that matches its outside diameter.



2. Install:

- Water pump seal "1" **New**

ECA14080

CAUTION:


Never lubricate the water pump seal surface with oil or grease.

NOTE:

- Install the water pump seal with the special tools.
- Before installing the water pump seal, apply Yamaha bond No.1215 or Quick Gasket "2" to the water pump housing "3".



Mechanical seal installer
90890-04078
Water pump seal installer
YM-33221-A
Middle driven shaft bearing driver
90890-04058
Bearing driver 40 mm
YM-04058
Yamaha bond No. 1215 (Three bond No. 1215@)
90890-85505



A. Push down

4. Mechanical seal installer


5. Middle driven shaft bearing driver

3. Install:

- Rubber damper "1" **New**
- Rubber damper holder "2" **New**

NOTE:

Before installing the rubber damper, apply tap water or coolant onto its outer surface.



4. Measure:

- Impeller shaft tilt
Out of specification → Repeat steps (3) and (4).


ECA14090

CAUTION:

Make sure the rubber damper and rubber damper holder are flush with the impeller.



Impeller shaft tilt limit
0.15 mm (0.006 in)



1. Straightedge
2. Impeller
5. Install:
 - Impeller shaft
 - Circlip **New**
 - O-ring **New**
 - Water pump cover



Water pump cover bolt
10 Nm (1.0 m·kg, 7.2 ft·lb)

EAS26590

INSTALLING THE WATER PUMP


1. Install:
 - O-ring
 - Copper washer **New**
 - Water pump assembly "1"

NOTE:

- Align the slit "a" on the impeller shaft with the projection "b" on the oil pump shaft.
- Lubricate the O-ring with a thin coat of lithium-soap-based grease.



Water pump assembly bolt
10 Nm (1.0 m·kg, 7.2 ft·lb)




2. Install:
 - O-ring **New**
 - Water pump inlet hose "1"
 - O-rings **New**

- Water pump outlet hose "2"
- Copper washer **New**

NOTE:

- Install the radiator outlet hose with white "a" mark positioned outside.
- Install the hose clamp with its screw head pointed to the inner side.



3. Fill:
 - Cooling system (with the specified amount of the recommended coolant)
 Refer to "CHANGING THE COOLANT" on page 3-18.
4. Check:
 - Cooling system
 Leaks → Repair or replace the faulty part.
5. Measure:
 - Radiator cap opening pressure
 Below the specified pressure → Replace the radiator cap.
 Refer to "CHECKING THE RADIATOR" on page 6-3.


FUEL SYSTEM

FUEL TANK	7-1
REMOVING THE FUEL TANK	7-2
REMOVING THE FUEL PUMP	7-2
CHECKING THE FUEL PUMP BODY	7-2
CHECKING THE FUEL PUMP OPERATION	7-2
INSTALLING THE FUEL PUMP	7-2
INSTALLING THE FUEL TANK	7-3
THROTTLE BODIES	7-4
CHECKING THE INJECTORS	7-6
CHECKING THE THROTTLE BODIES	7-6
CHECKING THE FUEL PRESSURE	7-6
ADJUSTING THE THROTTLE POSITION SENSOR	7-6
AIR INDUCTION SYSTEM	7-9
CHECKING THE AIR INDUCTION SYSTEM	7-12
INSTALLING THE AIR INDUCTION SYSTEM	7-12

EAS26620

FUEL TANK

Removing the fuel tank



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Left front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Right front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
1	Fuel hose	1	
2	Fuel sender coupler	1	Disconnect.
3	Fuel pump coupler	1	Disconnect.
4	Fuel tank drain hose	1	
5	Fuel tank breather hose	1	
6	Fuel tank	1	
7	Fuel pump	1	
8	Roll over valve	1	
			For installation, reverse the removal procedure.

EAS26630

REMOVING THE FUEL TANK

1. Extract the fuel in the fuel tank through the fuel tank cap with a pump.
2. Remove:
 - Fuel return hose
 - Fuel hose


ECA4S81003

CAUTION:

- **Be sure to disconnect the fuel hose by hand. Do not forcefully disconnect the hose with tools.**
- **Although the fuel has been removed from the fuel tank, be careful when removing the fuel hoses, since there may be fuel remaining in it.**

NOTE:

- To remove the fuel hose from the fuel injection pipe, slide the cover "a" on the end of the hose in the direction of the arrow shown and then remove the hose.
- Before removing the hoses, place a few rags in the area under where it will be removed.



3. Remove:
 - Fuel tank

NOTE:

Do not set the fuel tank down so that the installation surface of the fuel pump is directly under the tank. Be sure to lean the fuel tank in an upright position.

EAS26640

REMOVING THE FUEL PUMP

1. Remove:
 - Fuel pump

ECA14720

CAUTION:

- **Do not drop the fuel pump or give it a strong shock.**
- **Do not touch the base section of the fuel sender.**

EAS26670

CHECKING THE FUEL PUMP BODY

1. Check:
 - Fuel pump body
Obstruction → Clean.
Cracks/damage → Replace fuel pump assembly.
2. Check:
 - Diaphragms and gaskets
Turn/fatigue/cracks → Replace fuel pump assembly.
3. Check:
 - Valves
Cracks/damage → Replace fuel pump assembly.

EAS26690

CHECKING THE FUEL PUMP OPERATION

1. Check:
 - Fuel pump operation
Refer to "CHECKING THE FUEL PRESSURE" on page 7-6.

EAS26710


INSTALLING THE FUEL PUMP

1. Install:
 - Fuel pump
 - Fuel pump bolts



NOTE:

- Do not damage the installation surfaces of the fuel tank when installing the fuel pump.
- Always use a new fuel pump gasket.
- Install the fuel pump as shown in the illustration.
- Tighten the fuel pump bolts in stages in a crisscross pattern and to the specified torque.



EAS4S81001

INSTALLING THE FUEL TANK

1. Install:

- Fuel hose


ECA4S81001

CAUTION:

When installing the fuel hose, make sure that it is securely connected, and that the fuel hose holders are in the correct position, otherwise the fuel hose will not be properly installed.

NOTE:

Install the fuel hose connector securely onto the fuel tank until a distinct “click” is heard, and then make sure that it did not come loose. To install the fuel hose from the fuel injection hose, slide the cover “a” on the end of the hose in the direction of arrow shown.



2. Install:

- Fuel sender coupler
- Fuel pump coupler
- Fuel tank breather hose (FZS6W)
- Fuel tank drain hose


NOTE:

There is a white paint mark on the fuel tank breather hose (FZS6W). Refer to "CABLE ROUTING" on page 2-47.

EAS26970

THROTTLE BODIES


Removing the throttle bodies



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Left front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Right front cowling inner panel		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Battery		Refer to "GENERAL CHASSIS" on page 4-1.
	Air filter case		Refer to "GENERAL CHASSIS" on page 4-1.
	Battery box and battery box bracket		Refer to "GENERAL CHASSIS" on page 4-1.
1	Sub-wire harness coupler	2	Disconnect.
2	Coolant temperature sensor coupler	1	Disconnect.
3	Balance hose	1	Disconnect.
4	Throttle body joint clamp screw	4	
5	Throttle bodies	1	
6	Throttle cable	2	Disconnect.
7	Throttle body joint	4	
8	Heat protector	1	
9	Plunger control unit hose	1	Disconnect.
			For installation, reverse the removal procedure.

THROTTLE BODIES

Removing the injectors



FZS6WC

Order	Job/Parts to remove	Q'ty	Remarks
1	Throttle position sensor coupler	1	Disconnect.
2	Intake air pressure sensor coupler	1	Disconnect.
3	Cylinder #1 injector coupler	1	Disconnect.
4	Cylinder #2 injector coupler	1	Disconnect.
5	Cylinder #3 injector coupler	1	Disconnect.
6	Cylinder #4 injector coupler	1	Disconnect.
7	Sub-wire harness	1	
8	Negative pressure hose	1	
9	Intake air pressure sensor	1	
10	Fuel distributor	1	
11	Injector	4	
12	Throttle position sensor	1	
13	Fuel pulsation damper	1	
14	Throttle bodies	1	
			For installation, reverse the removal procedure.

EAS26980

CHECKING THE INJECTORS

1. Check:
 - Injectors
Damage → Replace.

EAS26990

CHECKING THE THROTTLE BODIES

1. Check:
 - Throttle bodies
Cracks/damage → Replace the throttle bodies as a set.
2. Check:
 - Fuel passages
Obstructions → Clean.



- a. Wash the throttle bodies in a petroleum-based solvent.
Do not use any caustic carburetor cleaning solution.
- b. Blow out all of the passages with compressed air.



3. Check:
 - Fuel pulsation damper

ECA4S81002

CAUTION:

Do not adjust the fuel pulsation damper.

EAS4S81043

CHECKING THE FUEL PRESSURE

1. Check:
 - Fuel pressure



- a. Remove the seat.
Refer to "GENERAL CHASSIS" on page 4-1.
- b. Disconnect the fuel hose (fuel tank to primary injector fuel rail) from the primary

EWA4S81015

WARNING

Cover fuel hose connections with a cloth when disconnecting them. Residual pressure in the fuel lines could cause fuel to spurt out when removing the hoses.

- c. Connect the pressure gauge "1" and adapter "2" to the fuel hose (fuel tank to primary injector fuel rail).



Pressure gauge


90890-03153

YU-03153

Fuel pressure adapter

90890-03176

YM-03176



- d. Start the engine.
- e. Measure the fuel pressure.



Fuel pressure

250 kPa (36.3 psi) (2.5 kgf/cm²)

Faulty → Replace the fuel pump.



EAS27030

ADJUSTING THE THROTTLE POSITION SENSOR


NOTE:

Before adjusting the throttle position sensor, the engine idling speed should be properly adjusted.

1. Check:
 - Throttle position sensor
Refer to "CHECKING THE THROTTLE POSITION SENSOR" on page 8-79.
2. Adjust:
 - Throttle position sensor angle



- a. Connect the throttle position sensor coupler to the wire harness.
- b. Connect the digital circuit tester to the throttle position sensor.



- Positive tester probe
Yellow "1"
- Negative tester probe
Black/Blue "2"




Digital circuit tester
90890-03174
Model 88 multimeter with
tachometer
YU-A1927

- Measure the throttle position sensor voltage.
- Adjust the throttle position sensor angle so that the voltage is within the specified range.



Output voltage (at idle)
Adjusted by tachometer




- After adjusting the throttle position sensor angle, tighten the throttle position sensor screws.



EAS27040


AIR INDUCTION SYSTEM



1. Air cut-off valve
2. Reed valve
3. To air filter case
 - A. To cylinder #1 and #2
 - B. To cylinder #3 and #4

AIR INDUCTION SYSTEM

Removing the air cut-off valve assembly and hoses



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS" on page 4-1.
	Left front cowling inner panel (with cowling)		Refer to "GENERAL CHASSIS" on page 4-1.
	Right front cowling inner panel (with cowling)		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Battery		Refer to "GENERAL CHASSIS" on page 4-1.
	Air filter case		Refer to "GENERAL CHASSIS" on page 4-1.
	Battery box and battery box bracket		Refer to "GENERAL CHASSIS" on page 4-1.
1	Air cut-off valve hose 1	1	Disconnect.
2	Air cut-off valve hose 2	1	Disconnect.
3	Air cut-off valve hose 3	1	Disconnect.
4	Air cut-off valve	1	
5	Reed valve cap	2	
6	Reed valve assembly	2	
7	Plate	4	
			For installation, reverse the removal procedure.

EAS27060



CHECKING THE AIR INDUCTION SYSTEM

Air injection


The air induction system burns unburned exhaust gases by injecting fresh air (secondary air) into the exhaust port, reducing the emission of hydrocarbons. When there is negative pressure at the exhaust port, the reed valve opens, allowing secondary air to flow into the exhaust port. The required temperature for burning the unburned exhaust gases is approximately 600 to 700°C.

Air cut-off valve


The air cut-off valve is controlled by the signals from the ECU in accordance with the combustion conditions. Ordinarily, the air cut-off valve opens to allow the air to flow during idle and closes to cut-off the flow when the vehicle is being driven. However, if the coolant temperature is below the specified value, the air cut-off valve remains open and allows the air to flow into the exhaust pipe until the temperature becomes higher than the specified value.




- A. From the air filter case
- B. To the reed valve
1. Check:
 - Hoses
Loose connections → Connect properly.
Cracks/damage → Replace.
 - Pipes
Cracks/damage → Replace.
2. Check:
 - Reed valve "1"
 - Reed valve stopper
 - Reed valve seat
Cracks/damage → Replace the reed valve.



3. Measure:
 - Reed valve bending limit "a"
Out of specification → Replace the reed valve.



**Reed valve bending limit
0.4 mm (0.016 in)**



14710301

4. Check:
 - Air cut-off valve
Cracks/damage → Replace.
5. Check
 - Air induction system solenoid
Refer to "CHECKING THE AIR INDUCTION SYSTEM SOLENOID" on page 8-81.

EAS27070

INSTALLING THE AIR INDUCTION SYSTEM

1. Install:
 - Plate
 - Reed valves
2. Install:
 - Reed valve cover

ELECTRICAL SYSTEM

IGNITION SYSTEM	8-1
CIRCUIT DIAGRAM.....	8-1
TROUBLESHOOTING.....	8-3
ELECTRIC STARTING SYSTEM	8-5
CIRCUIT DIAGRAM.....	8-5
STARTING CIRCUIT CUT-OFF SYSTEM OPERATION.....	8-7
TROUBLESHOOTING.....	8-8
CHARGING SYSTEM	8-11
CIRCUIT DIAGRAM.....	8-11
TROUBLESHOOTING.....	8-13
LIGHTING SYSTEM	8-15
CIRCUIT DIAGRAM.....	8-15
TROUBLESHOOTING.....	8-17
SIGNALING SYSTEM	8-19
CIRCUIT DIAGRAM.....	8-19
TROUBLESHOOTING.....	8-21
COOLING SYSTEM	8-27
CIRCUIT DIAGRAM.....	8-27
TROUBLESHOOTING.....	8-29
FUEL INJECTION SYSTEM	8-31
CIRCUIT DIAGRAM.....	8-31
ECU SELF-DIAGNOSTIC FUNCTION.....	8-33
FAIL-SAFE ACTIONS (SUBSTITUTE CHARACTERISTICS OPERATION CONTROL).....	8-34
TROUBLESHOOTING METHOD.....	8-36
DIAGNOSTIC MODE.....	8-37
TROUBLESHOOTING DETAILS.....	8-43
FUEL PUMP SYSTEM	8-55
CIRCUIT DIAGRAM.....	8-55
TROUBLESHOOTING.....	8-57
ELECTRICAL COMPONENTS	8-59
CHECKING THE SWITCHES.....	8-63
CHECKING THE BULBS AND BULB SOCKETS.....	8-66
CHECKING THE LEDS.....	8-67
CHECKING THE FUSES.....	8-67
CHECKING AND CHARGING THE BATTERY.....	8-68
CHECKING THE RELAYS.....	8-71
CHECKING THE TURN SIGNAL/HAZARD RELAY.....	8-72

CHECKING THE RELAY UNIT (DIODE)	8-72
CHECKING THE SPARK PLUG CAPS	8-73
CHECKING THE IGNITION COILS	8-74
CHECKING THE CRANKSHAFT POSITION SENSOR.....	8-75
CHECKING THE LEAN ANGLE SENSOR.....	8-75
CHECKING THE STARTOR MOTOR OPERATION	8-75
CHECKING THE STATOR COIL.....	8-76
CHECKING THE RECTIFIER/REGULATOR.....	8-76
CHECKING THE HORN	8-77
CHECKING THE ENGINE OIL LEVEL GAUGE	8-77
CHECKING THE FUEL SENDER	8-78
CHECKING THE SPEED SENSOR	8-78
CHECKING THE RADIATOR FAN MOTOR.....	8-79
CHECKING THE COOLANT TEMPERATURE SENSOR	8-79
CHECKING THE THROTTLE POSITION SENSOR.....	8-79
CHECKING THE FUEL PUMP	8-80
CHECKING THE AIR INDUCTION SYSTEM SOLENOID	8-81
CHECKING THE INTAKE AIR PRESSURE SENSOR.....	8-81
CHECKING THE INTAKE AIR TEMPERATURE SENSOR	8-81




EAS27090

IGNITION SYSTEM

EAS27110

CIRCUIT DIAGRAM



1. Main switch
6. Main fuse
9. Battery
10. Starting circuit cut-off relay
11. Sidestand switch
12. Neutral switch
17. Lean angle sensor
18. Crankshaft position sensor
21. ECU (engine control unit)
28. Cylinder-#1/#4 ignition coil
29. Cylinder-#2/#3 ignition coil
30. Spark plug
46. Engine stop switch
53. Ignition fuse
60. Clutch switch

EAS27140

TROUBLESHOOTING

The ignition system fails to operate (no spark or intermittent spark).

NOTE:

- Before troubleshooting, remove the following part(s):
 1. Seat
 2. Fuel tank
 3. Side cowlings

1. Check the fuses. (Main and ignition) Refer to "CHECKING THE FUSES" on page 8-67.	NG→	Replace the fuse(s).
OK↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-68.	NG→	<ul style="list-style-type: none"> • Clean the battery terminals. • Recharge or replace the battery.
OK↓		
3. Check the spark plugs. Refer to "CHECKING THE SPARK PLUGS" on page 3-9.	NG→	Re-gap or replace the spark plugs.
OK↓		
4. Check the spark plug caps. Refer to "CHECKING THE SPARK PLUG CAPS" on page 8-73.	NG→	Replace the spark plug caps.
OK↓		
5. Check the ignition coils. Refer to "CHECKING THE IGNI- TION COILS" on page 8-74.	NG→	Replace the ignition coils.
OK↓		
6. Check the crankshaft position sen- sor. Refer to "CHECKING THE CRANKSHAFT POSITION SEN- SOR" on page 8-75.	NG→	Replace the crankshaft position sen- sor.
OK↓		
7. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-63.	NG→	Replace the main switch.
OK↓		

IGNITION SYSTEM


8. Check the engine stop switch. Refer to "CHECKING THE SWITCHES" on page 8-63.	NG→	Replace the right handlebar switch.
OK↓		
9. Check the neutral switch. Refer to "CHECKING THE SWITCHES" on page 8-63.	NG→	Replace the neutral switch.
OK↓		
10. Check the sidestand switch. Refer to "CHECKING THE SWITCHES" on page 8-63.	NG→	Replace the sidestand switch.
OK↓		
11. Check the clutch switch. Refer to "CHECKING THE SWITCHES" on page 8-63.	NG→	Replace the clutch switch.
OK↓		
12. Check the starting circuit cut-off relay. Refer to "CHECKING THE RELAYS" on page 8-71.	NG→	Replace the starting circuit cut-off relay.
OK↓		
13. Check the lean angle sensor. Refer to "CHECKING THE LEAN ANGLE SENSOR" on page 8-75.	NG→	Replace the lean angle sensor.
OK↓		
14. Check the entire ignition system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-1.	NG→	Properly connect or repair the ignition system's wiring
OK↓		
Replace the ECU (engine control unit).		

EAS27160

ELECTRIC STARTING SYSTEM

EAS27170

CIRCUIT DIAGRAM



ELECTRIC STARTING SYSTEM

1. Main switch
6. Main fuse
7. Starter relay
8. Starter motor
9. Battery
10. Starting circuit cut-off relay
11. Sidestand switch
12. Neutral switch
46. Engine stop switch
47. Start switch
53. Ignition fuse
60. Clutch switch

ELECTRIC STARTING SYSTEM


EAS27180

STARTING CIRCUIT CUT-OFF SYSTEM OPERATION

If the engine stop switch is set to “○” and the main switch is set to “ON” (both switches are closed), the starter motor can only operate if at least one of the following conditions is met:

- The transmission is in neutral (the neutral switch is closed).
- The clutch lever is pulled to the handlebar (the clutch switch is closed) and the sidestand is up (the sidestand switch is closed).

The starting circuit cut-off relay prevents the starter motor from operating when neither of these conditions has been met. In this instance, the starting circuit cut-off relay is open so current cannot reach the starter motor. When at least one of the above conditions has been met the starting circuit cut-off relay is closed and the engine can be started by pressing the starter switch.



- a. WHEN THE TRANSMISSION IS IN NEUTRAL
b. WHEN THE SIDESTAND IS UP AND THE CLUTCH LEVER IS PULLED TO THE HANDLEBAR

12. Starter relay
13. Starter motor

1. Battery
2. Main fuse
3. Main switch
4. Ignition fuse
5. Engine stop switch
6. Starting circuit cut-off relay
7. Diode
8. Clutch switch
9. Sidestand switch
10. Neutral switch
11. Start switch

ELECTRIC STARTING SYSTEM

EAS27190

TROUBLESHOOTING

The starter motor fails to turn.

NOTE:

- Before troubleshooting, remove the following part(s):

1. Seat
2. Front cowling inner panel
3. Fuel tank
4. Left side cover

1. Check the fuses. (Main and ignition) Refer to "CHECKING THE FUSES" on page 8-67.	NG→	Replace the fuse(s).
OK↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-68.	NG→	<ul style="list-style-type: none">• Clean the battery terminals.• Recharge or replace the battery.
OK↓		
3. Check the starter motor. Refer to "CHECKING THE STARTER MOTOR" on page 5-38.	NG→	Repair or replace the starter motor.
OK↓		
4. Check the starting circuit cut-off relay. Refer to "CHECKING THE RELAYS" on page 8-71.	NG→	Replace the starting circuit cut-off relay.
OK↓		
5. Check the starter relay. Refer to "CHECKING THE RELAYS" on page 8-71.	NG→	Replace the starter relay.
OK↓		
6. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-63.	NG→	Replace the main switch.
OK↓		
7. Check the engine stop switch. Refer to "CHECKING THE SWITCHES" on page 8-63.	NG→	Replace the right handlebar switch.
OK↓		

ELECTRIC STARTING SYSTEM

8. Check the neutral switch.
Refer to "CHECKING THE SWITCHES" on page 8-63.

NG→

Replace the neutral switch.

OK↓

9. Check the sidestand switch.
Refer to "CHECKING THE SWITCHES" on page 8-63.

NG→

Replace the sidestand switch.

OK↓

10. Check the clutch switch.
Refer to "CHECKING THE SWITCHES" on page 8-63.

NG→

Replace the clutch switch.

OK↓

11. Check the start switch.
Refer to "CHECKING THE SWITCHES" on page 8-63.

NG→

Replace the right handlebar switch.

OK↓

12. Check the entire starting system's wiring.
Refer to "CIRCUIT DIAGRAM" on page 8-5.

NG→


Properly connect or repair the starting system's wiring.

OK↓

The starting system circuit is OK.

EAS27200
CHARGING SYSTEM

EAS27210
CIRCUIT DIAGRAM



2. AC magneto
3. Rectifier/regulator
6. Main fuse
9. Battery

EAS27230

TROUBLESHOOTING

The battery is not being charged.

NOTE:


- Before troubleshooting, remove the following part(s):

1. Seat
2. Front cowling inner panel
3. Fuel tank

<p>1. Check the fuse. (Main) Refer to "CHECKING THE FUSES" on page 8-67.</p>	NG→	<p>Replace the fuse.</p>
OK↓		
<p>2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-68.</p>	NG→	<ul style="list-style-type: none"> • Clean the battery terminals. • Recharge or replace the battery.
OK↓		
<p>3. Check the stator coil. Refer to "CHECKING THE STATOR COIL" on page 8-76.</p>	NG→	<p>Replace the stator coil assembly.</p>
OK↓		
<p>4. Check the rectifier/regulator. Refer to "CHECKING THE RECTIFIER/REGULATOR" on page 8-76.</p>	NG→	<p>Replace the rectifier/regulator.</p>
OK↓		
<p>5. Check the entire charging system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-11.</p>	NG→	<p>Properly connect or repair the charging system's wiring.</p>
OK↓		
<p>Replace the rectifier/regulator.</p>		

EAS27240
LIGHTING SYSTEM

EAS27250
CIRCUIT DIAGRAM



- 1. Main switch
- 6. Main fuse
- 9. Battery
- 21. ECU (engine control unit)
- 39. High beam indicator light
- 52. Headlight fuse
- 54. Tail fuse
- 57. License plate light
- 58. Tail/brake light
- 61. Dimmer switch
- 66. Headlight relay
- 67. Headlight (high beam)
- 68. Headlight (low beam)

EAS27260

TROUBLESHOOTING

Any of the following fail to light: headlight, high beam indicator light, taillight, license light or meter light.

NOTE:

- Before troubleshooting, remove the following part(s):

1. Seat
2. Front cowling inner panel
3. Fuel tank
4. Side cover

<p>1. Check the each bulbs and bulb sockets condition. Refer to "CHECKING THE BULBS AND BULB SOCKETS" on page 8-66.</p>	<p>NG→</p>	<p>Replace the bulb(s) and bulb socket(s).</p>
<p>OK↓</p>		
<p>2. Check the fuses. (Main, headlight and tail) Refer to "CHECKING THE FUSES" on page 8-67.</p>	<p>NG→</p>	<p>Replace the fuse(s).</p>
<p>OK↓</p>		
<p>3. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-68.</p>	<p>NG→</p>	<ul style="list-style-type: none"> • Clean the battery terminals. • Recharge or replace the battery.
<p>OK↓</p>		
<p>4. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-63.</p>	<p>NG→</p>	<p>Replace the main switch.</p>
<p>OK↓</p>		
<p>5. Check the dimmer switch. Refer to "CHECKING THE SWITCHES" on page 8-63.</p>	<p>NG→</p>	<p>The dimmer switch is faulty. Replace the left handlebar switch.</p>
<p>OK↓</p>		
<p>6. Check the headlight relay. Refer to "CHECKING THE RELAYS" on page 8-71.</p>	<p>NG→</p>	<p>Replace the headlight relay.</p>
<p>OK↓</p>		

7. Check the entire lighting system's wiring.
Refer to "CIRCUIT DIAGRAM" on page 8-15.

NG→

Properly connect or repair the lighting system's wiring.

OK↓


This circuit is OK.

EAS27270

SIGNALING SYSTEM

EAS27280

CIRCUIT DIAGRAM



1. Main switch
6. Main fuse
9. Battery
10. Starting circuit cut-off relay
12. Neutral switch
13. Fuel pump
21. ECU (engine control unit)
32. Fuel level warning light
33. Oil level warning light
34. Neutral indicator light
35. Tachometer
36. Multi-function meter
40. Left turn signal indicator light
41. Right turn signal indicator light
42. Meter light
43. Oil level switch
45. Front brake light switch
51. Signal fuse
53. Ignition fuse
54. Tail fuse
55. Turn signal relay
56. Rear brake light switch
58. Tail/brake light
62. Hazard switch
63. Turn signal switch
64. Horn switch
65. Horn
69. Front left turn signal light
70. Front right turn signal light
71. Rear left turn signal light
72. Rear right turn signal light

EAS27290

TROUBLESHOOTING

- Any of the following fail to light: turn signal light, brake light or an indicator light.
- The horn fails to sound.

NOTE:

- Before troubleshooting, remove the following part(s):
 1. Seat
 2. Front cowling inner panel
 3. Fuel tank
 4. Side cover

<p>1. Check the fuses. (Main, ignition, signaling and tail) Refer to "CHECKING THE FUSES" on page 8-67.</p>	NG→	<p>Replace the fuse(s).</p>
OK↓		
<p>2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-68.</p>	NG→	<ul style="list-style-type: none"> • Clean the battery terminals. • Recharge or replace the battery.
OK↓		
<p>3. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-63.</p>	NG→	<p>Replace the main switch.</p>
OK↓		
<p>4. Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-19.</p>	NG→	<p>Properly connect or repair the signaling system's wiring.</p>
OK↓		
<p>This circuit is OK.</p>		

Check the signaling system

The horn fails to sound.

<p>1. Check the horn switch. Refer to "CHECKING THE SWITCHES" on page 8-63.</p>	NG→	<p>Replace the left handlebar switch.</p>
OK↓		
<p>2. Check the horn. Refer to "CHECKING THE HORN" on page 8-77.</p>	NG→	<p>Replace the horn.</p>
OK↓		

<p>3. Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-19.</p>	NG→	<p>Properly connect or repair the signaling system's wiring.</p>
OK↓		
<p>This circuit is OK.</p>		
<p>The tail/brake light fails to come on.</p>		
<p>1. Check the tail/brake light bulb and socket. Refer to "CHECKING THE BULBS AND BULB SOCKETS" on page 8-66.</p>	NG→	<p>Replace the tail/brake light bulb, socket or both.</p>
OK↓		
<p>2. Check the front brake light switch. Refer to "CHECKING THE SWITCHES" on page 8-63.</p>	NG→	<p>Replace the front brake light switch.</p>
OK↓		
<p>3. Check the rear brake light switch. Refer to "CHECKING THE SWITCHES" on page 8-63.</p>	NG→	<p>Replace the rear brake light switch.</p>
OK↓		
<p>4. Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-19.</p>	NG→	<p>Properly connect or repair the signaling system's wiring.</p>
OK↓		
<p>This circuit is OK.</p>		
<p>The turn signal light, turn signal indicator light or both fail to blink.</p>		
<p>1. Check the turn signal indicator light bulb and socket. Refer to "CHECKING THE LEDS" on page 8-67.</p>	NG→	<p>Replace the turn signal indicator light bulb, socket or both.</p>
OK↓		
<p>2. Check the turn signal switch. Refer to "CHECKING THE SWITCHES" on page 8-63.</p>	NG→	<p>Replace the left handlebar switch.</p>
OK↓		

SIGNALING SYSTEM

3. Check the hazard switch. Refer to "CHECKING THE SWITCHES" on page 8-63.	NG→	Replace the left handlebar switch.
OK↓		
4. Check the turn signal/hazard relay. Refer to "CHECKING THE RELAYS" on page 8-71.	NG→	The turn signal relay is faulty and must be replaced.
OK↓		
5. Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-19.	NG→	Properly connect or repair the signaling system's wiring.
OK↓		
This circuit is OK.		
The neutral indicator light fails to come.		
1. Check the neutral indicator light bulb and socket. Refer to "CHECKING THE LEDS" on page 8-67.	NG→	Replace the neutral indicator light bulb, socket or both.
OK↓		
2. Check the neutral switch. Refer to "CHECKING THE SWITCHES" on page 8-63.	NG→	Replace the neutral switch.
OK↓		
3. Check the starting circuit cut-off relay. Refer to "CHECKING THE RELAYS" on page 8-71.	NG→	Replace the starting circuit cut-off relay.
OK↓		

<p>4. Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-19.</p>	NG→	<p>Properly connect or repair the signaling system's wiring.</p>
OK↓		
<p>This circuit is OK.</p>		
The oil level warning light fails to come.		
<p>1. Check the oil level warning light bulb and socket. Refer to "CHECKING THE LEDS" on page 8-67.</p>	NG→	<p>Replace the oil level warning light bulb, socket or both.</p>
OK↓		
<p>2. Check the oil level switch. Refer to "CHECKING THE SWITCHES" on page 8-63.</p>	NG→	<p>Replace the oil level switch.</p>
OK↓		
<p>3. Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-19.</p>	NG→	<p>Properly connect or repair the signaling system's wiring.</p>
OK↓		
<p>This circuit is OK.</p>		
The fuel level warning light fails to come.		
<p>1. Check the fuel level warning light bulb and socket. Refer to "CHECKING THE LEDS" on page 8-67.</p>	NG→	<p>Replace the fuel level warning light bulb, socket or both.</p>
OK↓		
<p>2. Check the fuel sender. Refer to "CHECKING THE FUEL SENDER" on page 8-78.</p>	NG→	<p>Replace the fuel pump assembly.</p>
OK↓		

3. Check the entire signaling system's wiring.
Refer to "CIRCUIT DIAGRAM" on page 8-19.

NG→

Properly connect or repair the signaling system's wiring.

OK↓

This circuit is OK.

The speedometer fails to operate.

1. Check the speed sensor.
Refer to "CHECKING THE SPEED SENSOR" on page 8-78.

NG→

Replace the speed sensor.

OK↓

2. Check the entire signaling system's wiring.
Refer to "CIRCUIT DIAGRAM" on page 8-19.

NG→

Properly connect or repair the signaling system's wiring.

OK↓

Replace the meter assembly.

NOTE:

Repair or replace if there is an open or short circuit.


- Between ECU coupler and meter assembly.
(yellow/blue-yellow/blue)

EAS27300

COOLING SYSTEM

EAS27310

CIRCUIT DIAGRAM



- 1. Main switch
- 6. Main fuse
- 9. Battery
- 20. Coolant temperature sensor
- 21. ECU (engine control unit)
- 36. Multi-function meter
- 48. Radiator fan motor fuse
- 49. Radiator fan motor relay
- 50. Radiator fan motor
- 53. Ignition fuse

EAS27320

TROUBLESHOOTING

NOTE:


- Before troubleshooting, remove the following part(s):

1. Seat
2. Front cowling inner panel
3. Fuel tank
4. Side cover

<p>1. Check the fuses. (Main, ignition and radiator fan motor) Refer to "CHECKING THE FUSES" on page 8-67.</p>	NG→	<p>Replace the fuse(s).</p>
OK↓		
<p>2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-68.</p>	NG→	<ul style="list-style-type: none"> • Clean the battery terminals. • Recharge or replace the battery.
OK↓		
<p>3. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-63.</p>	NG→	<p>Replace the main switch.</p>
OK↓		
<p>4. Check the radiator fan motor. Refer to "CHECKING THE RADIATOR FAN MOTOR" on page 8-79.</p>	NG→	<p>The radiator fan motor is faulty and must be replaced.</p>
OK↓		
<p>5. Check the radiator fan motor relay. Refer to "CHECKING THE RELAYS" on page 8-71.</p>	NG→	<p>Replace the radiator fan motor relay.</p>
OK↓		
<p>6. Check the coolant temperature. Refer to "CHECKING THE COOLANT TEMPERATURE SENSOR" on page 8-79.</p>	NG→	<p>Replace the coolant temperature sensor.</p>
OK↓		
<p>7. Check the entire cooling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-27.</p>	NG→	<p>Properly connect or repair the cooling system's wiring.</p>
OK↓		
<p>This circuit is OK.</p>		

EAS27330
FUEL INJECTION SYSTEM

EAS27340
CIRCUIT DIAGRAM



1. Main switch
5. Fuel injection system fuse
6. Main fuse
9. Battery
10. Starting circuit cut-off relay
11. Sidestand switch
12. Neutral switch
13. Fuel pump
14. Throttle position sensor
15. Intake air pressure sensor
16. O₂ sensor
17. Lean angle sensor
18. Crankshaft position sensor
19. Intake air temperature sensor
20. Coolant temperature sensor
21. ECU (engine control unit)
22. Injector #1
23. Injector #2
24. Injector #3
25. Injector #4
27. Speed sensor
28. Cylinder-#1/#4 ignition coil
29. Cylinder-#2/#3 ignition coil
30. Spark plug
34. Neutral indicator light
36. Multi-function meter
37. Engine trouble warning light
46. Engine stop switch
53. Ignition fuse

EAS27350

ECU SELF-DIAGNOSTIC FUNCTION

The ECU is equipped with a self-diagnostic function in order to ensure that the fuel injection system is operating normally. If this function detects a malfunction in the system, it immediately operates the engine under substitute characteristics and illuminates the engine trouble warning light to alert the rider that a malfunction has occurred in the system. Once a malfunction has been detected, a fault code is stored in the memory of the ECU.

- To inform the rider that the fuel injection system is not functioning, the engine trouble warning light flashes when the start switch is being pushed to start the engine.
- If a malfunction is detected in the system by the self-diagnostic function, the ECU provides an appropriate substitute characteristic operation, and alerts the rider of the detected malfunction by illuminating the engine trouble warning light.
- After the engine has been stopped, the lowest fault code number appears on the clock LCD. Once a fault code has been displayed, it remains stored in the memory of the ECU until it is deleted.

Engine trouble warning light indication and FI system operation

Warning light indication	ECU operation	FI operation	Vehicle operation
Flashing*	Warning provided when unable to start engine	Operation stopped	Cannot be operated
Remains on	Malfunction detected	Operated with substitute characteristics in accordance with the description of the malfunction	Can or cannot be operated depending on the fault code

* The warning light flashes when any one of the conditions listed below is present and the start switch is pushed:

- | | | | |
|-----|--|-----|--|
| 12: | Crankshaft position sensor | 41: | Lean angle sensor (open or short-circuit) |
| 19: | Sidestand switch (open circuit in the wire to the ECU) | 50: | ECU internal malfunction (faulty ECU memory) |
| 30: | Lean angle sensor (latch up detected) | | |

Checking for a defective engine trouble warning light bulb

The engine trouble warning light comes on for 1.4 seconds after the main switch has been turned to "ON" and when the start switch is being pushed. If the warning light does not come on under these conditions, the warning light bulb may be defective.



- Main switch "OFF"
- Main switch "ON"
- Engine trouble warning light off
- Engine trouble warning light on for 1.4 seconds

EAS27362

FAIL-SAFE ACTIONS (SUBSTITUTE CHARACTERISTICS OPERATION CONTROL)

If the ECU detects an abnormal signal from a sensor while the vehicle is being driven, the ECU illuminates the engine trouble warning light and provides the engine with alternate operating instructions that are appropriate for the type of malfunction.

When an abnormal signal is received from a sensor, the ECU processes the specified values that are programmed for each sensor in order to provide the engine with alternate operating instructions that enable the engine to continue to operate or stop operating, depending on the conditions.

The ECU takes fail-safe actions in two ways: one in which the sensor output is set to a prescribed value, and the other in which the ECU directly operates an actuator. Details on the fail-safe actions are given in the table below.

Self-Diagnostic Function

Fault code No.	Item	Symptom	Able / unable to start	Able / unable to drive
12	Crankshaft position sensor	No normal signals are received from the crankshaft position sensor.	Unable	Unable
13	Intake air pressure sensor (open or short circuit)	Intake air pressure sensor-open or short circuit detected.	Able	Able
14	Intake air pressure sensor (pipe system)	Intake air pressure sensor-pipe system malfunction (clogged or detached hose).	Able	Able
15	Throttle position sensor (open or short circuit)	Throttle position sensor-open or short circuit detected.	Able	Able
16	Throttle position sensor (stuck)	The throttle position sensor is stuck.	Able	Able
19	Sidestand switch (open circuit wire harness to ECU)	Open circuit is detected in the input line from the sidestand switch to the ECU.	Unable	Unable
21	Coolant temperature sensor	Coolant temperature sensor-open or short circuit detected.	Able	Able
22	Intake air temperature sensor	Intake air temperature sensor-open or short circuit detected.	Able	Able
24	O ₂ sensor	No normal signal is received from the O ₂ sensor.	Able	Able
30	Lean angle sensor	Latch up detected. No normal signal is received from the lean angle sensor.	Unable	Unable
33	Ignition coil (#1, #4) (faulty ignition)	Malfunction detected in the primary wire of the ignition coil (#1, #4).	Able (depending on the number of faulty cylinders)	Able (depending on the number of faulty cylinders)

FUEL INJECTION SYSTEM

Fault code No.	Item	Symptom	Able / unable to start	Able / unable to drive
34	Ignition coil (#2, #3) (faulty ignition)	Malfunction detected in the primary wire of the ignition coil (#2, #3).	Able (depending on the number of faulty cylinders)	Able (depending on the number of faulty cylinders)
41	Lean angle sensor (open or short circuit)	Lean angle sensor-open or short circuit detected.	Unable	Unable
42	Speed sensor Neutral switch	No normal signals are received from the speed sensor. Open or short circuit is detected in the neutral switch.	Able	Able
43	Fuel system voltage (monitor voltage)	The ECU is unable to monitor the battery voltage (an open circuit in the line to the ECU).	Able	Able
44	Error in writing the amount of CO adjustment on EEPROM	Error is detected while reading or writing on EEPROM (CO adjustment value).	Able	Able
46	Vehicle system power supply (Monitoring voltage)	Power supply to the fuel injection system is not normal.	Able	Able
50	ECU internal malfunction (memory check error)	Faulty ECU memory. (When this malfunction is detected in the ECU, the fault code number might not appear on the meter.)	Unable	Unable
—	Start unable warning	Engine trouble warning light flashes when the start switch is turned ON. Relay is not turned ON even if the crank signal is input while the start switch is turned ON. When the start switch is turned ON while an error is detected with the fault code of No.12, 19, 30, 41, 43 or 50.	Unable	Unable

Communication error with the meter


Fault code No.	Item	Symptom	Able / unable to start	Able / unable to drive
Er-1	ECU internal malfunction (output signal error)	No signals are received from the ECU.	Unable	Unable
Er-2	ECU internal malfunction (output signal error)	No signals are received from the ECU within the specified duration.	Unable	Unable

EAS27411

DIAGNOSTIC MODE

Setting the diagnostic mode

1. Turn the main switch to “OFF” and set the engine stop switch to “○”.
2. Disconnect the wire harness coupler from the fuel pump.
3. Simultaneously press and hold the “SELECT” and “RESET” buttons, turn the main switch to “ON”, and continue to press the buttons for 8 seconds or more.



NOTE:


- All displays on the meter disappear except the clock and tripmeter displays.
- “DIAG” appears on the clock LCD.

4. Press the “SELECT” button to select the diagnostic monitoring mode “dIAG”.
5. After selecting “dIAG”, simultaneously press the “SELECT” and “RESET” buttons for 2 seconds or more to execute the selection.
6. Set the engine stop switch to “OFF”.
7. Select the diagnostic code number that applies to the item that was verified with the fault code number by pressing the “SELECT” and “RESET” buttons.

NOTE:

The diagnostic code number appears on the clock LCD (01–70).

- To decrease the selected diagnostic code number, press the “RESET” button. Press the “RESET” button for 1 second or longer to automatically decrease the diagnostic code numbers.
- To increase the selected diagnostic code number, press the “SELECT” button. Press the “SELECT” button for 1 second or longer to automatically increase the diagnostic code numbers.



8. Verify the operation of the sensor or actuator.
 - Sensor operation
The data representing the operating conditions of the sensor appears on the trip LCD.
 - Actuator operation
Set the engine stop switch to “○” to operate the actuator.

NOTE:

If the engine stop switch is set to “○”, set it to “⊗”, and then set it to “○” again.

9. Turn the main switch to “OFF” to cancel the diagnostic mode.

Diagnostic code table

Fault code No.	Symptom	Probable cause of malfunction	Diagnostic code No.
12	No normal signals are received from the crankshaft position sensor.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Defective crankshaft position sensor. • Malfunction in pickup rotor. • Malfunction in ECU. • Improperly installed sensor. 	—
13	Intake air pressure sensor-open or short circuit detected.	<ul style="list-style-type: none"> • Open or short circuit in wire sub lead. • Open or short circuit in wire harness. • Defective intake air pressure sensor. • Malfunction in ECU. 	03
14	Intake air pressure sensor-pipe system malfunction (clogged or detached hose). <ul style="list-style-type: none"> • Detected hose • Clogged hose 	<ul style="list-style-type: none"> • Intake air pressure sensor hose is detached, clogged, kinked, or pinched. • Malfunction in ECU. 	03
15	Throttle position sensor-open or short circuit detected.	<ul style="list-style-type: none"> • Open or short circuit in wire sub lead. • Open or short circuit in wire harness. • Defective throttle position sensor. • Malfunction in ECU. • Improperly installed throttle position sensor. 	01
16	Stuck throttle position sensor detected.	<ul style="list-style-type: none"> • Defective sensor (stuck throttle position sensor). • Malfunction in ECU. 	01
19	Open circuit is detected in the input line from the start switch to the ECU.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Malfunction in ECU. 	20
21	Coolant temperature sensor-open or short circuit detected.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Defective coolant temperature sensor. • Malfunction in ECU. • Improperly installed coolant temperature sensor. 	06
22	Intake air temperature sensor-open or short circuit detected.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Defective intake temperature sensor. • Malfunction in ECU. • Improperly installed intake air temperature sensor. 	05
24	No normal signal is received from the O ₂ sensor.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Defective O₂ sensor. • Malfunction in ECU. • Improperly installed O₂ sensor. 	—

FUEL INJECTION SYSTEM

Fault code No.	Symptom	Probable cause of malfunction	Diagnostic code No.
30	Latch up detected. No normal signal is received from the lean angle sensor.	<ul style="list-style-type: none"> • The vehicle has overturned. • Defective lean angle sensor. • Malfunction in ECU. • Improperly installed lean angle sensor. 	08
33	Malfunction detected in the primary wire of the ignition coil (#1 and #4).	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Malfunction in ignition coil. • Malfunction in ECU. • Malfunction in a component of ignition cut-off circuit system. 	30
34	Malfunction detected in the primary wire of the ignition coil (#2 and #3).	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Malfunction in ignition coil. • Malfunction in ECU. • Malfunction in a component of ignition cut-off circuit system. 	31
41	Lean angle sensor-open or short circuit detected.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Defective lean angle sensor. • Malfunction in ECU. 	08
42	No normal signals are received from the speed sensor. Open or short circuit is detected in the neutral switch.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Defective speed sensor. • Malfunction in vehicle speed sensor detected unit. • Defective neutral switch. • Malfunction in the engine side of the neutral switch. • Malfunction in ECU. 	07 21
43	The ECU is unable to monitor the battery voltage (an open circuit in the line to the ECU).	<ul style="list-style-type: none"> • Open circuit in wire harness. • Malfunction in ECU. 	09
44	Error is detected while reading or writing on EEPROM (CO adjustment value).	<ul style="list-style-type: none"> • Malfunction in ECU. (The CO adjustment value is not properly written on or read from the internal memory). 	60
46	Power supply to the fuel injection system is not normal.	<ul style="list-style-type: none"> • Malfunction in the charging system. Refer to "CHARGING SYSTEM" on page 8-11. 	—
50	Faulty ECU memory. (When this malfunction is detected in the ECU, the fault code number might not appear on the meter.)	<ul style="list-style-type: none"> • Malfunction in ECU. (The program and data are not properly written on or read from the internal memory.) 	—
Er-1	No signals are received from the ECU.	<ul style="list-style-type: none"> • Open or short circuit in communication line. • Malfunction in meter unit. • Malfunction in ECU. 	—
Er-2	No signals are received from the ECU within the specified duration.	<ul style="list-style-type: none"> • Open or short circuit in communication line. • Malfunction in meter unit. • Malfunction in ECU. 	—

FUEL INJECTION SYSTEM

Fault code No.	Symptom	Probable cause of malfunction	Diagnostic code No.
Er-3	Data from the ECU cannot be received correctly.	<ul style="list-style-type: none"> • Open or short circuit in communication line. • Malfunction in meter unit. • Malfunction in ECU. 	—
Er-4	Non-registered data has been received from the meter.	<ul style="list-style-type: none"> • Open or short circuit in communication line. • Malfunction in meter unit. • Malfunction in ECU. 	—

Sensor operation table

Diagnostic code No.	Item	Meter display	Checking method
01	Throttle angle <ul style="list-style-type: none"> • Fully closed position • Fully opened position 	15–17 97–100	Check with throttle fully closed. Check with throttle fully open.
03	Pressure difference (intake air pressure)	Displays the intake air pressure.	Turn On the engine stop switch, then operate the throttle while pressing the start switch. (If the display value changes, the performance is OK.)
05	Intake air temperature	Displays the intake air temperature.	Compare the actually measured intake air temperature with the meter display value. (*)
06	Coolant temperature	Displays the coolant temperature.	Compare the actually measured coolant temperature with the meter display value.
07	Vehicle speed pulse	0–999	Check that the number changes (integrating) when the rear wheels are rotated.
08	Lean angle sensor <ul style="list-style-type: none"> • Upright • Overturned 	0.4–1.4 3.8–4.2	Remove the lean angle sensor and incline it more than 65 degrees.
09	Fuel system voltage (battery voltage)	Approximately 12.0	Compare with the actually measured battery voltage. (If the battery voltage is lower, perform recharging.)
20	Sidestand switch <ul style="list-style-type: none"> • Stand retracted • Stand extended 	ON OFF	Turn ON/OFF the Sidestand switch.
21	Neutral switch <ul style="list-style-type: none"> • Neutral • In gear 	ON OFF	Perform the shift operation of transmission.

FUEL INJECTION SYSTEM

Diagnostic code No.	Item	Meter display	Checking method
60	EEPROM fault code display <ul style="list-style-type: none"> • Not fault • Fault detected 	00 01 to 02 (Fault detection cylinder) 01: #1 and #4 02: #2 and #3 <ul style="list-style-type: none"> • (If plural cylinders are defective, the display alternates every two seconds.) 	—
61	Malfunction history code display <ul style="list-style-type: none"> • No history • History exists 	00 12-50 (Fault detection code) <ul style="list-style-type: none"> • (If code numbers more than one are detected, the display alternates every two seconds to show all the detected code numbers. When all code numbers are shown, the display repeats the same process.) 	—
62	Malfunction history code erasure <ul style="list-style-type: none"> • No history • History exists 	00 00–17 (Memory numbers of the fault detection)	— To erase the history, turn ON the engine stop switch.
63	Malfunction code reinstate <ul style="list-style-type: none"> • No malfunction code • Malfunction code exists 	00 Fault code 24 <ul style="list-style-type: none"> • (If more than one code number is detected, the display changes every two seconds to show all the detected code numbers are shown, the display repeats.) 	— To reinstate, set the engine stop switch to “○”.
70	Control number	00–255	—

* If it is not possible to check the intake temperature, use the ambient temperature as reference (use the compared values for reference).

FUEL INJECTION SYSTEM

Actuator operation table

Diagnostic code No.	Item	Actuation	Checking method
30	Ignition coil #1/#4	Actuates the ignition coils #1, #4 for five times every second. Illuminates the engine trouble warning light.	Check the spark five times. • Connect an ignition checker.
31	Ignition coil #2/#3	Actuates the ignition coils #2, #3 for five times every second. Illuminates the engine trouble warning light.	Check the spark five times. • Connect an ignition checker.
36	Injector #1/#4	Actuates the injector #1/#4 for five times every second. Illuminates the engine trouble warning light.	Check the operating sound of the injector #1/#4 five times.
37	Injector #2/#3	Actuates the injector #2/#3 for five times every second. Illuminates the engine trouble warning light.	Check the operating sound of the injector #2/#3 five times.
48	AI system solenoid	Actuates the AI system solenoid for five times every second. Illuminates the engine trouble warning light.	Check the operating sound of the AI system solenoid five times.
50	Fuel injection system relay	Actuates the fuel injection system relay for five times every second. Illuminates the engine trouble warning light. (The engine trouble warning light is OFF when the relay is ON, and the engine trouble warning light is ON when the relay is OFF).	Check the operating sound of the fuel injection system relay five times.
51	Radiator fan motor relay	Actuates the radiator fan motor relay for five cycles every five-second. (ON 2 seconds, OFF 3 seconds) Illuminates the engine trouble warning light.	Check the operating sound of the Radiator fan motor relay five times.
52	Headlight relay	Actuates the headlight relay for five times every five-second. (ON 2 seconds, OFF 3 seconds) Illuminates the engine trouble warning light.	Check the operating sound of the headlight relay five times.

EAS27451

TROUBLESHOOTING DETAILS

This section describes the measures per fault code number displayed on the meter. Check and service the items or components that are the probable cause of the malfunction following the order given.

After the check and service of the malfunctioning part has been completed, reset the meter display according to the reinstatement method.

Fault code No.:

Code number displayed on the meter when the engine failed to work normally. Refer to "Self-Diagnostic Function table".

Diagnostic code No.:

Diagnostic code number to be used when the diagnostic mode is operated. Refer to "DIAGNOSTIC MODE" on page 8-37.

Fault code No.	12	Symptom	No normal signals are received from the crankshaft position sensor.	
Diagnostic code No.				
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Installed condition of crankshaft position sensor		Check the installed area for looseness or pinching.	Cranking the engine.
2	Connected state of connector <ul style="list-style-type: none"> • Crankshaft position sensor coupler • Main wire harness ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	
3	Open or short circuit in wire harness and/or sub lead.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between the crankshaft position sensor coupler and ECU coupler. (Gray-Gray) (Black/Blue-Black/Blue) 	
4	Defective crankshaft position sensor.		<ul style="list-style-type: none"> • Replace if defective. Refer to "CHECKING THE CRANKSHAFT POSITION SENSOR" on page 8-75.	

Fault code No.	13	Symptom	Intake air pressure sensor-open or short circuit detected.	
Diagnostic code No.		03	Intake air pressure sensor	
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connected state of connector <ul style="list-style-type: none"> • Intake air pressure sensor coupler • Main wire harness ECU coupler • Sub-wire harness coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	Turning the main switch ON.

FUEL INJECTION SYSTEM

Fault code No.	13	Symptom	Intake air pressure sensor-open or short circuit detected.		
Diagnostic code No.		03	Intake air pressure sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method	
2	Open or short circuit in wire harness and/or sub lead.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between intake air pressure sensor coupler and ECU coupler (Black/Blue–Black/Blue) (Pink/White–Pink/White) (Blue–Blue) 	Turning the main switch ON.	
3	Defective intake air pressure sensor		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.03) • Replace if defective. Refer to "CHECKING THE INTAKE AIR PRESSURE SENSOR" on page 8-81.		

Fault code No.	14	Symptom	AIntake air pressure sensor-pipe system malfunction (clogged or detached hose). BIntake air pressure sensor-open or short circuit detected. CStuck throttle position sensor detected.		
Diagnostic code No.		03	Intake air pressure sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method	
1	Intake air pressure sensor hose		<ul style="list-style-type: none"> • Check the intake air pressure sensor hose condition. • Repair or replace the sensor hose. 	Starting the engine and operating it at idle.	
2	Intake air pressure sensor malfunction at intermediate electrical potential.		<ul style="list-style-type: none"> • Check and repair the connection. • Replace it if there is a malfunction. 		
3	Connected state of connector <ul style="list-style-type: none"> • Intake air pressure sensor coupler • Main wire harness ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 		
4	Defective intake air pressure sensor		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.03) • Replace if defective. Refer to "CHECKING THE INTAKE AIR PRESSURE SENSOR" on page 8-81.		

FUEL INJECTION SYSTEM

Fault code No.	15	Symptom	Throttle position sensor-open or short circuit detected.	
Diagnostic code No.	01	Throttle position sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Installed condition of throttle position sensor.		Check the installed area for looseness or pinching.	Turning the main switch ON.
2	Connected state of connector <ul style="list-style-type: none"> • Throttle position sensor coupler • Main wire harness ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	
3	Open or short circuit in wire harness and/or sub lead.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between throttle position sensor coupler and ECU coupler (Black/Blue-Black/Blue) (Yellow-Yellow) (Blue-Blue) 	
4	Throttle position sensor lead wire open circuit output voltage check.		<ul style="list-style-type: none"> • Check for open circuit and replace the throttle position sensor. (Black/Blue-Yellow) 	
			Open circuit item	
			Ground wire open circuit	5 V
			Output wire open circuit	0 V
			Power supply wire open circuit	0 V
5	Defective throttle position sensor.		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.01) • Replace if defective. Refer to "CHECKING THE THROTTLE POSITION SENSOR" on page 8-79. 	

Fault code No.	16	Symptom	A Stuck throttle position sensor detected.	
Diagnostic code No.	01	Throttle position sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Installed condition of throttle position sensor.		Check the installed area for looseness or pinching.	Starting the engine and operating it at idle, and then by racing it.
2	Defective throttle position sensor.		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.01) • Replace if defective. Refer to "CHECKING THE THROTTLE POSITION SENSOR" on page 8-79. 	

FUEL INJECTION SYSTEM

Fault code No.	19	Symptom	Open circuit is detected in the input line from the sidestand switch to the ECU.	
Diagnostic code No.	20	Sidestand switch		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connected state of connector <ul style="list-style-type: none"> • Main wire harness ECU coupler (No. 13 and 30 pin, black) • Alarm coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	If the transmission is in gear, retracting the sidestand. If the transmission is in neutral, reconnecting the wiring.
2	Open or short circuit in wire harness or sub lead.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between ECU and sidestand switch (Black/Red–Blue/Green) 	
3	Defective sidestand switch		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.20) • Replace if defective. Refer to "CHECKING THE SWITCHES" on page 8-63.	

Fault code No.	21	Symptom	Coolant temperature sensor-open or short circuit detected.	
Diagnostic code No.	06	Coolant temperature sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Installed condition of coolant temperature sensor		Check the installed area for looseness or pinching.	Turning the main switch ON.
2	Connected state of connector <ul style="list-style-type: none"> • Coolant temperature sensor coupler • Main wire harness ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	
3	Open or short circuit in wire harness and/or sub lead.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Main wire harness (Black/Blue–Black/Blue) (Green/White–Green/White) 	
4	Defective coolant temperature sensor.		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.06) • Replace if defective. Refer to "CHECKING THE COOLANT TEMPERATURE SENSOR" on page 8-79.	

FUEL INJECTION SYSTEM

Fault code No.	22	Symptom	Intake air temperature sensor-open or short circuit detected.	
Diagnostic code No.	05	Intake air temperature sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Installed condition of intake air temperature sensor		Check the installed area for looseness or pinching.	Turning the main switch ON.
2	Connected state of connector <ul style="list-style-type: none"> • Intake air temperature sensor coupler • Main wire harness ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	
3	Open or short circuit in wire harness and/or sub lead.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Main wire harness (Black/Blue–Black/Blue) (Brown/White–Brown/White) 	
4	Defective intake air temperature sensor.		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.05) • Replace if defective. Refer to "CHECKING THE INTAKE AIR TEMPERATURE SENSOR" on page 8-81.	

Fault code No.	24	Symptom	No normal signal is received from the O₂ sensor.	
Diagnostic code No.				
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Installed condition of O ₂ sensor		Check the installed area for looseness or pinching.	Starting the engine, warming it up until the coolant temperature is 60°C (140°F) or more, and then running it between 2000–3000 r/min until the engine trouble indicator turns off.
2	Connected state of connector <ul style="list-style-type: none"> • O₂ sensor coupler • Main wire harness ECU coupler • Sub-wire harness coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	
3	Open or short circuit in wire harness and/or sub lead.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Main wire harness (Gray/Green–Gray/Green) (Black/Blue–Black/Blue) (Red/White–Red/White) (Pink/Black–Pink/Black) 	
4	Check fuel pressure.		Refer to "CHECKING THE FUEL PRESSURE" on page 7-6.	
5	Defective O ₂ sensor		Replace if defective.	

FUEL INJECTION SYSTEM

Fault code No.	30	Symptom	Latch up detected. No normal signal is received from the lean angle sensor.	
Diagnostic code No.	08	Lean angle sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	The vehicle has overturned.		Raise the vehicle upright.	Turning the main switch ON (however, the engine cannot be restarted unless the main switch is first turned OFF).
2	Installed state of the lean angle sensor.		Check the installed direction and condition of the sensor.	
3	Defective lean angle sensor.		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.08) • Replace if defective. Refer to "CHECKING THE LEAN ANGLE SENSOR" on page 8-75.	

Fault code No.	33	Symptom	Malfunction detected in the primary wire of the ignition coil (#1/#4).	
Diagnostic code No.	30	Ignition coil (#1/#4)		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connected state of connector <ul style="list-style-type: none"> • Ignition coil primary side coupler (Orange/Black) • Main wire harness ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	Starting the engine and operating it at idle.
2	Open or short circuit in wire harness and/or sub lead.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between ignition coil coupler (#1/#4) and ECU coupler/main wire harness. (Orange/Black–Orange/Black) (Red/Black–Red/Black) 	
3	Defective ignition coil (#1/#4)		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.30) • Test the primary and secondary coils for continuity. • Replace if defective. Refer to "CHECKING THE IGNITION COILS" on page 8-74.	

FUEL INJECTION SYSTEM

Fault code No.	34	Symptom	Malfunction detected in the primary wire of the ignition coil (#2/#3).	
Diagnostic code No.	31	Ignition coil (#2/#3)		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connected state of connector • Ignition coil primary side coupler (Gray/Black) • Main wire harness ECU coupler		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	Starting the engine and operating it at idle.
2	Open or short circuit in wire harness and/or sub lead.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between ignition coil coupler (#2/#3) and ECU coupler/main wire harness. (Gray/Black–Gray/Black) (Red/Black–Red/Black) 	
3	Defective ignition coil (#2/#3)		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.31) • Test the primary and secondary coils for continuity. • Replace if defective. Refer to "CHECKING THE IGNITION COILS" on page 8-74.	

Fault code No.	41	Symptom	Lean angle sensor-open or short circuit detected.	
Diagnostic code No.	08	Lean angle sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connected state of connector • Lean angle sensor coupler • Main wire harness ECU coupler		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	Turning the main switch ON.
2	Open or short circuit in wire harness and/or sub lead.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between lean angle sensor coupler and ECU coupler. (Black/Blue–Black/Blue) (Yellow/Green–Yellow/Green) (Blue–Blue) 	
3	Defective lean angle sensor		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.08) • Replace if defective. 	

FUEL INJECTION SYSTEM

Fault code No.	42	Symptom		A No normal signals are received from the speed sensor. B Open or short circuit is detected in the neutral switch.	
Diagnostic code No.	A	07	Speed sensor		
	B	21	Neutral switch		
Order	Item/components and probable cause			Check or maintenance job	Reinstatement method
A-1	Connected state of connector • Speed sensor coupler • Main wire harness ECU coupler			<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 	Starting the engine, and inputting the vehicle speed signals by operating the vehicle at a 20 to 30 km/h.
A-2	Open or short circuit in speed sensor lead.			<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between speed sensor coupler and ECU coupler. (Blue–Blue) (White/Yellow–White/Yellow) (Black/Blue–Black/Blue) 	
A-3	Gear for detecting vehicle speed has broken.			<ul style="list-style-type: none"> • Replace if defective. Refer to "CHECKING THE SPEED SENSOR" on page 8-78. 	
A-4	Defective speed sensor			<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.07) • Replace if defective. Refer to "CHECKING THE SPEED SENSOR" on page 8-78. 	
B-1	Connected state of connector • Neutral switch coupler • Main wire harness ECU coupler			<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 	Starting the engine, and inputting the vehicle speed signals by operating the vehicle at a 20 to 30 km/h.
B-2	Open or short circuit in neutral switch lead.			<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between neutral switch connector and relay unit coupler (Sky blue–Sky blue) 	
B-3	Faulty shift drum (neutral detection area)			<ul style="list-style-type: none"> • Replace if defective. Refer to "TRANSMISSION" on page 5-74. 	
B-4	Defective neutral switch.			<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.21) • Replace if defective. Refer to "CHECKING THE SWITCHES" on page 8-63. 	

FUEL INJECTION SYSTEM

Fault code No.	43	Symptom	The ECU is unable to monitor the battery voltage.	
Diagnostic code No.	50	Fuel injection system relay		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connected state of connector • Fuel injection system relay coupler • Main wire harness ECU coupler		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	Starting the engine and operating it at idle.
2	Open or short circuit in the wire harness.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Main wire harness (Red-Red) (Red/Black-Red/Black) (Red/Blue-Red/Blue) (Blue/Yellow-Blue/Yellow) 	
3	Malfunction or open circuit in fuel injection system relay		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No. 50) • Replace if defective. • If there is no malfunction with the fuel injection system relay, replace the ECU. 	

Fault code No.	44	Symptom	An error is detected while reading or writing on EEPROM (CO adjustment value).	
Diagnostic code No.	60	EEPROM fault cylinder No.		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Malfunction in ECU		<ul style="list-style-type: none"> • Set the faulty cylinder's exhaust gas volume. 1 Execute the diagnostic mode (Code No. 60) to check the faulty cylinder number. (If multiple cylinders are defective, the numbers of the faulty cylinders are displayed alternately at 2-second intervals.) • Replace ECU if it does not recover from the malfunction. 	Turning the main switch ON. (Readjust the exhaust gas volume after it is reinstated.)

FUEL INJECTION SYSTEM

Fault code No.	46	Symptom	Power supply to the FI system relay is not normal.	
Diagnostic monitoring code No.		—	—	
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connected state of connector. • Main wire harness ECU coupler		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	Starting the engine and operating it at idle.
2	Faulty battery		<ul style="list-style-type: none"> • Replace or change the battery Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-68. 	
3	The malfunction of the rectifier/regulator		<ul style="list-style-type: none"> • Replace if defective. Refer to "CHARGING SYSTEM" on page 8-11. 	
4	Open or short circuit in wire harness.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between battery and main switch Red-Red • Between main switch and Fuse (ignition) (Brown/Blue-Brown/Blue) • Between Fuse (ignition) and ECU (Red/White-Red/White) 	

Fault code No.	50	Symptom	Faulty ECU memory. (When this malfunction is detected in the ECU, the fault code number might not appear on the meter.)	
Diagnostic code No.		—	—	
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Malfunction in ECU		Replace the ECU.	Turning the main switch ON.

FUEL INJECTION SYSTEM

Fault code No.	Er-1	Symptom	No signals are received from the ECU.	
Diagnostic code No.	—	—		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connected state of connector <ul style="list-style-type: none"> • Main wire harness ECU coupler • Main wire harness meter coupler • Sub-wire harness coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	Reinstated automatically when it receives a normal signal.
2	Open or short circuit in wire harness and/or sub lead		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between meter coupler and ECU coupler (Yellow/Blue–Yellow/Blue) (Black/White–Black/White) 	
3	Malfunction in meter unit		Replace the meter unit.	
4	Malfunction in ECU		Replace the ECU.	

Fault code No.	Er-2	Symptom	No signals are received from the ECU within the specified duration.	
Diagnostic code No.	—	—		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connected state of connector <ul style="list-style-type: none"> • Main wire harness ECU coupler • Main wire harness meter coupler • Sub-wire harness coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	Reinstated automatically when it receives a normal signal.
2	Open or short circuit in wire harness and/or sub lead		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between meter coupler and ECU coupler (Yellow/Blue–Yellow/Blue) (Black/White–Black/White) 	
3	Malfunction in meter unit		Replace the meter unit.	
4	Malfunction in ECU		Replace the ECU.	

FUEL INJECTION SYSTEM

Fault code No.	Er-3	Symptom	Data from the ECU cannot be received correctly.	
Diagnostic code No.	—	—		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connected state of connector <ul style="list-style-type: none"> • Main wire harness ECU coupler • Main wire harness meter coupler • Sub-wire harness coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	Reinstated automatically when it receives a normal signal.
2	Open or short circuit in wire harness and/or sub lead		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between meter coupler and ECU coupler (Yellow/Blue–Yellow/Blue) (Black/White–Black/White) 	
3	Malfunction in meter unit		Replace the meter unit.	
4	Malfunction in ECU		Replace the ECU.	


Fault code No.	Er-4	Symptom	Non-registered data has been received from the meter.	
Diagnostic code No.	—	—		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connected state of connector <ul style="list-style-type: none"> • Main wire harness ECU coupler • Main wire harness meter coupler • Sub-wire harness coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect it securely. 	Reinstated automatically when it receives a normal signal.
2	Open or short circuit in wire harness and/or sub lead		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between meter coupler and ECU coupler (Yellow/Blue–Yellow/Blue) (Black/White–Black/White) 	
3	Malfunction in meter unit		Replace the meter unit.	
4	Malfunction in ECU		Replace the ECU.	

EAS27550

FUEL PUMP SYSTEM

EAS27560

CIRCUIT DIAGRAM



- 1. Main switch
- 5. Fuel injection system fuse
- 7. Main fuse
- 9. Battery
- 10. Starting circuit cut-off relay
- 13. Fuel pump
- 21. ECU (engine control unit)
- 46. Engine stop switch
- 53. Ignition fuse

EAS27570

TROUBLESHOOTING

If the fuel pump fails to operate.

NOTE:


- Before troubleshooting, remove the following part(s):

1. Seat
2. Front cowling inner panel³
3. Fuel tank

<p>1. Check the fuses. (Main, ignition and fuel injection system) Refer to "CHECKING THE FUSES" on page 8-67.</p>	NG→	<p>Replace the fuse(s).</p>
OK↓		
<p>2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-68.</p>	NG→	<ul style="list-style-type: none"> • Clean the battery terminals. • Recharge or replace the battery.
OK↓		
<p>3. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-63.</p>	NG→	<p>Replace the main switch.</p>
OK↓		
<p>4. Check the engine stop switch. Refer to "CHECKING THE SWITCHES" on page 8-63.</p>	NG→	<p>Replace the right handlebar switch.</p>
OK↓		
<p>5. Check the starting circuit cut-off relay. Refer to "CHECKING THE RELAYS" on page 8-71.</p>	NG→	<p>Replace the starting circuit cut-off relay.</p>
OK↓		
<p>6. Check the fuel pump. Refer to "CHECKING THE FUEL PRESSURE" on page 7-6.</p>	NG→	<p>Replace the fuel pump.</p>
OK↓		
<p>7. Check the entire fuel pump system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-55.</p>	NG→	<p>Properly connect or repair the fuel pump system's wiring.</p>
OK↓		
<p>Replace the ECU.</p>		

EAS27970


ELECTRICAL COMPONENTS



ELECTRICAL COMPONENTS

1. Main switch
2. Front brake light switch
3. Starter relay
4. Battery
5. Fuse box
6. Rear brake light switch
7. Neutral switch
8. Sidestand switch
9. Oil level switch
10. Radiator fan motor
11. Horn
12. Ignition coil

ELECTRICAL COMPONENTS




ELECTRICAL COMPONENTS

1. Coolant temperature sensor
2. Throttle position sensor
3. Intake air temperature sensor
4. Fuel pump
5. Intake air pressure sensor
6. ECU (engine control unit)
7. Lean angle sensor
8. Starting circuit cut-off relay
9. Dimmer relay
10. Radiator fan motor relay
11. Turn signal relay
12. Rectifier/regulator

ELECTRICAL COMPONENTS

EAS27980

CHECKING THE SWITCHES



ELECTRICAL COMPONENTS

1. Main switch
2. Horn switch
3. Dimmer switch
4. Turn signal switch
5. Hazard switch
6. Clutch switch
7. Sidestand switch
8. Engine stop switch
9. Front brake light switch
10. Start switch
11. Oil level switch
12. Neutral switch
13. Rear brake light switch
14. Fuse
15. Left handlebar switch lead coupler

ELECTRICAL COMPONENTS

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

ECA14370

CAUTION:


Never insert the tester probes into the coupler terminal slots "a". Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

NOTE:

- Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.
- When checking for continuity, switch back and forth between the switch positions a few times.



The terminal connections for switches (e.g., main switch, engine stop switch) are shown in an illustration similar to the one on the left.

The switch positions "a" are shown in the far left column and the switch lead colors "b" are shown in the top row in the switch illustration.


NOTE:

"○—○" indicates a continuity of electricity between switch terminals (i.e., a closed circuit at the respective switch position).

The example illustration on the left shows that:

There is continuity between black and black/white when the switch is set to "OFF".

There is continuity between red and brown when the switch is set to "ON".



Checking the condition of the bulb sockets

The following procedure applies to all of the bulb sockets.

1. Check:
 - Bulb socket (for continuity) (with the pocket tester)
No continuity → Replace.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

NOTE:

Check each bulb socket for continuity in the same manner as described in the bulb section; however, note the following.

- a. Install a good bulb into the bulb socket.
- b. Connect the pocket tester probes to the respective leads of the bulb socket.
- c. Check the bulb socket for continuity. If any of the readings indicate no continuity, replace the bulb socket.

EAS4S81029

CHECKING THE LEDS

The following procedures applies to all of the LEDs.

1. Check:
 - LED (for proper operation)
Improper operation → Replace.


- a. Disconnect the meter assembly coupler (meter assembly side).
- b. Connect two jumper leads “1” from the battery terminals to the respective coupler terminal as shown.

EWA4S81013



WARNING

- A wire that is used as a jumper lead must have at least the same capacity of the battery lead, otherwise the jumper lead may burn.
- This check is likely to produce sparks, therefore, make sure no flammable gas or fluid is in the vicinity.



- c. When the jumper leads are connected to the terminals the respective LED should illuminate.
Does not light → Replace the meter assembly.

EAS28000

CHECKING THE FUSES

The following procedure applies to all of the fuses.

ECA13680

CAUTION:

To avoid a short circuit, always set the main switch to “OFF” when checking or replacing a fuse.

1. Remove:
 - Seat
 - Right side cover
2. Check:
 - Fuse

- a. Connect the pocket tester to the fuse and check the continuity.

NOTE:

Set the pocket tester selector to “ $\Omega \times 1$ ”.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- b. If the pocket tester indicates “ ∞ ”, replace the fuse.

3. Replace:
 - Blown fuse

- a. Set the main switch to “OFF”.
- b. Install a new fuse of the correct amperage rating.
- c. Set on the switches to verify if the electrical circuit is operational.

- d. If the fuse immediately blows again, check the electrical circuit.

Fuses	Amperage rating	Q'ty
Main	30 A	1
Headlight	20 A	1
Signal	10 A	1
Ignition	10 A	1
Tail	10 A	1
Radiator fan motor	20 A	1
Fuel injection system	10 A	1
Backup	10 A	1
Reserve	10 A	1
Reserve	20 A	1
Reserve	30 A	1

EWA13310

WARNING

Never use a fuse with an amperage rating other than that specified. Improvising or using a fuse with the wrong amperage rating may cause extensive damage to the electrical system, cause the lighting and ignition systems to malfunction and could possibly cause a fire.



4. Install:
- Right side cover
 - Seat

EAS28030

CHECKING AND CHARGING THE BATTERY

EWA13290

WARNING

Batteries generate explosive hydrogen gas and contain electrolyte which is made of poisonous and highly caustic sulfuric acid. Therefore, always follow these preventive measures:

- Wear protective eye gear when handling or working near batteries.
- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks or open flames (e.g., welding equipment, lighted cigarettes).
- DO NOT SMOKE when charging or handling batteries.
- KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.

- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.

FIRST AID IN CASE OF BODILY CONTACT: EXTERNAL

- Skin — Wash with water.
- Eyes — Flush with water for 15 minutes and get immediate medical attention.

INTERNAL

- Drink large quantities of water or milk followed with milk of magnesia, beaten egg or vegetable oil. Get immediate medical attention.

ECA13660

CAUTION:

- This is a sealed battery. Never remove the sealing caps because the balance between cells will not be maintained and battery performance will deteriorate.
- Charging time, charging amperage and charging voltage for an MF battery are different from those of conventional batteries. The MF battery should be charged as explained in the charging method illustrations. If the battery is overcharged, the electrolyte level will drop considerably. Therefore, take special care when charging the battery.

NOTE:

Since MF batteries are sealed, it is not possible to check the charge state of the battery by measuring the specific gravity of the electrolyte. Therefore, the charge of the battery has to be checked by measuring the voltage at the battery terminals.


1. Remove:
- Seat
 - Front cowling inner panel
 - Fuel tank

2. Disconnect:
 - Battery leads
(from the battery terminals)

ECA13640

CAUTION:

First, disconnect the negative battery lead “1”, and then positive battery lead “2”.



3. Remove:
 - Battery
4. Check:
 - Battery charge



- a. Connect a pocket tester to the battery terminals.

- Positive tester probe → positive battery terminal
- Negative tester probe → negative battery terminal

NOTE:

- The charge state of an MF battery can be checked by measuring its open-circuit voltage (i.e., the voltage when the positive battery terminal is disconnected).
- No charging is necessary when the open-circuit voltage equals or exceeds 12.8 V.

- b. Check the charge of the battery, as shown in the charts and the following example.

Example
Open-circuit voltage = 12.0 V
Charging time = 6.5 hours
Charge of the battery = 20–30%



5. Charge:
 - Battery
(refer to the appropriate charging method illustration)

EWA13300

WARNING

Do not quick charge a battery.

ECA13670

CAUTION:

- Never remove the MF battery sealing caps.
- Do not use a high-rate battery charger since it forces a high-amperage current into the battery quickly and can cause battery overheating and battery plate damage.
- If it is impossible to regulate the charging current on the battery charger, be careful not to overcharge the battery.
- When charging a battery, be sure to remove it from the vehicle. (If charging has to be done with the battery mounted on the vehicle, disconnect the negative battery lead from the battery terminal.)
- To reduce the chance of sparks, do not plug in the battery charger until the battery charger leads are connected to the battery.
- Before removing the battery charger lead clips from the battery terminals, be sure to turn off the battery charger.
- Make sure the battery charger lead clips are in full contact with the battery terminal and that they are not shorted. A corroded battery charger lead clip may generate heat in the contact area and a weak clip spring may cause sparks.
- If the battery becomes hot to the touch at any time during the charging process, disconnect the battery charger and let the battery cool before reconnecting it. Hot batteries can explode!
- As shown in the following illustration, the open-circuit voltage of an MF battery stabilizes about 30 minutes after charging has been completed. Therefore, wait 30 minutes after charging is completed before measuring the open-circuit voltage.



Charging method using a variable-current (voltage) charger

- a. Measure the open-circuit voltage prior to charging.

ELECTRICAL COMPONENTS

NOTE:

Voltage should be measured 30 minutes after the machine is stopped.

- b. Connect a charged and AMP meter to the battery and start charging.

NOTE:

Set the charging voltage at 16–17 V. If the setting is lower, charging will be insufficient. If too high, the battery will be over-charged.

- c. Make sure that the current is higher than the standard charging current written on the battery.

NOTE:

If the current is lower than the standard charging current written on the battery, set the charging voltage adjust dial at 20–24 V and monitor the amperage for 3–5 minutes to check the battery.

- Reach the standard charging current
Battery is good.
- Does not reach the standard charging current
Replace the battery.

- d. Adjust the voltage so that the current is at the standard charging level.
- e. Set the time according to the charging time suitable for the open-circuit voltage. Refer to “Battery condition checking steps”.
- f. If charging requires more than 5 hours, it is advisable to check the charging current after a lapse of 5 hours. If there is any change in the amperage, readjust the voltage to obtain the standard charging current.
- g. Measure the battery open-circuit voltage after leaving the battery unused for more than 30 minutes.

12.8 V or more --- Charging is complete.
12.7 V or less --- Recharging is required.
Under 12.0 V --- Replace the battery.



Charging method using a constant voltage charger

- a. Measure the open-circuit voltage prior to charging.

NOTE:

Voltage should be measured 30 minutes after the machine is stopped.

- b. Connect a charger and AMP meter to the battery and start charging.
- c. Make sure that the current is higher than the standard charging current written on the battery.

NOTE:

If the current is lower than the standard charging current written on the battery, This type of battery charger cannot charge the MF battery. A variable voltage charger is recommended.

- d. Charge the battery until the battery’s charging voltage is 15 V.

NOTE:

Set the charging time at 20 hours (maximum).

- e. Measure the battery open-circuit voltage after leaving the battery unused for more than 30 minutes.

12.8 V or more --- Charging is complete.
12.7 V or less --- Recharging is required.
Under 12.0 V --- Replace the battery.




- 6. Install:
 - Battery
- 7. Connect:
 - Battery leads
(to the battery terminals)

ECA13630

CAUTION:

First, connect the positive battery lead “1”, and then the negative battery lead “2”.



- 8. Check:
 - Battery terminals
Dirt → Clean with a wire brush.
Loose connection → Connect properly.

9. Lubricate:
 - Battery terminals



10. Install:
 - Fuel tank
 - Front cowling inner panel
 - Seat


EAS28040

CHECKING THE RELAYS


Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, replace the relay.




1. Disconnect the relay from the wire harness.
2. Connect the pocket tester ($\Omega \times 1$) and battery (12 V) to the relay terminal as shown. Check the relay operation. Out of specification → Replace.



1. Positive battery terminal
2. Negative battery terminal
3. Positive tester probe
4. Negative tester probe




Relay unit (starting circuit cut-off relay)




1. Positive battery terminal


2. Negative battery terminal
3. Positive tester probe
4. Negative tester probe




Relay unit (fuel pump relay)




1. Positive battery terminal
2. Negative battery terminal
3. Positive tester probe
4. Negative tester probe




Headlight relay



1. Positive battery terminal
2. Negative battery terminal
3. Positive tester probe
4. Negative tester probe



Radiator fan motor



1. Positive battery terminal
2. Negative battery terminal
3. Positive tester probe
4. Negative tester probe



Result
Continuity/No continuity
(between “3” to “4”)

EAS4S81032

CHECKING THE TURN SIGNAL/HAZARD RELAY

1. Check:
 - Turn signal/hazard relay input voltage
Out of specification → The wiring circuit from the main switch to the turn signal/hazard relay coupler is faulty and must be repaired.




Turn signal/hazard relay input voltage
DC 12 V

- a. Connect the pocket tester (DC 20 V) to the turn signal/hazard relay terminal as shown.




Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Positive tester probe → Brown/Green “1”
- Negative tester probe → Ground



- b. Turn the main switch to “ON”.
- c. Measure the turn signal/hazard relay input voltage.

2. Check:
 - Turn signal/hazard relay output voltage
Out of specification → Replace.




Turn signal/hazard relay output voltage
DC 12 V

- a. Connect the pocket tester (DC 20 V) to the turn signal/hazard relay terminal as shown.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Positive tester probe → Brown/White “1”
- Negative tester probe → Ground



- b. Turn the main switch to “ON”.
- c. Measure the turn signal/hazard relay output voltage.

EAS28050

CHECKING THE RELAY UNIT (DIODE)

1. Check:
 - Relay unit (diode)
Out of specification → Replace.

EAS28100

CHECKING THE IGNITION COILS

The following procedure applies to all of the ignition coils.

1. Check:
 - Primary coil resistance
Out of specification → Replace.




Primary coil resistance
1.53–2.07 Ω at 20°C (68°F)

- a. Disconnect the ignition coil connectors from the ignition coil terminals.
- b. Connect the pocket tester ($\Omega \times 1$) to the ignition coil as shown.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Positive tester probe
Red/black
- Negative tester probe
Orange/Black (Gray/Black)



- c. Measure the primary coil resistance.

2. Check:
 - Secondary coil resistance
Out of specification → Replace.




Secondary coil resistance
12.0–18.0 k Ω at 20°C (68°F)

- a. Disconnect the spark plug cap from the ignition coil.
- b. Connect the pocket tester ($\Omega \times 1k$) to the ignition coil as shown.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Negative tester probe
Spark plug lead “1”
- Positive tester probe
Spark plug lead “2”



- c. Measure the secondary coil resistance.

3. Check:
 - Ignition spark gap
Out of specification → Replace.




Minimum ignition spark gap
6.0 mm (0.24 in)

- a. Disconnect the spark plug cap from the spark plug.
- b. Connect the ignition checker/dynamic spark tester “1” as shown.



Ignition checker
90890-06754
Opama pet-4000 spark checker
YM-34487



2. Spark plug cap
- c. Set the main switch to “ON”.
- d. Measure the ignition spark gap “a”.

18110202

- e. Crank the engine by pushing the starter switch and gradually increase the spark gap until a misfire occurs.



EAS28120

CHECKING THE CRANKSHAFT POSITION SENSOR

- Disconnect:
 - Crankshaft position sensor coupler (from the wire harness)
- Check:
 - Crankshaft position sensor resistance Out of specification → Replace the crankshaft position sensor.



Crankshaft position sensor
248–372 Ω at 20°C (68°F)




- Connect the pocket tester ($\Omega \times 100$) to the crankshaft position sensor coupler as shown.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Positive tester probe Gray "1"
- Negative tester probe Black "2"



- Measure the crankshaft position sensor resistance.



EAS28130

CHECKING THE LEAN ANGLE SENSOR

- Remove:
 - Lean angle sensor (from the bracket.)
- Check:
 - Lean angle sensor output voltage Out of specification → Replace.



Lean angle sensor output voltage
65°: 1.0–4.0 V




- Connect the lean angle sensor coupler to the wireharness.
- Connect the pocket tester (DC 20 V) to the lean angle sensor coupler as shown.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Positive tester probe Yellow/Green "1"
- Negative tester probe Black/Blue "2"



- When turn the lean angle sensor to 65°.
- Measure the lean angle sensor out put voltage.



EAS4S81035

CHECKING THE STARTOR MOTOR OPERATION

- Check:
 - Starter motor operation Does not operate → Perform the electric starting system troubleshooting, starting with step 5. Refer to "TROUBLESHOOTING" on page 9-1.




- Connect the positive battery terminal "1" and starter motor lead "2" with a jumper lead "3".

EWA13810



- A wire that is used as a jumper lead must have at least the same capacity of the battery, otherwise the jumper lead may burn.**

- This check is likely to produce sparks, therefore, make sure no flammable gas or fluid is in the vicinity.



18210801

b. Check the starter motor operation.



2. Check:
- Stator coil resistance
Out of specification → Replace the stator coil.

EAS28150

CHECKING THE STATOR COIL

1. Disconnect:
 - Stator coil coupler (from the wire harness)
2. Check:
 - Stator coil resistance
Out of specification → Replace the stator coil.

	<p>Stator coil resistance 0.22–0.34 Ω at 20°C (68°F)</p>
--	---




- a. Connect the pocket tester ($\Omega \times 1$) to the stator coil coupler as shown.

	<p>Pocket tester 90890-03112 Analog pocket tester YU-03112-C</p>
--	--

- Positive tester probe
White "1"
- Negative tester probe
White "2"

- Positive tester probe
White "1"
- Negative tester probe
White "3"

- Positive tester probe
White "2"
- Negative tester probe
White "3"



b. Measure the stator coil resistance.



EAS28170

CHECKING THE RECTIFIER/REGULATOR

1. Check:
 - Charging voltage
Out of specification → Replace the rectifier/regulator.


	<p>Charging voltage above 14 V at 5000 r/min</p>
--	---



- a. Set the engine tachometer to the ignition coil of cylinder #1.
- b. Connect the pocket tester (AC 20 V) to the rectifier/regulator coupler as shown.

	<p>Pocket tester 90890-03112 Analog pocket tester YU-03112-C</p>
--	--

- Positive tester probe
Red "1"
- Negative tester probe
Black "2"



- c. Start the engine and let it run at approximately 5000 r/min.
- d. Measure the rectifier/regulator input voltage.



EAS28180

CHECKING THE HORN

1. Check:
 - Horn resistance
 Out of specification → Replace.




Horn resistance
1.01–1.11 Ω at 20°C (68°F)

- a. Disconnect the horn leads from the horn terminals.
- b. Connect the pocket tester ($\Omega \times 1$) to the horn terminals.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C


- Positive tester probe
Horn terminal “1”
- Negative tester probe
Horn terminal “2”



- c. Measure the horn resistance.

2. Check:
 - Horn sound
 Faulty sound → Adjust or replace.


- a. Connect a battery (12 V) to the horn.
- b. Turn the adjusting screw in direction “a” or “b” until the specified horn sound is obtained.



EAS28190

CHECKING THE ENGINE OIL LEVEL GAUGE

1. Drain:
 - Engine oil
2. Remove:
 - Engine oil level gauge
(from the oil pan)
3. Check:
 - Engine oil level gauge resistance



Engine oil level gauge
Maximum level position resistance
114–126 Ω at 20°C (68°F)
Minimum level position resistance
484–536 Ω at 20°C (68°F)

- a. Connect the pocket tester ($\Omega \times 100$) to the engine oil level gauge terminal as shown.




Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

Maximum level position “A”

- Positive tester probe
Connector (white) “1”
- Negative tester probe
Body earth “2”

Minimum level position “B”

- Positive tester probe
Connector (white) “1”
- Negative tester probe
Body earth “3”



b. Measure the pickup coil resistance.



EAS28230

CHECKING THE FUEL SENDER

1. Remove:
 - Fuel tank
2. Disconnect:
 - Fuel pump coupler
 - Fuel sender coupler (from the wire harness)
3. Remove:
 - Fuel pump (from the fuel tank)
4. Check:
 - Fuel sender resistance
Out of specification → Replace the fuel pump assembly.




Fuel sender resistance (full)
20–26 Ω at 20°C (68°F)
Fuel sender resistance (empty)
134–140 Ω at 20°C (68°F)

- a. Connect the pocket tester ($\Omega \times 10$) to the fuel sender terminal as shown.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Positive tester probe
Green/White “1”
- Negative tester probe
Black “2”



- b. Measure the fuel sender resistance.



EAS28240

CHECKING THE SPEED SENSOR

1. Check:
 - Speed sensor output voltage
Out of specification → Replace.




Output voltage reading cycle
0.6 V–4.8 V–0.6 V–4.8 V

- a. Connect the pocket tester (DC 20 V) to the speed sensor coupler (wire harness side) as shown.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Positive tester probe
White/Yellow “1”
- Negative tester probe
Black/Blue “2”



- b. Set the main switch to “ON”.
- c. Elevate the rear wheel and slowly rotate it.
- d. Measure the voltage (DC 5 V) of White/Yellow and Black/Blue. With each full rotation of the rear wheel, the voltage reading should cycle from 0.6 V to 4.8 V to 0.6 V to 4.8 V.



EAS28250


CHECKING THE RADIATOR FAN MOTOR

1. Check:
 - Radiator fan motor
Faulty/rough movement → Replace.



- a. Disconnect the radiator fan motor coupler from the wire harness.
- b. Connect the battery (DC 12 V) as shown.

- Positive tester probe
Blue "1"
- Negative tester probe
Black "2"



- c. Measure the radiator fan motor movement.



EAS28260

CHECKING THE COOLANT TEMPERATURE SENSOR

1. Remove:
 - Coolant temperature sensor


EWA14130



WARNING

- Handle the coolant temperature sensor with special care.
- Never subject the coolant temperature sensor to strong shocks. If the coolant temperature sensor is dropped, replace it.

2. Check:
 - Coolant temperature sensor resistance
Out of specification → Replace.




Coolant temperature sensor
 5.21–6.37 kΩ at 0°C (32°F)
 0.29–0.35 kΩ at 80°C (176°F)



- a. Connect the pocket tester ($\Omega \times 100$) to the coolant temperature sensor "1" as shown.



Pocket tester
 90890-03112
Analog pocket tester
 YU-03112-C



- b. Immerse the coolant temperature sensor in a container filled with coolant "2".

NOTE: _____
 Make sure the coolant temperature sensor terminals do not get wet.

- c. Place a thermometer "3" in the coolant.
- d. Slowly heat the coolant, and then let it cool to the specified temperature indicated in the table.
- e. Check the coolant temperature sensor for continuity at the temperatures indicated in the table.



EAS28300

CHECKING THE THROTTLE POSITION SENSOR

1. Remove:
 - Throttle position sensor
(from the throttle body)
2. Check:
 - Throttle position sensor




- a. Connect the pocket tester ($\Omega \times 1k$) to the throttle position sensor as shown.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Tester positive lead → Blue "1"
- Tester negative lead → Black/Blue "2"




- b. Check the throttle position sensor maximum resistance.
 Out of specification → Replace the throttle position sensor.




Resistance
4.0–6.0 kΩ

- c. Connect the pocket tester ($\Omega \times 1k$) to the throttle position sensor as shown.

- Tester positive lead → Yellow "3"
- Tester negative lead → Black/Blue "2"



- d. While slowly turning the throttle position sensor shaft, check that the throttle position sensor resistance is within the specified range.
 The resistance does not change or it changes abruptly → Replace the throttle position sensor.



Throttle position sensor resistance
0 to 3.5–6.5 kΩ at 20°C (68°F)

3. Install:

- Throttle position sensor

NOTE:

When installing the throttle position sensor, adjust its angle properly. Refer to "ADJUSTING THE THROTTLE POSITION SENSOR" on page 7-6.

EAS28350

CHECKING THE FUEL PUMP

EWA13850




WARNING

Gasoline is extremely flammable and under certain circumstances there can be a danger of an explosion or fire. Be extremely careful and note the following points:

- Stop the engine before refueling.
- Do not smoke, and keep away from open flames, sparks, or any other source of fire.
- If you do accidentally spill gasoline, wipe it up immediately with dry rags.
- If gasoline touches the engine when it is hot, a fire may occur. Therefore, make sure the engine is completely cool before performing the following test.

1. Disconnect:
 - Fuel pump coupler (from the wire harness)
2. Check:
 - Fuel pump resistance
 Out of specification → Replace.




Fuel pump resistance
0.2–3.0 Ω at 20°C (68°F)

- a. Connect the pocket tester ($\Omega \times 1$) to the fuel pump coupler as shown.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Positive tester probe
 Red/blue "1"
- Negative tester probe
 Black "2"



b. Measure the fuel pump resistance.



EAS28370


CHECKING THE AIR INDUCTION SYSTEM SOLENOID

- Check:
 - Air induction system solenoid resistance
Out of specification → Replace.




Air induction system solenoid resistance
18–22 Ω at 20°C (68°F)

- Remove the air induction system solenoid coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) to the air induction system solenoid terminal as shown.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Positive tester probe
Brown/Red “1”
- Negative tester probe
Red/White “2”




c. Measure the air induction system solenoid resistance.



EAS28410

CHECKING THE INTAKE AIR PRESSURE SENSOR

- Check:
 - Intake air pressure sensor output voltage
Out of specification → Replace.




Intake air pressure sensor output voltage
3.75–4.25 V

- Connect the pocket tester (DC 20 V) to the intake air pressure sensor coupler (wire harness side) as shown.



Pocket tester
90890-03112
Analog pocket tester
YU-03112-C

- Positive tester probe
Pink/White “1”
- Negative tester probe
Black/Blue “2”



- Set the main switch to “ON”.
- Measure the intake air pressure sensor output voltage.



EAS28420

CHECKING THE INTAKE AIR TEMPERATURE SENSOR

- Remove:
 - Intake air temperature sensor
(from the air filter case.)

EWA14110



- Handle the intake air temperature sensor with special care.**
- Never subject the intake air temperature sensor to strong shocks. If the intake air temperature sensor is dropped, replace it.**

TROUBLESHOOTING

TROUBLESHOOTING	9-1
GENERAL INFORMATION	9-1
STARTING FAILURES	9-1
INCORRECT ENGINE IDLING SPEED	9-1
POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE	9-2
FAULTY GEAR SHIFTING	9-2
SHIFT PEDAL DOES NOT MOVE	9-2
JUMPS OUT OF GEAR	9-2
FAULTY CLUTCH	9-2
OVERHEATING	9-2
OVERCOOLING	9-3
POOR BRAKING PERFORMANCE	9-3
FAULTY FRONT FORK LEGS	9-3
UNSTABLE HANDLING	9-3
FAULTY LIGHTING OR SIGNALING SYSTEM	9-4

EAS28450

TROUBLESHOOTING

EAS28460

GENERAL INFORMATION

NOTE:

The following guide for troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to basic troubleshooting. Refer to the relative procedure in this manual for checks, adjustments, and replacement of parts.

EAS28470

STARTING FAILURES

Engine

1. Cylinder(s) and cylinder head(s)
 - Loose spark plug
 - Loose cylinder head or cylinder
 - Damaged cylinder head gasket
 - Damaged cylinder gasket
 - Worn or damaged cylinder
 - Incorrect valve clearance
 - Improperly sealed valve
 - Incorrect valve-to-valve-seat contact
 - Incorrect valve timing
 - Faulty valve spring
 - Seized valve
2. Piston(s) and piston ring(s)
 - Improperly installed piston ring
 - Damaged, worn or fatigued piston ring
 - Seized piston ring
 - Seized or damaged piston
3. Air filter
 - Improperly installed air filter
 - Clogged air filter element
4. Crankcase and crankshaft
 - Improperly assembled crankcase
 - Seized crankshaft

Fuel system

1. Fuel tank
 - Empty fuel tank
 - Clogged fuel filter
 - Clogged fuel tank drain hose
 - Deteriorated or contaminated fuel
2. Fuel pump
 - Faulty fuel pump
 - Faulty fuel pump relay
3. Throttle body(-ies)
 - Deteriorated or contaminated fuel
 - Sucked-in air

Electrical system

1. Battery
 - Discharged battery
 - Faulty battery
2. Fuse(s)
 - Blown, damaged or incorrect fuse
 - Improperly installed fuse
3. Spark plug(s)
 - Incorrect spark plug gap
 - Incorrect spark plug heat range
 - Fouled spark plug
 - Worn or damaged electrode
 - Worn or damaged insulator
 - Faulty spark plug cap
4. Ignition coil(s)
 - Cracked or broken ignition coil body
 - Broken or shorted primary or secondary coils
 - Faulty spark plug lead
5. Ignition system
 - Faulty ECU
 - Faulty crankshaft position sensor
6. Switches and wiring
 - Faulty main switch
 - Faulty engine stop switch
 - Broken or shorted wiring
 - Faulty neutral switch
 - Faulty start switch
 - Faulty sidestand switch
 - Faulty clutch switch
 - Improperly grounded circuit
 - Loose connections
7. Starting system
 - Faulty starter motor
 - Faulty starter relay
 - Faulty starting circuit cut-off relay
 - Faulty starter clutch

EAS28490

INCORRECT ENGINE IDLING SPEED

Engine

1. Cylinder(s) and cylinder head(s)
 - Incorrect valve clearance
 - Damaged valve train components
2. Air filter
 - Clogged air filter element

Fuel system

1. Throttle body(-ies)
 - Damaged or loose throttle body joint
 - Improperly synchronized carburetors
 - Improperly adjusted engine idling speed (throttle stop screw)

- Improper throttle cable free play
- Flooded throttle body
- Faulty air induction system

Electrical system

1. Battery
 - Discharged battery
 - Faulty battery
2. Spark plug(s)
 - Incorrect spark plug gap
 - Incorrect spark plug heat range
 - Fouled spark plug
 - Worn or damaged electrode
 - Worn or damaged insulator
 - Faulty spark plug cap
3. Ignition coil(s)
 - Broken or shorted primary or secondary coils
 - Faulty spark plug lead
 - Cracked or broken ignition coil
4. Ignition system
 - Faulty ECU
 - Faulty crankshaft position sensor

EAS28510

POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE

Refer to "STARTING FAILURES" on page 9-1.

Engine

1. Air filter
 - Clogged air filter element

Fuel system

1. Fuel pump
 - Faulty fuel pump

EAS28530

FAULTY GEAR SHIFTING

Shifting is difficult

Refer to "Clutch drags".

EAS28540

SHIFT PEDAL DOES NOT MOVE

Shift shaft

- Improperly adjusted shift rod
- Bent shift shaft

Shift drum and shift forks

- Foreign object in a shift drum groove
- Seized shift fork
- Bent shift fork guide bar

Transmission

- Seized transmission gear

- Foreign object between transmission gears
- Improperly assembled transmission

EAS28550

JUMPS OUT OF GEAR

Shift shaft

- Incorrect shift pedal position
- Improperly returned stopper lever

Shift forks

- Worn shift fork

Shift drum

- Incorrect axial play
- Worn shift drum groove

Transmission

- Worn gear dog

EAS28560

FAULTY CLUTCH

Clutch slips

1. Clutch
 - Improperly assembled clutch
 - Improperly adjusted clutch cable
 - Loose or fatigued clutch spring
 - Worn friction plate
 - Worn clutch plate
2. Engine oil
 - Incorrect oil level
 - Incorrect oil viscosity (low)
 - Deteriorated oil

Clutch drags

1. Clutch
 - Unevenly tensioned clutch springs
 - Warped pressure plate
 - Bent clutch plate
 - Swollen friction plate
 - Bent clutch push rod
 - Damaged clutch boss
 - Burnt primary driven gear bushing
 - Match marks not aligned
2. Engine oil
 - Incorrect oil level
 - Incorrect oil viscosity (high)
 - Deteriorated oil

EAS28600

OVERHEATING

Engine

1. Clogged coolant passages
 - Cylinder head(s) and piston(s)
 - Heavy carbon buildup

2. Engine oil
 - Incorrect oil level
 - Incorrect oil viscosity
 - Inferior oil quality

Cooling system

1. Coolant
 - Low coolant level
2. Radiator
 - Damaged or leaking radiator
 - Faulty radiator cap
 - Bent or damaged radiator fin
3. Water pump
 - Damaged or faulty water pump
 - Thermostat
 - Thermostat stays closed
 - Oil cooler
 - Clogged or damaged oil cooler
 - Hose(s) and pipe(s)
 - Damaged hose
 - Improperly connected hose
 - Damaged pipe
 - Improperly connected pipe

Fuel system

1. Throttle body(-ies)
 - Damaged or loose throttle body joint
2. Air filter
 - Clogged air filter element

Chassis

1. Brake(s)
 - Dragging brake

Electrical system

1. Spark plug(s)
 - Incorrect spark plug gap
 - Incorrect spark plug heat range
2. Ignition system
 - Faulty ECU
3. Cooling system
 - Faulty radiator fan motor relay
 - Faulty coolant temperature sensor
 - Faulty ECU

EAS28610

OVERCOOLING

Cooling system

1. Thermostat
 - Thermostat stays open

EAS28620

POOR BRAKING PERFORMANCE

- Worn brake pad

- Worn brake disc
- Air in hydraulic brake system
- Leaking brake fluid
- Faulty brake caliper kit
- Faulty brake caliper seal
- Loose union bolt
- Damaged brake hose
- Oil or grease on the brake disc
- Oil or grease on the brake pad
- Incorrect brake fluid level

EAS28660

FAULTY FRONT FORK LEGS

Leaking oil

- Bent, damaged or rusty inner tube
- Cracked or damaged outer tube
- Improperly installed oil seal
- Damaged oil seal lip
- Incorrect oil level (high)
- Loose damper rod assembly bolt
- Damaged damper rod assembly bolt copper washer
- Cracked or damaged cap bolt O-ring

Malfunction

- Bent or damaged inner tube
- Bent or damaged outer tube
- Damaged fork spring
- Worn or damaged outer tube bushing
- Bent or damaged damper rod
- Incorrect oil viscosity
- Incorrect oil level

EAS28670

UNSTABLE HANDLING

1. Handlebar
 - Bent or improperly installed handlebar
2. Steering head components
 - Improperly installed upper bracket
 - Improperly installed lower bracket (improperly tightened ring nut)
 - Bent steering stem
 - Damaged ball bearing or bearing race
3. Front fork leg(s)
 - Uneven oil levels (both front fork legs)
 - Unevenly tensioned fork spring (both front fork legs)
 - Broken fork spring
 - Bent or damaged inner tube
 - Bent or damaged outer tube
4. Swingarm
 - Worn bearing or bushing
 - Bent or damaged swingarm
5. Rear shock absorber assembly(-ies)

- Faulty rear shock absorber spring
 - Leaking oil or gas
6. Tire(s)
- Uneven tire pressures (front and rear)
 - Incorrect tire pressure
 - Uneven tire wear
7. Wheel(s)
- Incorrect wheel balance
 - Deformed cast wheel
 - Damaged wheel bearing
 - Bent or loose wheel axle
 - Excessive wheel runout
8. Frame
- Bent frame
 - Damaged steering head pipe
 - Improperly installed bearing race

EAS28710

FAULTY LIGHTING OR SIGNALING SYSTEM

Headlight does not come on

- Wrong headlight bulb
- Too many electrical accessories
- Hard charging
- Incorrect connection
- Improperly grounded circuit
- Poor contacts (main or light switch)
- Burnt-out headlight bulb

Headlight bulb burnt out

- Wrong headlight bulb
- Faulty battery
- Faulty rectifier/regulator
- Improperly grounded circuit
- Faulty main switch
- Faulty light switch
- Headlight bulb life expired

Tail/brake light does not come on

- Wrong tail/brake light bulb
- Too many electrical accessories
- Incorrect connection
- Burnt-out tail/brake light bulb

Tail/brake light bulb burnt out

- Wrong tail/brake light bulb
- Faulty battery
- Incorrectly adjusted rear brake light switch
- Tail/brake light bulb life expired

Turn signal does not come on

- Faulty turn signal switch
- Faulty turn signal relay
- Burnt-out turn signal bulb

- Incorrect connection
- Damaged or faulty wire harness
- Improperly grounded circuit
- Faulty battery
- Blown, damaged or incorrect fuse

Turn signal blinks slowly

- Faulty turn signal relay
- Faulty main switch
- Faulty turn signal switch
- Incorrect turn signal bulb

Turn signal remains lit

- Faulty turn signal relay
- Burnt-out turn signal bulb

Turn signal blinks quickly

- Incorrect turn signal bulb
- Faulty turn signal relay
- Burnt-out turn signal bulb

Horn does not sound

- Improperly adjusted horn
- Damaged or faulty horn
- Faulty main switch
- Faulty horn switch
- Faulty battery
- Blown, damaged or incorrect fuse
- Faulty wire harness

EAS28740

WIRING DIAGRAM

FZS6W/FZS6WC

1. Main switch
2. AC magneto
3. Rectifier/regulator
4. Backup fuse
5. Fuel injection system fuse
6. Main fuse
7. Starter relay
8. Starter motor
9. Battery
10. Starting circuit cut-off relay
11. Sidestand switch
12. Neutral switch
13. Fuel pump
14. Throttle position sensor
15. Intake air pressure sensor
16. O₂ sensor
17. Lean angle sensor
18. Crankshaft position sensor
19. Intake air temperature sensor
20. Coolant temperature sensor
21. ECU (engine control unit)
22. Injector #1
23. Injector #2
24. Injector #3
25. Injector #4
26. Air induction system solenoid
27. Speed sensor
28. Cylinder-#1/#4 ignition coil
29. Cylinder-#2/#3 ignition coil
30. Spark plug
31. Meter assembly
32. Fuel level warning light
33. Oil level warning light
34. Neutral indicator light
35. Tachometer
36. Multi-function meter
37. Engine trouble warning light
38. Coolant temperature warning light
39. High beam indicator light
40. Left turn signal indicator light
41. Right turn signal indicator light
42. Meter light
43. Oil level switch
44. Right handlebar switch
45. Front brake light switch
46. Engine stop switch
47. Start switch
48. Radiator fan motor fuse
49. Radiator fan motor relay
50. Radiator fan motor
51. Signal fuse
52. Headlight fuse
53. Ignition fuse
54. Tail fuse
55. Turn signal relay
56. Rear brake light switch

57. License plate light
58. Tail/brake light
59. Left handlebar switch
60. Clutch switch
61. Dimmer switch
62. Hazard switch
63. Turn signal switch
64. Horn switch
65. Horn
66. Headlight relay
67. Headlight (high beam)
68. Headlight (low beam)
69. Front left turn signal light
70. Front right turn signal light
71. Rear left turn signal light
72. Rear right turn signal light

R/Y	Red/Yellow
Sb/W	Sky blue/White
W/B	White/Black
W/R	White/Red
W/Y	White/Yellow
Y/B	Yellow/Black
Y/G	Yellow/Green
Y/L	Yellow/Blue
Y/R	Yellow/Red

EAS4S81044



COLOR CODE

B	Black
Br	Brown
Ch	Chocolate
Dg	Dark green
G	Green
Gy	Gray
L	Blue
O	Orange
P	Pink
R	Red
Sb	Sky blue
W	White
Y	Yellow
B/G	Black/Green
B/L	Black/Blue
B/R	Black/Red
B/W	Black/White
B/Y	Black/Yellow
Br/G	Brown/Green
Br/L	Brown/Blue
Br/R	Brown/Red
Br/W	Brown/White
G/B	Green/Black
G/R	Green/Red
G/W	Green/White
G/Y	Green/Yellow
Gy/G	Gray/Green
Gy/R	Gray/Red
L/B	Blue/Black
L/R	Blue/Red
L/W	Blue/White
L/Y	Blue/Yellow
O/B	Orange/Black
P/W	Pink/White
R/B	Red/Black
R/G	Red/Green
R/L	Red/Blue
R/W	Red/White



YAMAHA MOTOR CO., LTD.
2500 SHINGAI IWATA SHIZUOKA JAPAN

FZS6W/FZS6WC WIRING DIAGRAM



FZS6W/FZS6WC WIRING DIAGRAM

